

Catalina P2 Command and Options Summary

Command (1)	C sources (1 +)	Propeller Hardware Version (1)	C library (<= 1)	Maths library (<= 1)	Other libraries (0 +)	Propeller Base Platform (<= 1)	Memory Model (<= 1)	Cache Option (<= 1)	Human/Machine Interface and Graphics Option (0 +)	Clock Frequency Options (<= 1)	Miscellaneous Options (0 +)
		-						-	-	-	
									-C TTY		-C NO_SCREEN
									-C SIMPLE		-C NO_MOUSE
									-C VGA		-C NO_KEYBOARD
									-C HD_VGA		-C CR_ON_LF
					-ltiny			-C CACHED_1K	-C LORES_VGA		-C NO_CR_TO_LF
			-lc	-lm	-lserial2	-C P2_EVAL	-C NATIVE	-C CACHED_2K	-C HIRES_VGA	-C MHZ_200	-C NON_ANSI_HMI
catalina	program.c	-p2	-lci	-lma	-lserial8	-C P2D2	-C COMPACT	-C CACHED_4K	-C VGA_640	-C MHZ_220	-C NO_LUT
			-lcix	-lmb	-lthreads	-C P2_EDGE	-C TINY	-C CACHED_8K	-C VGA_800	-C MHZ_260	-C NO_FIFO
			-lcx	-lmc	-lint	-C P2_CUSTOM	-C SMALL	-C CACHED_16K	-C VGA_1024	-C MHZ_297	-C CLOCK
					-lpsram		-C LARGE	-C CACHED_32K	-C MONO	-C MHZ_300	-C RTC
					-lhyper			-C CACHED_64K	-C COLOR_1		-C NO_FLOAT
					-lwifi			-C CACHED	-C COLOR_2		-C NO_ARGS
					-llinenoise				-C COLOR_4		-C NO_REBOOT
									-C COLOR_8		-C NO_EXIT
									-C COLOR_24		-C NO_LUT
									-C NO_HMI		-C P2_REV_A
											-C OPTIMIZE
											-C USE_USB_A
											-C USE_USB_B

All Command Line Options:

-? or -h	print this help (and exit)	-v	verbose (output information messages)
-B baud	baud rate to use for serial interfaces (P2 only)	-v -v	very verbose (more information messages)
-c	compile only (do not bind)	-W option	option to pass directly to LCC
-d	output diagnostic messages	-x layout	use specified segment layout (layout = 0 .. 6, 8 .. 11)
-C symbol	define a Catalina symbol (e.g. -C NO_GAMEPAD)	-y	generate listing file
-D symbol	define a symbol (e.g. -D printf=tiny_printf)	-Y	preprocess only (do not compile)
-E	allowable frequency error (default is 100k)	-z	don't invoke the parallelizer on input files that follow
-f freq	required clock frequency (see also -F & -E)	-Z	invoke the parallelizer on input files that follow
-F freq	crystal frequency (default is 20M)		
-g[level]	generate debugging information (default level = 1)		
-H addr	address of top of heap		
-I path	path to include files (default 'C:\Program Files (x86)\Catalina\include')		
-k	kill (suppress) statistics output		
-l lib	search library lib when binding		
-L path	path to libraries (default 'C:\Program Files (x86)\Catalina')		
-M size	maximum memory size (use with -x)		
-o name	name of output file (default is first file name)		
-O[level]	optimize code (default level = 1)		
-p ver	Propeller hardware version 1 or 2 (1 is the default)		
-q	enable quick build (re-use any existing target files)		
-P addr	address for Read-Write segments		
-R addr	address for Read-Only segments		
-S	compile to assembly code (do not bind)		
-t name	name of dedicated target to use		

-T path path to target files (default 'C:\Program Files (x86)\Catalina\target')
-U symbol undefine symbol (e.g. -U DEFAULT)