

Catalina P1 Command and Options Summary

Command	C sources	C library	Maths library	Other libraries	Propeller Base Platform	XMM Add-On Board	Propeller CPU	Memory Model	Loader Option	Cache Option	Human/Machine Interface and Graphics Option	Miscellaneous Options
(1)	(1 +)	(<= 1)	(<= 1)	(0 +)	(<= 1)	(<= 1)	(<= 1)	(<= 1)	(<= 1)	(<= 1)	(<= 1)	(0 +)
catalina	program.c	-lc -lci -lcix -lcx	-lm -lma -lmb	-ltiny -lserial4 -litty -litty256 -lthreads -lgraphics -lvgraphics -lsound -lspi	-C HYDRA -C HYBRID -C DEMO -C TRIBLADEPROP -C DRACBLADE -C RAMBLADE -C RAMBLADE3 -C C3 -C ASC -C CUSTOM -C PP -C QUICKSTART -C FLIP	-C SUPERQUAD -C RAMPAGE -C HX512 -C PMC -C RP2	-C CPU_1 -C CPU_2 -C CPU_3	-C COMPACT -C TINY -C SMALL -C LARGE	-C EEPROM -C SDCARD -C FLASH	-C CACHED_1K -C CACHED_2K -C CACHED_4K -C CACHED_8K -C CACHED -C VGA_2_COLOR -C VGA_4_COLOR	-C TV -C LORES_TV -C HIRES_TV -C VGA -C LORES_VGA -C HIRES_VGA -C PROPTERMINAL -C PC -C TTY -C NO_HMI -C DOUBLE_BUFFER -C VGA_640 -C VGA_800 -C VGA_1024 -C VGA_1152 -C NO_FLOAT -C NO_ARGS -C NO_REBOOT -C NO_EXIT	-C ALTERNATE -C NO_SCREEN -C NO_MOUSE -C NO_KEYBOARD -C PROXY_SCREEN -C PROXY_MOUSE -C PROXY_KEYBOARD -C PROXY_SD -C NTSC -C NO_INTERLACE -C CR_ON_LF -C NO_CR_TO_LF -C NON_ANSI_HMI -C CLOCK -C GAMEPAD -C SD

All Command Line Options:

-?	or -h	print this help (and exit)	-y	generate listing file
-b		generate a binary output file (this is the default)	-Y	preprocess only (do not compile)
-c		compile only (do not bind)	-z	don't invoke the parallelizer on input files that follow
-d		output diagnostic messages	-Z	invoke the parallelizer on input files that follow
-C symbol		define a Catalina symbol (e.g. -C NO_GAMEPAD)		
-D symbol		define a symbol (e.g. -D printf=tiny_printf)		
-e		generate an eeprom output file		
-g[level]		generate debugging information (default level = 1)		
-H addr		address of top of heap		
-I path		path to include files (default 'C:\Program Files (x86)\Catalina\include')		
-k		kill (suppress) statistics output		
-l lib		search library lib when binding		
-L path		path to libraries (default 'C:\Program Files (x86)\Catalina')		
-M size		maximum memory size (use with -x)		
-o name		name of output file (default is first file name)		
-O[level]		optimize code (default level = 1)		
-p ver		Propeller hardware version 1 or 2 (1 is the default)		
-P addr		address for Read-Write segments		
-R addr		address for Read-Only segments		
-S		compile to assembly code (do not bind)		
-t name		name of dedicated target to use		
-T path		path to target files (default 'C:\Program Files (x86)\Catalina\target')		
-U symbol		undefine symbol (e.g. -U DEFAULT)		
-v		verbose (output information messages)		
-v -v		very verbose (more information messages)		
-W option		option to pass directly to LCC		
-x layout		use specified segment layout (layout = 0 .. 6, 8 .. 10)		