

Catalina P2 Command and Options Summary

Command (1)	C sources (1 +)	Propeller Hardware Version (0+)	C library (<= 1)	Maths library (<= 1)	Other libraries (0 +)	Propeller Base Platform (<= 1)	Memory Model (<= 1)	Human/Machine Interface and Graphics Option (<= 1)	Clock Frequency Options (<= 1)	Miscellaneous Options (0 +)
catalina	program.c	-p1 -p2	-lc -lci -lcix -lcx	-lm -lma -lmb -lmc	-ltiny -lserial2 -lserial8 -lthreads -linterrupts -lpsram	-C P2_EVAL -C P2D2 -C P2_EDGE -C P2_CUSTOM	-C NATIVE -C COMPACT -C TINY	-C TTY -C SIMPLE -C VGA -C LORES_VGA -C HIRES_VGA -C VGA_640 -C VGA_800 -C VGA_1024 -C MONO -C COLOR_1 -C COLOR_4 -C COLOR_8 -C COLOR_24 -C NO_HMI	-C MHZ_200 -C MHZ_220 -C MHZ_260	-C NO_SCREEN -C NO_MOUSE -C NO_KEYBOARD -C CR_ON_LF -C NO_CR_TO_LF -C NON_ANSI_HMI -C CLOCK -C NO_FLOAT -C NO_ARGS -C NO_REBOOT -C NO_EXIT -C P2_REV_A

All Command Line Options:

-?	or -h	print this help (and exit)	-y	generate listing file
-B	baud	baud rate to use for serial interfaces (P2 only)	-Y	preprocess only (do not compile)
-c		compile only (do not bind)	-z	don't invoke the parallelizer on input files that follow
-d		output diagnostic messages	-Z	invoke the parallelizer on input files that follow
-C	symbol	define a Catalina symbol (e.g. -C NO_GAMEPAD)		
-D	symbol	define a symbol (e.g. -D printf=tiny_printf)		
-E		allowable frequency error (default is 100k)		
-f	freq	required clock frequency (see also -F & -E)		
-F	freq	crystal frequency (default is 20M)		
-g[level]		generate debugging information (default level = 1)		
-H	addr	address of top of heap		
-I	path	path to include files (default 'C:\Program Files (x86)\Catalina\include')		
-k		kill (suppress) statistics output		
-l	lib	search library lib when binding		
-L	path	path to libraries (default 'C:\Program Files (x86)\Catalina')		
-M	size	maximum memory size (use with -x)		
-o	name	name of output file (default is first file name)		
-O[level]		optimize code (default level = 1)		
-p	ver	Propeller hardware version 1 or 2 (1 is the default)		
-q		enable quick build (re-use any existing target files)		
-P	addr	address for Read-Write segments		
-R	addr	address for Read-Only segments		
-S		compile to assembly code (do not bind)		
-t	name	name of dedicated target to use		
-T	path	path to target files (default 'C:\Program Files (x86)\Catalina\target')		
-U	symbol	undefine symbol (e.g. -U DEFAULT)		
-v		verbose (output information messages)		
-v -v		very verbose (more information messages)		
-W	option	option to pass directly to LCC		
-x	layout	use specified segment layout (layout = 0 .. 6, 8 .. 11)		