

ESP32-S3-N16R8 + 4-Channel Relay Module

Dometic Brisk II Direct Wiring (No Control Box)

SSR-25DA Compressor + Direct Fan Relay Switching

1. Overview

This document describes how to wire the ESP32-S3-N16R8 dev board with an external 4-channel relay module to control the Dometic Brisk II rooftop AC unit. The Dometic Etratech control box (P/N 3313199.000) is eliminated. The relay module has 4 channels (10A each, active HIGH via jumper) and controls all loads via two switching stages:

- SSR-25DA solid state relay for the compressor (25A capacity, handles ~12A running current and inrush). Triggered by CH2 relay via 12VDC.
- Relay CH3/CH4 for fans (10A contacts, adequate for ~2-3A fan motors). These switch 120VAC directly.
- Relay CH1 for furnace (dry contact closure to standalone unit with its own blower).

CH2 does NOT switch 120VAC for the compressor. Instead, it switches 12VDC from the RV battery to the SSR-25DA DC input, which then switches 120VAC to the compressor. This keeps all high-current switching on the SSR while CH2 handles only milliamp-level 12VDC trigger current.

WARNING: This system switches 120VAC through the SSR-25DA and relay module contacts. All 120VAC wiring must be in a proper junction box with 14 AWG wire (minimum for 15A circuit). The SSR-25DA must be mounted on a heatsink. Disconnect shore power before all wiring work.

2. System Architecture

Compressor Signal Path

ESP32 GPIO 5 HIGH -> Relay CH2 closes -> 12VDC from RV battery reaches SSR-25DA DC+ input -> SSR turns ON -> 120VAC LINE flows through SSR AC output -> Supco SFPC freeze stat (NC) -> 6-pin Blue wire -> Compressor motor

The SSR-25DA handles the full compressor load current (25A rating vs ~12A running). The CH2 relay only switches 12VDC at milliamps to trigger the SSR. This eliminates relay contact wear and welding risk.

Fan Signal Path

ESP32 GPIO 6/7 HIGH -> Relay CH3/CH4 closes -> 120VAC LINE flows directly through relay NO contact -> 6-pin Red/Black wire -> Fan motor. Fan motors draw ~2-3A, well within the relay 10A contact rating.

Freeze Protection (Dual-Layer)

With the Etratech control box removed, the built-in K1 freeze relay is gone. Freeze protection is now provided by two independent layers:

- SOFTWARE: DS18B20 waterproof probe on the evaporator coil, connected to ESP32 GPIO 42. When

evaporator temp drops below 32F, the ESP32 cuts the compressor (GPIO 5 LOW). Held off until evaporator recovers to 45F.

- **HARDWARE BACKUP:** Supco SFPC freeze protection control. Clamp-on device that snaps onto the suction line. Normally closed, opens at 35F, closes at 50F. Wired in series between SSR AC2 output and the 6-pin Blue wire. Independent of ESP32 -- passive, unpowered, fail-safe.

3. Component Reference

ESP32-S3-N16R8 Dev Board

Spec	Value
MCU	ESP32-S3-N16R8 (16MB Flash, 8MB PSRAM)
Form Factor	44-pin dev board with USB-C
Power	5V USB-C or 3.3V/5V pin
Onboard	WS2812 NeoPixel RGB LED (GPIO 48)

4-Channel Relay Module (External)

Spec	Value
Channels	4 channels, 10A @ 250VAC per channel
Trigger	Active HIGH (set via jumper)
Input	3.3V/5V logic compatible

Relay channel assignments:

- CH1 (GPIO 4): Furnace dry contact closure
- CH2 (GPIO 5): Compressor -- switches 12VDC to SSR-25DA DC+ trigger
- CH3 (GPIO 6): Fan Low -- switches 120VAC directly
- CH4 (GPIO 15): Fan High -- switches 120VAC directly

SSR-25DA Solid State Relay

Spec	Value
Model	Twtade SSR-25DA
Output	24-380VAC, 25A
Input	3-32VDC (triggered with 12VDC from RV battery)
Heatsink	Required (~15W dissipation at 12A load)

Terminal assignments:

- DC+ (pin 3): 12VDC from relay module CH2 NO output
- DC- (pin 4): 12VDC GND (RV battery negative)
- AC1 (pin 1): 120VAC LINE (hot) input
- AC2 (pin 2): Output to freeze stat -> 6-pin Blue wire

Why not trigger the SSR directly from 3.3V GPIO? The SSR-25DA needs ~5mA minimum to trigger reliably. At 3.3V through its internal resistor and LED, only ~1.5mA is available. Using the relay module CH2 to switch 12VDC provides ~15mA -- well above the minimum threshold.

Supco SFPC Freeze Protection Control

ESP32-S3-N16R8 + 4-Channel Relay - SSR-25DA Wiring Instructions

Spec	Value
Model	Supco SFPC
Type	Clamp-on, snaps onto suction line (up to 7/8" OD)
Contacts	SPST NC, opens at 35F, closes at 50F
Rating	10A @ 120V, 5A @ 240V
Install	On suction line just outside evaporator coil

Alternative: Honeywell FPC (opens at 38F, closes at 48F). Either device works. The Supco SFPC has a wider differential (15F) which reduces nuisance trips.

4. Wiring Reference

6-Pin Cable (AC Unit Side)

This cable runs from the junction box up to the Dometic Brisk II rooftop unit. All load wires carry 120VAC when their respective relay/SSR is ON.

Pin	Color	Function	Connection
1	Blue	Compressor	SSR AC2 -> freeze stat -> Blue
2	Black	Fan High	CH4 (GPIO 15) NO -> Black
3	Yellow	Rev Valve	Not connected (no heat pump)
4	Red	Fan Low	CH3 (GPIO 6) NO -> Red
5	White	Neutral	Pass-through to AC unit
6	Grn/Ylw	Chassis Gnd	Pass-through to AC unit

Relay Module Connections

Channel	GPIO	Switches	Connection
CH1	GPIO 4	Dry contact	Furnace call (no voltage)
CH2	GPIO 5	12VDC	SSR DC+ trigger (from RV battery)
CH3	GPIO 6	120VAC	Fan Low (direct to Red)
CH4	GPIO 15	120VAC	Fan High (direct to Black)

CH2 (Compressor) is NOT on the 120VAC bus. Its COM connects to RV +12VDC, and its NO connects to SSR DC+. The SSR handles 120VAC switching. CH1 (Furnace) is a dry contact. Only CH3 and CH4 carry 120VAC.

5. Wiring Procedure

DISCONNECT SHORE POWER before all wiring. Verify with a non-contact voltage tester. All 120VAC connections must be inside a junction box.

Step 1: Remove the Etratech Control Box

- Disconnect shore power and verify no voltage is present.
- Disconnect the 6-pin cable from the control box output side.
- Disconnect 120VAC LINE and NEUTRAL from the control box input side.
- Disconnect furnace wires from the control box FURNACE terminals.
- Disconnect freeze sensor wires from J4 (no longer used by control box).
- Remove the Etratech control box entirely.

Step 2: Mount and Wire the SSR-25DA

- Mount the SSR-25DA on a metal heatsink (aluminum, at least 4"x4"). Use thermal paste between SSR and heatsink. Mount heatsink inside or adjacent to the junction box with adequate airflow.
- AC1 (pin 1): Connect with 14 AWG wire to 120VAC LINE (hot). Use a Wago 221-412 or wire nut to branch LINE to both the SSR AC1 and the CH3/CH4 COM bus.
- AC2 (pin 2): Connect with 14 AWG wire to the Supco SFPC freeze stat input terminal. The freeze stat output connects to the 6-pin Blue wire.
- DC+ (pin 3): Connect with 18-22 AWG wire to relay module CH2 NO screw terminal.
- DC- (pin 4): Connect with 18-22 AWG wire to RV 12VDC GND (battery negative / chassis ground).

Step 3: Wire 120VAC Bus to CH3/CH4 COM

- Create a 120VAC LINE bus to CH3 COM and CH4 COM screw terminals. Use 14 AWG wire and Wago connectors or wire nuts to branch from the same LINE wire feeding SSR AC1.
- CH3 NO (GPIO 6) -> 14 AWG -> 6-pin Red wire (Fan Low)
- CH4 NO (GPIO 15) -> 14 AWG -> 6-pin Black wire (Fan High)

Step 4: Wire 12VDC to CH2 COM

- Connect RV +12VDC (house battery / converter) to CH2 COM screw terminal. Use 18-22 AWG wire. This is the SSR trigger source.
- CH2 NO connects to SSR DC+ (already done in Step 2).
- When GPIO 5 goes HIGH, CH2 closes, 12VDC reaches SSR DC+, and the SSR turns on 120VAC to the compressor.

Step 5: Wire Neutral and Ground Pass-Through

- Route NEUTRAL (white) directly through the junction box to the 6-pin White wire. Not switched by any relay.
- Route GROUND (green/yellow) directly through to the 6-pin Green/Yellow wire. Connect ground to the junction box and any metal enclosures.

- Cap the Yellow wire (Pin 3, reversing valve) with a wire nut.

Step 6: Wire Furnace (CH1)

- Connect furnace call wires to CH1 COM and NO screw terminals. This is a dry contact closure -- no 120VAC, no 12VDC on these terminals.

Step 7: Install Supco SFPC Freeze Stat

- Snap the Supco SFPC clamp onto the suction line just outside the evaporator coil. No thermal paste needed -- the clamp provides direct contact with the copper tubing.
- Wire in series: SSR AC2 output -> freeze stat -> 6-pin Blue wire. Use 14 AWG wire and appropriate connectors.
- Verify NC (closed) at room temperature with a continuity test.

Step 8: Install DS18B20 Freeze Sensor

- Mount the waterproof DS18B20 probe on the evaporator coil in contact with copper tubing or aluminum fins. Use thermal paste and secure with cable tie or aluminum tape.
- Wire to ESP32-S3-N16R8 dev board: Red to 3.3V pin, Black to GND, Yellow/White data to GPIO 42.
- Solder a 4.7K ohm pull-up resistor between GPIO 42 and 3.3V, as close to the dev board as practical.
- Route sensor cable away from 120VAC wires to avoid noise.

6. I2C Sensor and Display Wiring

The BME280 temperature/humidity/pressure sensor and SSD1306 OLED display are mounted at the thermostat location (former Dometic stat position) and connected to the ESP32-S3-N16R8 via a 3-meter I2C cable run.

ESP32-S3-N16R8 Pin Connections

Signal	GPIO	Dev Board Pin	Wire Color
SDA	GPIO 41	GPIO 41	Green
SCL	GPIO 40	GPIO 40	Blue
3.3V	--	3V3	Red
GND	--	GND	Black

I2C Devices (Shared Bus)

Device	Address	Function
BME280	0x76	Temperature, humidity, pressure
SSD1306 OLED	0x3C	128x64 pixel display

Both devices share the same I2C bus (SDA + SCL). Use 18 AWG 4-conductor thermostat wire for the 3-meter cable run. I2C bus speed: 400 kHz (can reduce to 100 kHz if cable causes issues). WARNING: OLED and BME280 VCC = 3.3V ONLY (not 5V or 12V!).

7. Freeze Protection Details

Software Layer (DS18B20)

Condition	Action
Evap temp < 32F	Cut compressor (GPIO 5 LOW)
Evap temp >= 45F	Allow compressor to resume
DS18B20 not found	Software freeze protection disabled
Check interval	Every 5 seconds

Hardware Layer (Supco SFPC)

Condition	Action
Suction line < 35F	Switch opens, compressor circuit broken
Suction line > 50F	Switch closes, circuit restored
No power needed	Passive NC switch, always active

The two layers are independent. The DS18B20 software layer acts first (32F threshold). The Supco SFPC hardware layer is backup (35F threshold). Even with a total ESP32 failure, the SFPC physically breaks the compressor circuit if the suction line reaches 35F.

8. Failsafe Behavior

The system is fail-safe: any single point of failure results in HVAC OFF. The relay module and SSR-25DA are normally open, so power loss to the ESP32 disconnects all loads.

Condition	Result
ESP32 power loss	All relays open -> SSR off -> all loads OFF
ESP32 software crash	boot.py sets GPIOs LOW on reboot -> all OFF
Shore power loss	No 120VAC available -> all loads OFF
12VDC battery loss	SSR DC+ has no trigger -> compressor OFF
DS18B20 reads < 32F	Software cuts compressor, recovery at 45F
SFPC trips (< 35F)	Hardware breaks compressor circuit
SSR failure (open)	Compressor stays OFF (safe direction)
Relay welded shut	Only that one fan load stays on
120VAC bus fault	Breaker trips -> all loads OFF

There is NO backup thermostat. If the ESP32 loses power or crashes, all HVAC stops until the ESP32 recovers. The system is fail-safe (everything OFF) but not fail-operational.

9. ESP32-S3-N16R8 GPIO Reference

IP: 192.168.71.153 | 44-pin dev board | 5V USB-C

GPIO	Function	Channel/Device	Load
4	Furnace	CH1 NO/COM	Dry contact closure
5	Compressor	CH2 -> SSR	12VDC trigger -> SSR 120VAC
6	Fan Low	CH3 NO	120VAC -> Pin 4 Red
7	Fan High	CH4 NO	120VAC -> Pin 2 Black
41	I2C SDA	Dev board	BME280 + OLED
40	I2C SCL	Dev board	BME280 + OLED
15	Freeze Sensor	Dev board	1-Wire DS18B20, 4.7K pull-up
2	Reset Button	Dev board	Momentary NO to GND, pull-up
48	RGB LED	Onboard	WS2812 NeoPixel status indicator

Power Architecture

- Control side: RV 12VDC battery system (always available with battery). Powers ESP32 (via 5V regulator) and SSR trigger via CH2.
- Load side: 120VAC shore power through SSR and relay contacts. Completely isolated from control side via relay contacts.
- boot.py sets CH1-CH4 GPIOs (4, 5, 6, 7) LOW (OFF) on startup.
- Reset button: GPIO 2, momentary NO to GND with internal pull-up. Press triggers machine.reset() (hard reboot). IRQ-based with 500ms debounce -- responds instantly regardless of main loop state.

10. Pre-Installation Checklist

Tools Required

- Digital multimeter with continuity and AC voltage modes
- Non-contact voltage tester (NCVT)
- Wire strippers rated for 14 AWG and 18-22 AWG
- Crimping tool for ring/spade terminals (if used)
- Small screwdriver for relay module screw terminals and SSR terminals
- Soldering iron (for DS18B20 pull-up resistor)
- Heat shrink tubing and heat gun
- Cable ties and/or aluminum tape (for sensor mounting)

Materials

- ESP32-S3-N16R8 dev board + 4-channel relay module
- Twtade SSR-25DA solid state relay
- Aluminum heatsink for SSR (at least 4"x4")
- Thermal paste (for SSR-to-heatsink and DS18B20 mounting)
- Supco SFPC freeze protection control (clamp-on)
- DS18B20 waterproof temperature sensor (stainless steel probe)
- 4.7K ohm resistor (1/4W, for DS18B20 pull-up)
- BME280 sensor breakout board
- SSD1306 OLED display (128x64, I2C)
- 18 AWG 4-conductor thermostat wire (~3 meters for I2C run)
- 14 AWG stranded copper wire (THHN or equivalent), 3-4 feet
- 18-22 AWG wire for 12VDC SSR trigger connections
- Wire nuts (14 AWG rated) or Wago 221-412/415 connectors
- Junction box (metal or PVC, sized for conductor count)
- Cable clamps / strain reliefs for junction box knockouts

Verification Checklist

- ☐ Shore power DISCONNECTED and verified with NCVT
- ☐ Etratech control box fully removed from circuit
- ☐ SSR-25DA mounted on heatsink with thermal paste
- ☐ SSR AC1 (pin 1) connected to 120VAC LINE (14 AWG)
- ☐ SSR AC2 (pin 2) -> Supco SFPC -> 6-pin Blue (compressor)
- ☐ SSR DC+ (pin 3) connected to relay module CH2 NO terminal
- ☐ SSR DC- (pin 4) connected to RV 12VDC GND
- ☐ CH2 COM connected to RV +12VDC (NOT 120VAC)
- ☐ 120VAC LINE bus connected to CH3/CH4 COM only (14 AWG)

- [] CH3 NO (GPIO 6) -> 6-pin Red (fan low)
- [] CH4 NO (GPIO 15) -> 6-pin Black (fan high)
- [] CH1 (GPIO 4) wired as dry contact for furnace ONLY
- [] CH1 NOT connected to 120VAC or 12VDC bus
- [] Neutral (White) passes through directly -- NOT switched
- [] Ground (Green/Yellow) passes through directly -- NOT switched
- [] Yellow wire (reversing valve) capped with wire nut
- [] Supco SFPC clamped on suction line near evaporator
- [] Supco SFPC verified NC (closed) at room temperature
- [] DS18B20 wired to GPIO 42 with 4.7K pull-up to 3.3V
- [] DS18B20 probe mounted on evaporator coil with thermal paste
- [] I2C cable: SDA=GPIO 41, SCL=GPIO 40, 3.3V, GND
- [] BME280 and OLED responding on I2C bus
- [] All 120VAC connections inside junction box
- [] All wire nuts / Wago connectors tight and secure
- [] Junction box closed and cable clamps installed
- [] Shore power reconnected
- [] ESP32 boot verified: all relays OFF on startup
- [] Each relay tested individually from web UI
- [] SSR trigger verified: GPIO 5 HIGH -> compressor runs
- [] DS18B20 reading verified in web UI (reasonable temperature)
- [] Freeze protection tested: sensor below 32F -> compressor cuts
- [] Reset button (GPIO 2) wired: momentary NO between GPIO 2 and GND
- [] Reset button tested: press triggers hard reboot, board comes back online

Generated for RV Thermostat Project - ESP32 MicroPython