THE DRUIDS DEN

GUEST GUIDE

Projector setup

Settle in for movie night at the Den.

1 Plug in and position the projector

Remove the power strip from the bottom of the cart and plug it into the wall **beneath the bookshelf**. Switch the strip to **ON**. Place the projector on the cart's **top shelf** and remove the lens cap; it should pop off with minimal pressure.

2 Connect the cords

Take the connecting cords out of the wicker box. Match the cord ends as follows:

YELLOW TAG	BLUE TAG	UNMARKED
Projector	DVD player or your device	Power strip

3 Power on and adjust the picture

Turn on the projector and DVD player using the buttons on the devices. Once the projector starts, adjust the picture using the **focus and keystone controls** on top of the projector, just behind the lens.

4 Select HDMI

Press **Source** on top of the projector, use the **arrow keys** to select **HDMI**, then press **OK** to display your connected device. The Source button is at the **top left** of the button group, opposite the power button.

5 Use the remotes and enjoy

The remote controls are in the **wicker box**. Use them to navigate the DVD menu or adjust the projector volume. Enjoy!

WHEN YOU ARE FINISHED

Please return **all cords, devices, the lens cap, and the cart** to their original positions once you are no longer using the projector.