

NAD Electronics

C356 RS232 Command List

Notes

- Send a Carriage Return <CR> before and after each command
- In addition to using the <=> operator, each [Prefix].[Variable] can be incremented, decremented, or queried by using <+>, <->, or <?> operators.

Main.Model	Operators: ?
-------------------	--------------

N/A

Description: Query Model

Example: <CR>Main.Model?<CR>

Main.Mute	Operators: =/+/-/?
------------------	--------------------

Possible Values:

Off

On

Description: Set Main Mute On/Off

Example: <CR>Main.Mute=0ff<CR>

Main.Power	Operators: =/+/-/?
-------------------	--------------------

Possible Values:

On

Off

Description: Set Main Power On/Off

Example: <CR>Main.Power=0n<CR>

Main.Source	Operators: =/+/-/?
--------------------	--------------------

Possible Values:

CD

Tuner

Video

Disc

Ipod

Tape2

Aux

Description: Set Source

Example: <CR>Main.Source=CD<CR>

Main.SpeakerA	Operators: =/+/-/?
----------------------	--------------------

Possible Values:

Off

On

Description: Set Main Speaker A On/Off

Example: <CR>Main.SpeakerA=0ff<CR>

Main.SpeakerB

Operators: =/+/-/?

Possible Values:

Off
On

Description: Set Main Speaker B On/Off

Example: <CR>Main.SpeakerB=Off<CR>

Main.Tape1

Operators: =/+/-/?

Possible Values:

On
Off

Description: Set Tape1 On/Off

Example: <CR>Main.Tape1=On<CR>

Main.Volume

Operators: +/-

N/A

Description: Increment / Decrement Volume (No Discrete Values due to motorized volume control)

Example: <CR>Main.Volume+<CR>