NAD Electronics

C389/C399 Command List (RS232 and Ethernet)

Notes
- Send a Carriage Return <CR> before and after each command
- In addition to using the <=> operator, each [Prefix].[Variable] can be incremented, decremented, or queried by using <+>, <->, or <?> operators.

DiracX.Name

Operators: ?

N/A

Description: Query Dirac filter name.
1<= X <= 5

Example: `<CR>DiracX.Name?<CR>`

DiracX.State

Operators: ?

N/A

Description: Query Dirac filter state. This can be used to determine whether a filter can be selected using Main.Dirac command.
1<= X <= 5

Example: `<CR>DiracX.State?<CR>`

Main.AutoStandby

Operators: =/+/-/?

Possible Values:

- On
- Off

Description: Enable/Disabled Auto standby. After 20 minutes of inactivity the player will go to standby automatically.

Example: `<CR>Main.AutoStandby=On<CR>`

Main.Balance

Operators: =/+/-/?

Possible Values:

- -7.0R
- 0
- -7.0L

Description: Range -7R -6R .. 0 .. -6L -7L. Set audio balance. -7R means right channel is attenuated by 7 db compared to left channel, which leads to a balance on the left.

Example: `<CR>Main.Balance=-7.0R<CR>`

Main.Bass

Operators: =/+/-/?

Possible Values:

- Range -7 - 7

Description: Set bass

Example: `<CR>Main.Bass=-7<CR>`

Main.Brightness

Operators: =/+/-/?

Possible Values:

2
3
1

Description: Set LCD brightness
Example: <CR>Main.Brightness=2<CR>

Main.BT.Name

Operators: =/+/-/?

Possible Values:

String

Description: Set the Bluetooth device name
Example: <CR>Main.BT.Name=String<CR>

Main.CEC.Power

Operators: =/+/-/?

Possible Values:

On
Off

Description: Allow HDMI CEC to change the player power state. When Off, CEC power off is ignored.
Example: <CR>Main.CEC.Power=On<CR>

Main.ControlStandby

Operators: =/+/-/?

Possible Values:

Off
On

Description: Allow compatible MDC2 cards to be left powered on.
Example: <CR>Main.ControlStandby=Off<CR>

Main.CrossOver

Operators: =/+/-/?

Possible Values:

Range 40 - 200 Step 10

Description: Set the crossover frequency (in Hz) between main and subwoofer output. This feature is only available when a compatible MDC2 card is present (i.e. MDC2 BluOS-D).
Example: <CR>Main.CrossOver=40<CR>

Main.Dirac

Operators: =/+/-/?

Possible Values:

Range 0 - 5

Description: Set the selected Dirac filter. 0 means no filter selected. If a filter is Enabled (see DiracX.State), it can be selected by issuing a Main.Dirac=X command, where X is a number between 1 and 5.
Example: <CR>Main.Dirac=0<CR>

Main.Display

Operators: =/+/-/?

Possible Values:

Temp

On

Description: A value of On will always keep the display on. if Temp is selected, the LCD display (and backlight) will be turned off along with the front panel LED. As soon as the player is interacted with, both will turn on temporarily.

Example: `<CR>Main.Display=Temp<CR>`

Main.IR.Channel

Operators: =/+/-/?

Possible Values:

Range 0 - 7

Description: Select IR channel used. Allow multiple devices to be controlled separately.

Example: `<CR>Main.IR.Channel=0<CR>`

Main.Model

Operators: ?

N/A

Description: Return the current unit model

Example: `<CR>Main.Model?<CR>`

Main.ModelName

Operators: ?

N/A

Description: Return the current unit friendly name

Example: `<CR>Main.ModelName?<CR>`

Main.Mute

Operators: =/+/-/?

Possible Values:

On

Off

Description: Mute/unmute the audio output.

Example: `<CR>Main.Mute=On<CR>`

Main.Power

Operators: =/+/-/?

Possible Values:

On

Off

Description: Power on/off the unit

Example: `<CR>Main.Power=On<CR>`

Main.Source

Operators: =/+/-/?

Possible Values:

Range 1 - 10

Description: Select audio source. The value range is from 1 to X where X is the value returned by Main.Sources?

Example: <CR>Main.Source=1<CR>

Main.Sources

Operators: ?

N/A

Description: Returns the total number of sources available on the unit.

Example: <CR>Main.Sources?<CR>

Main.Speaker

Operators: =/+/-/?

Possible Values:

On

Off

Description: Turn on/off speaker output

Example: <CR>Main.Speaker=On<CR>

Main.Subwoofer

Operators: =/+/-/?

Possible Values:

Range 0 - 2

Description: Select the number of subwoofers connected. This feature is only available when a compatible MDC2 card is present (i.e. MDC2 BluOS-D)

Example: <CR>Main.Subwoofer=0<CR>

Main.ToneDefeat

Operators: =/+/-/?

Possible Values:

On

Off

Description: Turn tone controls on/off. If On is selected, Main.Bass and Main.Treble won't have any effect.

Example: <CR>Main.ToneDefeat=On<CR>

Main.Treble

Operators: =/+/-/?

Possible Values:

Range -7 - 7

Description: Set treble

Example: <CR>Main.Treble=-7<CR>

Main.Version

Operators: ?

N/A

Description: Query firmware version

Example: <CR>Main.Version?<CR>

Main.Volume

Operators: =/+/-/?

Possible Values:

Range -80 - 12

Description: Volume unit is dB. The minimum and maximum depends on the volume limits (Main.VolumeLimits?)

Example: `<CR>Main.Volume=-80<CR>`

Main.VolumeDisplayMode

Operators: =/+/-/?

Possible Values:

Decibel

Percent

Description: Show volume display on front panel in dB/Percent

Example: `<CR>Main.VolumeDisplayMode=Decibel<CR>`

Main.VolumeLimits

Operators: =/+/-/?

Possible Values:

String

Description: The maximum and minimum values that Main.Volume can reach. Example: Main.VolumeLimits=X,Y where
X <= Y-30
X >= -80
Y <= +12

Example: `<CR>Main.VolumeLimits=String<CR>`

Main.VolumePercent

Operators: =/+/-/?

Possible Values:

Range 0 - 100

Description: Volume of the unit in percent.

Example: `<CR>Main.VolumePercent=0<CR>`

SourceX.AnalogBypass

Operators: =/+/-/?

Possible Values:

Off

On

Description: Enable/disable analog bypass for the analog source. This only applies to analog sources.
1 <= X <= Main.Sources?

Example: `<CR>SourceX.AnalogBypass=Off<CR>`

SourceX.AnalogGain

Operators: =/+/-/?

Possible Values:

Range -12 - 5

Description: Apply a gain offset at the input of an analog source. This only applies to analog sources.
1 <= X <= Main.Sources?

Example: `<CR>SourceX.AnalogGain=-12<CR>`

SourceX.AutoSense

Operators: =/+/-/?

Possible Values:

On

Off

Description: When it is On, the source will wake up when an active signal is detected on that specific source. It will switch to the source automatically and start playback. This does not apply to Phono Source.
1 <= X <= Main.Sources?

Example: `<CR>SourceX.AutoSense=On<CR>`

SourceX.Enabled

Operators: =/+/-/?

Possible Values:

Yes

No

Description: Enable/disable the source. Example: Source5.Enabled
1 <= X <= Main.Sources?

Example: `<CR>SourceX.Enabled=Yes<CR>`

SourceX.Input

Operators: ?

N/A

Description: Default source name. This can be used to identify the source after SourceX.Name had changed. Example: Source5.Input
1 <= X <= Main.Sources?

Example: `<CR>SourceX.Input?<CR>`

SourceX.Name

Operators: =/?

Possible Values:

<VALUE>

Description: Name of the source as displayed on the front panel LCD.
1 <= X <= Main.Sources?

Example: `<CR>SourceX.Name=<VALUE><CR>`

SourceX.Slot

Operators: ?

N/A

Description: Represent the MDC slot number the source is associated with. 0 means internal source. 1 is MDC slot 1. Example: Source5.Slot
1 <= X <= Main.Sources?

Example: `<CR>SourceX.Slot?<CR>`

SourceX.VolumeControl

Operators: =/+/-/?

Possible Values:

Variable

Fixed

Description: Set a variable/fixed volume control on the source. When Fixed is selected, the volume used for this source will be taken from SourceX.VolumeFixed. When Variable is selected the volume used for this source is from Main.Volume
1 <= X <= Main.Sources?

Example: `<CR>SourceX.VolumeControl=Variable<CR>`

SourceX.VolumeFixed

Operators: =/+/-/?

Possible Values:

Range -80 - 12

Description: Source volume when SourceX.VolumeControl=Fixed is selected.
1 <= X <= Main.Sources?

Example: `<CR>SourceX.VolumeFixed=-80<CR>`