6809 FORTH — MEMORY MAP

64K ADDRESS SPACE · SUBROUTINE-THREADED · 16-BIT CELL

block heights are log-scaled for legibility — not linear with actual byte size
high addresses at top, low addresses at bottom — standard memory-map orientation
BASECODE end differs by serial build: polled (SERIALPOLL=1, default) / interrupt-driven (SERIALPOLL=0)

$FFFF

VECTORS hardware vectors — **$FFF0–$FFFF**

INITCODE — **$FFA4–$FFEB**
COLDSTRT / WARM entry (4 pad bytes to VECTORS)

BASECODE — **$DCC4–$FE60 polled** / **$DCC4–$FF9F interrupt**
ROM primitives + system words

BASEDICT — **$D4B3–$DCC3**
ROM dictionary headers

(unused) — **$C100–$D4B2**
spare ROM — INOUT shadow to BASEDICT

INOUT — **$C000–$C0FF**
I/O block — ACIA regs at INOUT+8

RSTACK — **$BD00–$BFFF**
return stack (S) — grows down

DSTACK — **$B900–$BCFF**
data stack (U) — grows down

$8000

APPCODE — **$7000–$B8FF**
application code (CODEHERE)
Transient (floating, 128 B above CODEHERE)

$4000

APPDICT — **$2000–$6FFF**
application dictionary (DPHERE)

$1000

APPVARS — **$021B–$1FFF**
mutable var space (VARHERE)

(unclaimed) not used for any purpose — **$0200–$021A**

OUTBUF — **$01C0–$01FF**
output ring buffer (interrupt build)

INBUF — **$0180–$01BF**
input ring buffer (interrupt build)

SERBUFCTL serial indices + error counters — **$0176–$017F**

(unclaimed) not used for any purpose — **$0156–$0175**

TIBBUF — **$0106–$0155**
terminal input buffer (80 bytes)

MVSCRATCH — **$0100–$0105**

GLOBALS — **$0000–$00FF**
shared system globals — Direct Page (255 of 256 used)

$0000

◄ Direct Page (DP)
set to $00 at reset

REGION KEY

- ROM (fixed)
- RAM — grows up
- RAM — grows up (vars)
- Stack — grows down
- Fixed buffer
- I/O / device / serial
- RAM — fixed
- Unused / spare