# 6809 FORTH — MEMORY MAP

64K ADDRESS SPACE · SUBROUTINE-THREADED · 16-BIT CELL

*block heights are log-scaled for legibility — not linear with actual byte size*
high addresses at top, low addresses at bottom — standard memory-map orientation
BASECODE end differs by serial build: polled (SERIALPOLL=1, default) / interrupt-driven (SERIALPOLL=0)

$FFFF

**VECTORS** hardware vectors — **$FFF0–$FFFF**

**INITCODE** — **$FFA4–$FFEB**
COLDSTRT / WARM entry (4 pad bytes to VECTORS)

**BASECODE** — **$DCC4–$FDE5 polled** / **$DCC4–$FF24 interrupt**
ROM primitives + system words

**BASEDICT** — **$D4B3–$DCC3**
ROM dictionary headers

**(unused)** — **$C100–$D4B2**
spare ROM — INOUT shadow to BASEDICT

**INOUT** — **$C000–$C0FF**
I/O block — ACIA regs at INOUT+8

**RSTACK** — **$BD00–$BFFF**
return stack (S) — grows down

**DSTACK** — **$B900–$BCFF**
data stack (U) — grows down

$8000

**APPCODE** — **$7000–$B8FF**
application code (CODEHERE)
Transient (floating, 128 B above CODEHERE)

$4000

**APPDICT** — **$2000–$6FFF**
application dictionary (DPHERE)

$1000

**APPVARS** — **$021B–$1FFF**
mutable var space (VARHERE)

**(unclaimed)** not used for any purpose — **$0200–$021A**

**OUTBUF** — **$01C0–$01FF**
output ring buffer (interrupt build)

**INBUF** — **$0180–$01BF**
input ring buffer (interrupt build)

**SERBUFCTL** serial indices + error counters — **$0176–$017F**

**(unclaimed)** not used for any purpose — **$0156–$0175**

**TIBBUF** — **$0106–$0155**
terminal input buffer (80 bytes)

**MVSCRATCH** — **$0100–$0105**

**GLOBALS** — **$0000–$00FF**
shared system globals — Direct Page (255 of 256 used)

$0000

◄ Direct Page (DP)
set to $00 at reset

REGION KEY

- ROM (fixed)
- RAM — grows up
- RAM — grows up (vars)
- Stack — grows down
- Fixed buffer
- I/O / device / serial
- RAM — fixed
- Unused / spare