

Use #22 Hook-up Wire for Windings Numbers on coil are connection points to the FAR Circuits PC board