

Machine B - Hydraulic Press
Model H500 Operator and Maintenance Manual

1. Introduction

This manual covers safe operation, routine maintenance, and troubleshooting procedures for the Machine B H500 hydraulic press.

2. Hydraulic System Overview

The H500 relies on a sealed hydraulic circuit to generate press force. Pressure is continuously monitored by the onboard controller. A drop in system pressure will trigger a fault condition and halt the press cycle.

3. Error Code Reference

E101 - Hydraulic Pressure Low

Meaning: The hydraulic system pressure has dropped below the minimum operating threshold required for a safe press cycle.

Causes:

- Hydraulic fluid leak
- Worn pump seals
- Low hydraulic fluid reservoir level

Corrective Actions:

- Stop the press cycle immediately
- Check the hydraulic fluid reservoir level and top up if low
- Inspect hoses and fittings for visible leaks
- Contact maintenance if the pump seals are suspected to be worn

Warnings:

- Relieve system pressure fully before opening any hydraulic line.

E310 - Pump Overcurrent

Meaning: The hydraulic pump motor drew current above the rated limit.

Causes:

- Pump obstruction
- Failing pump motor

Corrective Actions:

- Stop the machine and isolate power
- Inspect the pump for obstructions
- Contact a qualified technician if the fault recurs

4. Filter Replacement

Replace the hydraulic return-line filter every 500 operating hours or immediately if the filter clog indicator activates.