

Applications & connector guide

Toyota 122 Superseal connects selected vehicle-harness circuits to a 60-pin and a 26-pin Superseal connector. This guide uses Aristo signal descriptions and separate GS300 compatibility notes.

Vehicle applications

Vehicle / engine	Application
Toyota Aristo JZS161 2JZ-GTE VVT-i	Intended vehicle family. Check the harness version: FCUT applies from July 2000 onward in the reference. Vehicle pin B1 is not listed for Aristo, although the adapter connects it as ground.
Lexus GS300 S160 2JZ-GE — 1998 reference	Related application requiring wiring verification. Pin functions differ from Aristo; it is not confirmed as a plug-and-play fit. The GS300 notes identify the differences.

A fully tested model-year range is not established. Matching the 122-pin connector alone does not establish electrical compatibility.

Pinouts & references

[Vehicle pinout with connector pictures](#) | [Superseal pinout with connector pictures](#)

[Aristo wiring / pin-function reference — wilbo666](#) | [1998 GS300 wiring PDF](#)

The published pinouts contain both Aristo functions and Lexus-derived additions. The descriptions in this guide remain Aristo-specific; Lexus-only functions appear in the GS300 notes.

Superseal numbering: 60/1A, 60/1B and 26/1D use the published pin labels, prefixed by connector size (60 or 26 pins). Vehicle contacts retain A1, B1, etc.

Reading the tables

Tables are grouped by vehicle sections A–E. The description column is for Aristo; “GS300:” notes refer only to the cited 1998 2JZ-GE diagram. “—” means no additional GS300 note, not proof of compatibility. Amber marks a documented difference in function; a missing wire alone is not highlighted.

Ignition trigger signals connect to the external igniter. The adapter provides no ignition driver.

Unconnected vehicle contacts with a known function are listed separately on page 5. Free Superseal contacts are also listed there.

Connected pins — section A

Only contacts connected through the adapter are shown here. Unconnected vehicle contacts are listed on page 5.

Vehicle section A — engine / ignition

Vehicle	Superseal	Aristo description	GS300 compatibility note
A1	26/1D	Cylinder 3 Injector	—
A2	26/2D	Cylinder 4 Injector	—
A3	26/5D	Cylinder 5 Injector	—
A4	26/6D	Cylinder 6 Injector	—
A5	26/4D	Intake air bypass VSV	GS300: ACIS valve.
A6	26/11D	Oil level switch	—
A7	26/7D	ETCS-i Motor (-)	—
A8	26/13D	ETCS-i Motor (+)	—
A9	26/12D	ETCS-i ground	—
A10	26/14D	Camshaft sensor	—
A11	26/8D	Ignition Trigger; cylinders 1 & 6	—
A12	26/9D	Ignition Trigger; cylinders 5 & 2	—
A13	26/3D	Ignition Trigger; cylinders 3 & 4	—
A15	26/10D	Wastegate control VSV	GS300: no wire shown in reference.
A17	26/19D	VVTi Solenoid (-)	—
A18	26/26D	VVTi Solenoid (+)	—
A19	26/25D	ETCS-i Clutch (-)	—
A20	26/18D	ETCS-i Clutch (+)	—
A21	26/24D	ECU Ground	—
A22	60/15B	Crankshaft & Intake Camshaft Position Sensor Ground	—
A23	60/21B	Crankshaft sensor (+)	—
A25	26/20D	Igniter feedback	—
A26	26/21D	Alternator status signal	—
A27	26/15D	Knock Sensor (Rear)	—
A28	26/22D	Knock Sensor (Front)	—
A29	26/16D	A/C compressor lock signal	—
A30	26/17D	ETCS-i motor shield	—
A31	26/23D	ECU Ground	—

Connected pins — sections B & C

Descriptions refer to Aristo. Notes refer to the cited 1998 GS300 wiring diagram.

Vehicle section B — sensors / engine

Vehicle	Superseal	Aristo description	GS300 compatibility note
B1	60/6B	Not listed in Aristo reference	GS300: E03 ground. Adapter connects this pin as ground.
B2	60/7B	Sensor Power	—
B3	60/24B	Exhaust gas control VSV	GS300: HT2A, O2 sensor heater; not a turbo VSV.
B5	60/26B	Cylinder 1 Injector	—
B6	60/25B	Cylinder 2 Injector	—
B8	60/14B	Oil pressure switch	—
B9	60/13B	MAP sensor signal	GS300: no wire shown in reference.
B10	60/12B	Engine Airflow	—
B14	60/19B	Water Temperature Sensor	—
B15	60/18B	Accelerator Pedal Position Sensor	—
B16	60/17B	Accelerator Sensor (Demand Position Sensor)	—
B17	60/5B	ECU Ground	—
B18	60/4B	Sensor Ground	—
B19	60/11B	Airflow Meter Ground	—
B22	60/23B	Air Temperature Sensor	—
B23	60/16B	Throttle Position Sensor	—
B24	60/22B	Throttle Position Sensor (Actual)	—

Vehicle section C — transmission / auxiliary

Vehicle	Superseal	Aristo description	GS300 compatibility note
C5	60/2B	Speed Sensor (+)	—
C11	60/9B	Speed Sensor (-)	—
C12	60/3B	Exhaust bypass VSV	GS300: no wire shown in reference.
C16	60/10B	Fuel pressure VSV	GS300: no wire shown in reference.

Connected pins — sections D & E

Descriptions refer to Aristo. Notes refer to the cited 1998 GS300 wiring diagram.

Vehicle section D — vehicle / body systems

Vehicle	Superseal	Aristo description	GS300 compatibility note
D2	60/32A	Starter Signal	—
D3	60/23A	Fuel monitoring; Jul 2000 onward only (source tentative)	GS300: no wire shown in reference.
D6	60/31A	Stop light switch	—
D10	60/22A	Ambient temperature signal	GS300: TAM, A/C system; detailed function not shown.
D11	60/30A	Brake / cruise signal	GS300: cruise-control system connection.
D12	60/24A	AC Pressure Switch 2	GS300: no wire shown in reference.
D13	60/33A	A/C relay control	—
D18	60/34A	Radiator coolant sensor (+)	GS300: PTNK, fuel-vapour pressure; not coolant temperature.
D20	60/17A	Tachometer	GS300: no wire shown in reference.
D21	60/9A	AC Pressure Switch 1	—
D22	60/25A	Radiator coolant sensor (-)	GS300: no wire shown in reference.
D23	60/8A	Cruise Control Switch	—
D25	60/20B	Fan control REC	GS300: no wire shown in reference.
D27	60/1B	MPX2 multiplex link	—
D28	60/8B	MPX1 multiplex link	—

Vehicle section E — power / vehicle interfaces

Vehicle	Superseal	Aristo description	GS300 compatibility note
E1	60/1A	Battery power	—
E4	60/11A	Fuel pump ECU status	—
E5	60/3A	Fuel pump ECU control (0–5 V PWM in reference)	GS300: fuel pump ECU signal; waveform not specified.
E6	60/6A	Check engine light	—
E7	60/5A	ETCS-i power	—
E8	60/18A	EFI relay switched power	—
E9	60/12A	Ignition Switch	—
E10	60/4A	EFI main relay control (positive-side)	—
E11	60/13A	Diagnostic line SIL	—
E13	60/14A	TRC+ serial data	—
E14	60/27A	ENG+ serial data	—
E15	60/15A	Engine speed signal NEO	—
E16	60/26A	EFI relay switched power	—
E18	60/29A	Fan control REC2	GS300: no wire shown in reference.
E20	60/16A	TRC- serial data	—
E21	60/28A	ENG- serial data	—
E22	60/7A	PRE and PRE2 Switches Ground	—

Unconnected & free contacts

These vehicle contacts have a function in the project pinout or a cited reference, but no connection to Superseal through this adapter. Descriptions remain Aristo-specific; Lexus-only functions are in the last column.

Vehicle	Aristo description	GS300 compatibility note
A14	Not listed in Aristo reference	GS300: L, shift-lock ECU signal.
A16	Not listed in Aristo reference	GS300: PS, power-steering oil-pressure switch.
B4	O2 sensor heater	GS300: HT1A, O2 heater.
B7	EVAP purge VSV	—
B11	Not listed in Aristo reference	GS300: OX2A, oxygen sensor signal.
B12	O2 sensor signal	GS300: OX1A.
B13	A/T neutral indication	GS300: N, snow-mode switch. Different application.
B20	A/T 2nd-gear indication	GS300: terminal label 3.
B21	A/T 1st-gear indication	GS300: terminal label 2.
C1	A/T shift solenoid 1	—
C2	A/T shift solenoid 2	—
C3	A/T shift solenoid SD	GS300: terminal label S3.
C4	A/T clutch speed sensor (+)	—
C6	A/T shift solenoid S4	—
C7	A/T lock-up solenoid (+)	—
C8	A/T accumulator pressure (+)	—
C9	A/T line-pressure solenoid (+)	—
C10	A/T clutch speed sensor (-)	—
C13	A/T lock-up solenoid (-)	—
C14	A/T accumulator pressure (-)	—
C15	A/T line-pressure solenoid (-)	—
C17	A/T fluid-temperature sensor	—
D4	A/T upshift request	GS300: no wire shown in reference.
D5	Diagnostic test connector	—
D7	A/T manual-mode indication	GS300: terminal 4, shift-lock / A/T signal.
D8	Not listed in Aristo reference	GS300: OX1B, oxygen sensor signal.
D14	A/T downshift request	GS300: no wire shown in reference.
D16	A/T reverse indication	—
D17	A/T drive indication	—
D26	A/T park indication	—

Other unconnected vehicle contacts: A24, D1, D9, D15, D19, D24, E2, E3, E12, E17, E19. No function is listed for these contacts in either cited reference.

Free Superseal contacts: 60/2A, 60/10A, 60/19A, 60/20A, 60/21A. All 60-pin section B contacts (1B–26B) and all 26-pin contacts (1D–26D) are connected.

Coverage: 81 connected vehicle contacts; 30 unconnected contacts with reference descriptions; 11 unconnected contacts without a listed function. All 122 vehicle and 86 Superseal positions are accounted for.