A1 PO2SHTC
A2 IGP2
A3 IGP1
A4 PG2
A5 PG1
A6 PHO2S+
A7 CKP
A8 IMRC VPS
A9 KS
A10 SG2
A11 SG1
A12 IACV

A15 TPS
A16 PHO2S−

A18 VSS
A19 MAP
A20 VCC2
A21 VCC1
A22 PO2SHTC+
A23 LG2
A24 LG1
A25 CMP
A26 TDC
A27 IGPLS4
A28 IGPLS3
A29 IGPLS2
A30 IGPLS1

J3A
TE 1318612-1 Honda K

A1	OUT_O2_HEATER_B1S1
A2	12V_FROM_MAIN_RELAY
A3	12V_FROM_MAIN_RELAY
A4	GND
A5	GND
A6	IN_AF_POS
A7	IN_CRANK
A8	IN_INTAKE_RUNNER_POSITION
A9	IN_KNOCK
A10	GNDA
A11	GNDA
A12	OUT_IDLE
A13	OEM_A13
A14	OEM_A14
A15	IN_TPS1
A16	IN_AF_NEG
A17	OEM_A17
A18	IN_VSS
A19	IN_MAP
A20	+5V
A21	+5V
A22	IN_O2_HEATER_POWER
A23	GNDA
A24	GNDA
A25	IN_CAM1
A26	IN_CAM2
A27	OUT_IGN4
A28	OUT_IGN3
A29	OUT_IGN2
A30	OUT_IGN1
A31	OEM_A31

B1 VTC+
B2 INJ4
B3 INJ3
B4 INJ2
B5 INJ1
B6 FANC
B7 RVS
B8 ECT
B9 VTPSW
B10 ALTL

B13 ALTF
B14 LSA+
B15 VTS
B16 LSB+
B17 IAT
B18 ALTC

B21 PCS
B22 IMRC
B23 VTC−
B24 LSC+

J3B
TE 1318612-1 Honda K

B1	VTC_SUPPLY
B2	OUT_INJ4
B3	OUT_INJ3
B4	OUT_INJ2
B5	OUT_INJ1
B6	OUT_FAN_RELAY
B7	OUT_REVERSE_LOCKOUT
B8	IN_CLT
B9	IN_VTEC_PRESSURE_SWITCH
B10	IN_ALTERNATOR_LAMP
B11	OEM_B11
B12	OEM_B12
B13	IN_ALTERNATOR_FIELD
B14	OEM_B14
B15	OUT_VTEC
B16	OEM_B16
B17	IN_IAT
B18	OUT_ALTERNATOR
B19	OEM_B19
B20	OEM_B20
B21	OUT_EVAP_PURGE
B22	OUT_INTAKE_RUNNER
B23	OUT_VVT1
B24	OEM_B24

J3C
TE 1318612-1 Honda K

C1	OEM_C1
C2	+12V_LOAD_FROM_ECU
C3	LSU_UN
C4	LSU_RCAL
C5	LSU_IP
C6	LSU_VM
C7	OUT_LSU_HEATER_HIGH
C8	IN_AUX3
C9	IN_AUX2
C10	IN_AUX1
C11	OUT_AUX3
C12	OUT_AUX2
C13	OUT_AUX1
C14	CAN_L
C15	CAN_H
C16	OUT_ETB_NEG
C17	OUT_ETB_POS
C18	IN_AUX_DIGITAL3
C19	IN_AUX_DIGITAL2
C20	GND
C21	IN_AUX_DIGITAL1
C22	+5V

D2 S−MODE
D3 S−UP
D4 ATPN
D5 ATPR
D6 ATPP

D9 S−DN
D10 ATPD

D12 CCS

J3D
TE 1318612-1 Honda K

D1	OEM_D1
D2	OEM_D2
D3	OEM_D3
D4	OEM_D4
D5	OEM_D5
D6	OEM_D6
D7	OEM_D7
D8	OEM_D8
D9	OEM_D9
D10	OEM_D10
D11	OEM_D11
D12	OEM_D12
D13	OEM_D13
D14	OEM_D14
D15	OEM_D15
D16	OEM_D16
D17	OEM_D17

E1 IMO FPR
E2 SHO2S
E3 LG3
E4 SG3
E5 VCC3
E6 SO2SHTC
E7 MRLY
E8 PO2SHTCR
E9 IG1

E13 ILU
E14 FTP
E15 ELD
E16 PSPSW

E18 ACC

E20 2WBS
E21 VSV
E22 BKSW
E23 K−LINE
E24 SEFMJ
E25 VSSOUT
E26 NEP
E27 IMOCD

E29 SCS
E30 WEN
E31 MIL

J3E
TE 1318612-1 Honda K

E1	OUT_FUEL_PUMP_RELAY
E2	IN_O2_B1S2
E3	GND
E4	GNDA_E4
E5	+5V
E6	OUT_O2_HEATER_B1S2
E7	OUT_MAIN_RELAY
E8	OUT_AF_SENSOR_RELAY
E9	IN_VIGN
E10	OUT_FUEL_RELAY_ALT
E11	OEM_E11
E12	OEM_E12
E13	OEM_E13
E14	IN_FUEL_TANK_PRESSURE
E15	IN_ELECTRICAL_LOAD
E16	IN_POWER_STEERING_SWITCH
E17	OEM_E17
E18	OUT_AC_RELAY
E19	OEM_E19
E20	OUT_EVAP_BYPASS
E21	OUT_EVAP_VENT
E22	IN_BRAKE_SWITCH
E23	K_LINE
E24	MULTIPLEX_SEFMJ
E25	OEM_E25
E26	OUT_TACH
E27	IMMOBILIZER_DATA
E28	OEM_E28
E29	SERVICE_CHECK
E30	OUT_IMMOBILIZER_LAMP
E31	OUT_CHECK_ENGINE

J1A
Superseal 60 A/B

OUT_EVAP_VENT	1A
IMMOBILIZER_DATA	2A
OUT_O2_HEATER_B1S2	3A
OUT_CHECK_ENGINE	4A
GND	5A
IN_O2_B1S2	6A
IN_BRAKE_SWITCH	7A
OUT_INJ4	8A
OUT_INJ3	9A
OUT_MAIN_RELAY	10A
IN_POWER_STEERING_SWITCH	11A
IN_ELECTRICAL_LOAD	12A
GNDA_E4	13A
MULTIPLEX_SEFMJ	14A
OUT_FUEL_RELAY_ALT	15A
IN_ALTERNATOR_LAMP	16A
IN_AUX_DIGITAL1	17A
OUT_AC_RELAY	18A
IN_VIGN	19A
OUT_TACH	20A
IN_FUEL_TANK_PRESSURE	21A
OEM_E12	22A
K_LINE	23A
OEM_B11	24A
IN_AUX_DIGITAL3	25A
OUT_AF_SENSOR_RELAY	26A
OUT_EVAP_BYPASS	27A
SERVICE_CHECK	28A
OUT_IMMOBILIZER_LAMP	29A
OEM_D4	30A
OEM_D12	31A
OUT_FUEL_PUMP_RELAY	32A
OEM_C1	33A
IN_AUX_DIGITAL2	34A

J1B
Superseal 60 A/B

OUT_ETB_NEG	1B
OUT_LSU_HEATER_HIGH	2B
OUT_AUX3	3B
OUT_VVT1	4B
OUT_EVAP_PURGE	5B
OUT_INJ2	6B
OUT_REVERSE_LOCKOUT	7B
CAN_L	8B
IN_AUX1	9B
LSU_VM	10B
LSU_RCAL	11B
IN_ALTERNATOR_FIELD	12B
OUT_FAN_RELAY	13B
CAN_H	14B
IN_AUX2	15B
IN_AUX3	16B
LSU_IP	17B
LSU_UN	18B
+5V	19B
OUT_ETB_POS	20B
OUT_AUX1	21B
OUT_AUX2	22B
+12V_LOAD_FROM_ECU	23B
OUT_INTAKE_RUNNER	24B
OUT_VTEC	25B
OUT_INJ1	26B

J2
Superseal 26 C

OEM_A31	1C
IN_VTEC_PRESSURE_SWITCH	2C
IN_VSS	3C
OUT_IGN4	4C
GND	5C
OUT_IDLE	6C
OUT_O2_HEATER_B1S1	7C
IN_INTAKE_RUNNER_POSITION	8C
IN_KNOCK	9C
IN_CRANK	10C
IN_AF_POS	11C
IN_TPS1	12C
GNDA	13C
OUT_IGN1	14C
IN_MAP	15C
IN_CLT	16C
IN_AF_NEG	17C
IN_CAM2	18C
IN_CAM1	19C
OUT_ALTERNATOR	20C
OUT_IGN2	21C
OUT_IGN3	22C
IN_IAT	23C
GND	24C
IN_O2_HEATER_POWER	25C
12V_FROM_MAIN_RELAY	26C

JP1
VTC supply B1
VTC_SUPPLY — +12V_LOAD_FROM_ECU

OEM_A13 — PA13
OEM_A14 — PA14
OEM_A17 — PA17
OEM_B12 — PB12
OEM_B14 — PB14
OEM_B16 — PB16
OEM_B19 — PB19
OEM_B20 — PB20
OEM_B24 — PB24
OEM_D1 — PD1

OEM_D2 — PD2
OEM_D3 — PD3
OEM_D5 — PD5
OEM_D6 — PD6
OEM_D7 — PD7
OEM_D8 — PD8
OEM_D9 — PD9
OEM_D10 — PD10
OEM_D11 — PD11
OEM_D13 — PD13

OEM_D14 — PD14
OEM_D15 — PD15
OEM_D16 — PD16
OEM_D17 — PD17
OEM_E11 — PE11
OEM_E13 — PE13
OEM_E17 — PE17
OEM_E19 — PE19
OEM_E25 — PE25
OEM_E28 — PE28

GND
GNDA
+5V

rusEFI
Sheet: /
File: honda-k-125-superseal.kicad_sch
Title: Honda K 125 to Superseal 60+26
Size: A2 | Date: 2026-10-19 | **Rev: a**
KiCad E.D.A. 10.0.6 | Id: 1/1