VEHICLE / 1 – 22 PINS

1A BATT
1B MAIN12V
1C SPARE
1D K–LINE
1E MIL
1F BRAKE
1G PSP
1H BATT2
1I FAN2
1J SPARE
1K AT 1
1L TEN
1M SPARE
1N AT 2
1O ALT FLD
1P AC REQ
1Q CHG LMP
1R FAN1
1S AC REL
1T ALT FB
1U O2H1
1V NEUTRAL

J3A

1A	1	IN_CONSTANT_POWER
1B	12	12V_FROM_MAIN_RELAY
1C	2	OEM_1C
1D	13	K_LINE
1E	3	OUT_CHECK_ENGINE
1F	14	IN_BRAKE
1G	4	IN_PSP
1H	15	IN_BACKUP_POWER
1I	5	OUT_FAN2
1J	16	OEM_1J
1K	6	OEM_1K
1L	17	IN_DIAG_TEN
1M	7	OEM_1M
1N	18	OEM_1N
1O	8	OUT_ALT_FIELD
1P	19	IN_AC_REQUEST
1Q	9	OUT_CHARGE_LAMP
1R	20	OUT_FAN1
1S	10	OUT_AC_RELAY
1T	21	IN_ALT_FEEDBACK
1U	11	OUT_O2H1
1V	22	IN_NEUTRAL

VEHICLE / 2 – 16 PINS

2A FTP
2B IAT
2C O2 1
2D VSS
2E CLT
2F KNOCK
2G SPARE
2H CAM
2I 5V
2J CRANK
2K TACH
2L MAF
2M EGR M
2N EGR N
2O EGR O
2P EGR P

J3B

2A	23	IN_FTP
2B	31	IN_IAT
2C	24	IN_O2_1
2D	32	IN_VSS
2E	25	IN_CLT
2F	33	IN_KNOCK
2G	26	OEM_2G
2H	34	IN_CAM
2I	27	+5VAS
2J	35	IN_CRANK
2K	28	OUT_TACH
2L	36	IN_MAF
2M	29	OUT_EGR_M
2N	37	OUT_EGR_N
2O	30	OUT_EGR_O
2P	38	OUT_EGR_P

VEHICLE / 3 – 26 PINS

3A GND
3B GND
3C GND
3D SPARE
3E TPS
3F GNDA
3G IGN1
3H IGN2
3I CLUTCH
3J O2 2
3K FUEL LV
3L EVAP
3M IAC12V
3N PUMP
3O IAC
3P SPARE
3Q VICS
3R SPARE
3S EGR PR
3T EGR SOL
3U CDCV
3V O2H2
3W INJ1
3X INJ2
3Y INJ3
3Z INJ4

J3C

3A	39	GND
3B	52	GND
3C	40	GND
3D	53	OEM_3D
3E	41	IN_TPS1
3F	54	GNDA
3G	42	OUT_IGN1
3H	55	OUT_IGN2
3I	43	IN_CLUTCH
3J	56	IN_O2_2
3K	44	IN_FUEL_LEVEL
3L	57	OUT_EVAP
3M	45	IAC_SUPPLY
3N	58	OUT_FUEL_PUMP
3O	46	OUT_IDLE
3P	59	OEM_3P
3Q	47	OUT_VICS
3R	60	OEM_3R
3S	48	IN_EGR_PRESS
3T	61	OUT_EGR_SOL
3U	49	OUT_CDCV
3V	62	OUT_O2H2
3W	50	OUT_INJ1
3X	63	OUT_INJ2
3Y	51	OUT_INJ3
3Z	64	OUT_INJ4

OPTIONAL / 4 – 12 PINS

4A GND
4B FLEX
4C AUX
4D BOOST
4E VVT
4F 5V
4G WBO COM
4H WBO VS
4I WBO R
4J WBO IP
4K WBO H–
4L WBO H+

J3D

4A	65	GND
4B	71	IN_FLEX
4C	66	IN_AUX
4D	72	OUT_BOOST
4E	67	OUT_VVT
4F	73	+5VAS
4G	68	WBO_VS_IP
4H	74	WBO_VS
4I	69	WBO_TRIM
4J	75	WBO_IP
4K	70	OUT_WBO_HEATER
4L	76	WBO_HEATER_SUPPLY

SUPERSEAL 60 / A

J1A

1A	1	K_LINE
2A	2	IN_PSP
3A	3	OEM_1K
4A	4	OUT_ALT_FIELD
5A	5	IN_ALT_FEEDBACK
6A	6	IN_AUX
7A	7	WBO_VS
8A	8	IN_FTP
9A	9	IN_CLT
10A	10	IN_BRAKE
11A	11	OUT_FAN2
12A	12	OEM_1M
13A	13	OUT_CHARGE_LAMP
14A	14	IN_NEUTRAL
15A	15	OUT_VVT
16A	16	WBO_IP
17A	17	IN_O2_1
18A	18	OUT_CHECK_ENGINE
19A	19	IN_DIAG_TEN
20A	20	IN_AC_REQUEST
21A	21	OUT_AC_RELAY
22A	22	IN_FLEX
23A	23	WBO_VS_IP
24A	24	OUT_WBO_HEATER
25A	25	IN_VSS
26A	26	OEM_1C
27A	27	OEM_1J
28A	28	OEM_1N
29A	29	OUT_FAN1
30A	30	OUT_O2H1
31A	31	OUT_BOOST
32A	32	WBO_TRIM
33A	33	IN_IAT
34A	34	IN_KNOCK

SUPERSEAL 60 / B

J1B

1B	35	OEM_2G
2B	36	IN_MAF
3B	37	OUT_EGR_P
4B	38	OUT_IGN2
5B	39	OUT_EVAP
6B	40	OUT_VICS
7B	41	OUT_CDCV
8B	42	IN_CRANK
9B	43	OUT_EGR_N
10B	44	IN_TPS1
11B	45	IN_O2_2
12B	46	OUT_IDLE
13B	47	IN_EGR_PRESS
14B	48	OUT_TACH
15B	49	OUT_EGR_O
16B	50	OUT_IGN1
17B	51	IN_FUEL_LEVEL
18B	52	OEM_3P
19B	53	OUT_EGR_SOL
20B	54	IN_CAM
21B	55	OUT_EGR_M
22B	56	OEM_3D
23B	57	IN_CLUTCH
24B	58	OUT_FUEL_PUMP
25B	59	OEM_3R
26B	60	OUT_O2H2

SUPERSEAL 26 / C

J2

1C	1	12V_FROM_MAIN_RELAY
2C	2	12V_FROM_MAIN_RELAY
3C	3	IN_CONSTANT_POWER
4C	4	IN_BACKUP_POWER
5C	5	GNDA
6C	6	+5VAS
7C	7	SPARE_7C
8C	8	OUT_INJ1
9C	9	OUT_INJ3
10C	10	SPARE_10C
11C	11	SPARE_11C
12C	12	SPARE_12C
13C	13	SPARE_13C
14C	14	OUT_INJ2
15C	15	OUT_INJ4
16C	16	SPARE_16C
17C	17	SPARE_17C
18C	18	SPARE_18C
19C	19	SPARE_19C
20C	20	+12V_LOAD_FROM_ECU
21C	21	+12V_LOAD_FROM_ECU
22C	22	SPARE_22C
23C	23	SPARE_23C
24C	24	GND
25C	25	GND
26C	26	GND

LOAD SUPPLY

JP1
+12V_LOAD_FROM_ECU — WBO_HEATER_SUPPLY

JP2
+12V_LOAD_FROM_ECU — IAC_SUPPLY

SPARE SUPERSEAL CONTACTS

TP1 SPARE_22C
TP2 SPARE_10C
TP3 SPARE_16C
TP4 SPARE_23C
TP5 SPARE_11C
TP6 SPARE_17C
TP7 SPARE_12C
TP8 SPARE_18C
TP9 SPARE_13C
TP10 SPARE_19C
TP11 SPARE_7C

POWER NETS

GND
GNDA
+5VAS
IN_BACKUP_POWER
IN_CONSTANT_POWER
12V_FROM_MAIN_RELAY
+12V_LOAD_FROM_ECU

rusEFI

Sheet: /
File: miata–NB1–superseal.kicad_sch

Title: Mazda Miata NB1 1999–2000 – Superseal 60+26

Size: A3	Date: 2026–10–10	**Rev: a**
KiCad E.D.A. 10.0.6		Id: 1/1