VEHICLE / 1 – 22 PINS

J3A

1A	FAN1	1	OUT_FAN1
1B	FAN2	12	OUT_FAN2
1C	CHARGE	2	IN_CHARGE
1D	K–LINE	13	K_LINE
1E	MIL	3	OUT_CHECK_ENGINE
1F	SPARE	14	OEM_1F
1G	AC REL	4	OUT_AC_RELAY
1H	LIGHT	15	IN_HEADLIGHT
1I	TEN	5	IN_DIAG_TEN
1J	DEFOG	16	IN_DEFOG
1K	AC REQ	6	IN_AC_REQUEST
1L	CLUTCH	17	IN_CLUTCH
1M	VSS	7	IN_VSS
1N	SPARE	18	OEM_1N
1O	GND	8	GND
1P	AC IN	19	OEM_1P
1Q	BRAKE	9	IN_BRAKE
1R	AT 1	20	OEM_1R
1S	SPARE	10	OEM_1S
1T	AT 2	21	OEM_1T
1U	PUMP	11	OUT_FUEL_PUMP
1V	SPARE	22	OEM_1V

VEHICLE / 3 – 16 PINS

J3B

3A	SPARE	23	OEM_3A
3B	MAF	31	IN_MAF
3C	O2H1	24	OUT_O2H1
3D	O2H2	32	OUT_O2H2
3E	SPARE	25	OEM_3E
3F	TPS	33	IN_TPS1
3G	CLT	26	IN_CLT
3H	EGR PR	34	IN_EGR_PRESS
3I	5V	27	+5VAS
3J	EGR POS	35	IN_EGR_POS
3K	IAT	28	IN_IAT
3L	TPS IDL	36	IN_TPS_IDLE
3M	O2 1	29	IN_O2_1
3N	KEY	37	IN_VIGN
3O	GNDA	30	GNDA
3P	PSP	38	IN_PSP

VEHICLE / 4 – 26 PINS

J3C

4A	GND	39	GND
4B	MAIN12V	52	12V_FROM_MAIN_RELAY
4C	GND	40	GND
4D	GND	53	GND
4E	CKP A	41	IN_CRANK_VR_A
4F	CAS1	54	IN_CAS1
4G	CAS2	42	IN_CAS2
4H	CKP B	55	IN_CRANK_VR_B
4I	BATT	43	IN_CONSTANT_POWER
4J	PRC	56	OUT_PRC
4K	SPARE	44	OEM_4K
4L	TACH	57	OUT_TACH
4M	SPARE	45	OEM_4M
4N	IGN1	58	OUT_IGN1
4O	EGR VNT	46	OUT_EGR_VENT
4P	EGR VAC	59	OUT_EGR_VAC
4Q	IAC	47	OUT_IDLE
4R	IGN2	60	OUT_IGN2
4S	SPARE	48	OEM_4S
4T	EVAP	61	OUT_EVAP
4U	INJ1	49	OUT_INJ1
4V	INJ2	62	OUT_INJ2
4W	INJ3	50	OUT_INJ3
4X	INJ4	63	OUT_INJ4
4Y	AT 3	51	OEM_4Y
4Z	O2 2	64	IN_O2_2

OPTIONAL / 2 – 12 PINS

J3D

2A	GND	65	GND
2B	FLEX	71	IN_FLEX
2C	AUX	66	IN_AUX
2D	BOOST	72	OUT_BOOST
2E	VVT	67	OUT_VVT
2F	5V	73	+5VAS
2G	WBO COM	68	WBO_VS_IP
2H	WBO VS	74	WBO_VS
2I	WBO R	69	WBO_TRIM
2J	WBO IP	75	WBO_IP
2K	WBO H–	70	OUT_WBO_HEATER
2L	WBO H+	76	WBO_HEATER_SUPPLY

SUPERSEAL 60 / A

J1A

1A		1	OUT_FAN1
2A		2	OEM_1F
3A		3	IN_DEFOG
4A		4	OEM_1N
5A		5	IN_BRAKE
6A		6	OEM_1V
7A		7	OUT_VVT
8A		8	WBO_IP
9A		9	OUT_O2H1
10A		10	K_LINE
11A		11	IN_HEADLIGHT
12A		12	IN_CLUTCH
13A		13	OEM_1P
14A		14	OEM_1T
15A		15	IN_AUX
16A		16	WBO_VS
17A		17	OEM_3A
18A		18	IN_CHARGE
19A		19	OUT_AC_RELAY
20A		20	IN_AC_REQUEST
21A		21	OEM_1R
22A		22	OUT_FUEL_PUMP
23A		23	OUT_BOOST
24A		24	WBO_TRIM
25A		25	IN_MAF
26A		26	OUT_FAN2
27A		27	OUT_CHECK_ENGINE
28A		28	IN_DIAG_TEN
29A		29	IN_VSS
30A		30	OEM_1S
31A		31	IN_FLEX
32A		32	WBO_VS_IP
33A		33	OUT_WBO_HEATER
34A		34	OUT_O2H2

SUPERSEAL 60 / B

J1B

1B		35	OEM_3E
2B		36	IN_EGR_POS
3B		37	IN_PSP
4B		38	IN_CRANK_VR_B
5B		39	OEM_4M
6B		40	OUT_IDLE
7B		41	OUT_INJ1
8B		42	IN_CLT
9B		43	IN_TPS_IDLE
10B		44	IN_CAS1
11B		45	OEM_4K
12B		46	OUT_EGR_VENT
13B		47	OEM_4S
14B		48	IN_EGR_PRESS
15B		49	IN_O2_1
16B		50	IN_CAS2
17B		51	OUT_TACH
18B		52	OUT_EGR_VAC
19B		53	OUT_EVAP
20B		54	IN_TPS1
21B		55	IN_IAT
22B		56	IN_CRANK_VR_A
23B		57	OUT_PRC
24B		58	OUT_IGN1
25B		59	OUT_IGN2
26B		60	OUT_INJ2

SUPERSEAL 26 / C

J2

1C		1	12V_FROM_MAIN_RELAY
2C		2	12V_FROM_MAIN_RELAY
3C		3	IN_CONSTANT_POWER
4C		4	IN_VIGN
5C		5	GNDA
6C		6	+5VAS
7C		7	SPARE_7C
8C		8	OUT_INJ3
9C		9	OEM_4Y
10C		10	SPARE_10C
11C		11	SPARE_11C
12C		12	SPARE_12C
13C		13	SPARE_13C
14C		14	OUT_INJ4
15C		15	IN_O2_2
16C		16	SPARE_16C
17C		17	SPARE_17C
18C		18	SPARE_18C
19C		19	SPARE_19C
20C		20	+12V_LOAD_FROM_ECU
21C		21	+12V_LOAD_FROM_ECU
22C		22	SPARE_22C
23C		23	SPARE_23C
24C		24	GND
25C		25	GND
26C		26	GND

OPTIONAL WIDEBAND SUPPLY

JP1

+12V_LOAD_FROM_ECU — WBO_HEATER_SUPPLY

SPARE SUPERSEAL CONTACTS

TP1	SPARE_22C
TP2	SPARE_10C
TP3	SPARE_16C
TP4	SPARE_23C
TP5	SPARE_11C
TP6	SPARE_17C
TP7	SPARE_12C
TP8	SPARE_18C
TP9	SPARE_13C
TP10	SPARE_19C
TP11	SPARE_7C

POWER NETS

GND, GNDA, +5VAS, IN_VIGN, IN_CONSTANT_POWER, 12V_FROM_MAIN_RELAY, +12V_LOAD_FROM_ECU

rusEFI

Sheet: /
File: miata-NA8-superseal.kicad_sch

Title: Mazda Miata NA8 1996–1997 – Superseal 60+26

Size: A3	Date: 2026-10-10	**Rev: a**
KiCad E.D.A. 10.0.6		Id: 1/1