BEATPODS LUXE

USER MANUAL

GOAT DIGITAL

COMPANY PROFILE

GOAT Digital is a dynamic and fast-emerging brand committed to delivering high-quality, premium mobile accessories at aggressive and reasonable prices. Launched in January 2025 and headquartered in Nagpur, Maharashtra, our mission is simple: to bridge the gap between cutting-edge tech and affordability.
We specialize in a wide range of mobile accessories including:
TWS (True Wireless Stereo) Earbuds, Neckbands, Power Banks, Fast Chargers, Data & Charging Cable, And a growing line of innovative mobile gadgets.

To become India's most trusted and value-driven brand in the mobile accessories space by delivering products that combine style, performance, and durability — without the premium price tag.

We offer premium build quality, ensuring our products stand out in durability and design. Our smart, fast-charging solutions are engineered for efficiency and convenience, while our audio devices deliver superior sound experiences. With an aggressive pricing strategy, we make top-tier technology accessible to everyone. Every product undergoes rigorous quality control to maintain high standards. As a proudly Indian brand, we are committed to excellence and innovation.

INSIDE THE BOX

- 1 N Pair of TWS Earbuds
- 1N Charging Case
- 1N Type-C Charging Cable

PRODUCT LAYOUT



HOW TO PAIR

Step 1: Make sure your charging case is charged up. Open the lid of the charging case and take out both the earbuds. The earbuds will turn ON automatically and enter into pairing mode.

Step 2: Tap **“BeatPods Luxe”** from the smartphone’s Bluetooth menu. There is a ring prompt after a succesful connection. This indicates earbuds are successfully connected to your device.

Step 3: Congratulations! You are now connected and can start playing media.

TOUCH CONTROLS

Function	Left Earbud	Right Earbud	Touch Control
Volume Increase		●	Single Tap on the right earbud’s touch sensor
Volume Decrease	●		Single Tap on the left earbud’s touch sensor
Play/Plause	●●	●●	Double Tap on any earbud’s touch sensor
Next Track		●●●	Triple Tap on the right earbud’s touch sensor
Previous Track	●●●		Triple Tap on the left earbud’s touch sensor
Voice Assistant	—		Long Press for 2 seconds on the left earbud’s touch sensor
Game Mode		—	Long Press for 2 seconds on the right earbud’s touch sensor

CALL CONTROLS

Function	Left Earbud	Right Earbud	Touch Control
Answer Incoming Call	●●	●●	Double Tap on any earbud’s touch sensor
Hang Up Call	●●	●●	While on call, Double Tap on any earbud’s touch sensor
Reject Call	—	—	Long Press for 2 seconds on any earbud’s touch sensor

CHARGING THE CASE

Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can damage the battery of the case and earbuds.

Charging the Case: While charging the case, the case LED light will start blinking

Fully Charged: When fully charged, the charging case LED light will glow static until the charger is removed.

CHARGING THE EARBUDS

Earbuds Low Battery: - Earbuds will play a jingle, when the buds are low on power.

Charging the Earbuds: Place the earbuds inside the charging case and close the case lid, the earbuds will start charging automatically and the case LED light will glow static.

Earbuds Completely Charged: When the earbuds are completely charged, the LED Light on the charging case will turn off.

TECHNICAL SPECIFICATIONS

Parameter	Value	Parameter	Value
Bluetooth Version	5.3	Case Charging Time	1.5 Hours
Effective Distance	15m	Earbuds Charging Time	1 Hour
Impedance	32 Ω	Talktime	upto 45 Hours
Product Weight	38g	Frequency	20Hz~20KHz
Speaker Size	13mm	IP Rating	IPX5
Total Playtime	upto 35 Hours	Charging Port	Type-C
Standby Time	upto 300 Hours	Rated Input	5V/1A

SAFETY & MAINTENANCE

Please read the below suggestions to help prolong the product lifespan and clearly understand the warranty clauses:
Please keep the product dry, do not put it in humid conditions to avoid a short circuit.

Do not expose it to the peak sun or high heat for extended periods, as this will shorten the lifespan of electronic components, damage the battery and deform some plastic parts.

Please do not put it in cold circumstances to avoid damage to the PCB board.

Please do not attempt to dismantle the product, as it may be unsafe, especially for non-professionals.

Do not use chemical products, detergents, or oily liquids to clean the item.

Do not scratch the surface with sharp items to avoid damaging the case and appearance.

Do not charge the product for more than 5 hours to avoid loss in battery life.

Avoid hearing music at maximum volume for long periods as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not a manufacturing defect will render the warranty null and void. Therefore, please take utmost care of your product.