Pilot Assembly Replacement Checklist

Majestic DVR36 (36" rear-vent, installed 2000) • Vermont Castings SIT Pilot Assembly LP, SRV10002265 • Date: _____

Gas smell at any point: leave the house, call the propane supplier or 911 from outside, touch no switches. Your unit's manual and labels override this sheet.

0. Verify before you start

- [ ] Rating plate says **LP (propane)** — the part is LP only
- [ ] Gas valve brand: □ SIT □ Honeywell (Honeywell: compare old and new pilot closely before disassembly; SRV10002265 is the SIT 3-way for pilots with thermocouple + thermopile)
- [ ] Part number on old pilot / valve: _____
- [ ] Kit contents present: pilot hood with tubing, thermocouple, thermopile, igniter electrode and wire
- [ ] New pilot matches old: tube length, bracket holes, fitting sizes
- [ ] Tools: 3/8" & 7/16" wrenches, small adjustable wrench, nut drivers, screwdrivers, multimeter (mV DC), shop vac with soft brush, flashlight, gloves, leak solution, camera, fresh batteries

1. Shut down

- [ ] Gas supply valve OFF
- [ ] Unit cooled at least 1 hour; control knob OFF
- [ ] Room ventilated; no flames or sparks nearby

2. Access

- [ ] Photograph the firebox, logs, wiring and tubing before touching anything
- [ ] Remove glass door assembly; store it safely
- [ ] Remove logs and embers (mark positions)
- [ ] Remove burner / panels as needed to reach pilot and valve
- [ ] Photograph pilot tube, thermocouple, thermopile and igniter wire runs

3. Remove old assembly

- [ ] Disconnect pilot gas tube at valve (two wrenches; don't twist the tubing)
- [ ] Disconnect thermocouple at valve
- [ ] Disconnect thermopile leads
- [ ] Disconnect igniter wire
- [ ] Remove pilot bracket screws/nut and slide out the assembly
- [ ] Compare old vs. new side by side

4. Install new assembly

- [ ] Mount bracket in the same position and orientation as the old one
- [ ] Route pilot tube with gentle curves — no kinks or sharp bends
- [ ] Connect pilot gas tube: hand-tight, then snug with wrench
- [ ] Connect thermocouple: finger-tight plus about 1/4 turn (check SIT sheet in the kit)
- [ ] Connect thermopile leads
- [ ] Connect igniter wire; keep it clear of hot surfaces
- [ ] Compare all wiring with your photos

5. Maintenance while it's open

- [ ] Vacuum burner compartment, valve area and pilot hood
- [ ] Clean burner ports; check logs for soot or damage
- [ ] Inspect door gasket for cracks, gaps or hardening (direct-vent seal)
- [ ] Clean glass inside and out (cold, non-abrasive cleaner)
- [ ] Inspect valve, flex line and fittings for corrosion
- [ ] Look for rust or moisture inside the firebox
- [ ] Check remote / wall switch and replace batteries
- [ ] Outside: check vent termination for nests or debris; vent connections tight and sealed

6. Leak test (no flame)

- [ ] Open gas supply
- [ ] Soap/leak solution on pilot tube fitting, valve inlet and every connection touched
- [ ] No growing bubbles. If any: gas off, tighten, retest

7. Light and verify

- [ ] Follow the lighting instructions on the unit's label (PILOT, press and hold, ignite)
- [ ] Hold knob about 1 minute after the pilot lights; release; pilot stays lit
- [ ] Pilot flame steady, blue, enveloping thermocouple tip
- [ ] Main burner lights; flame height and color normal
- [ ] Re-check fittings for leaks with flame on
- [ ] Replace logs per photos, then glass door (all latches secure)
- [ ] Run 15–20 minutes; re-check for leaks and verify pilot stays lit

Optional mV readings (typical SIT values; confirm in your manual)	**Measured**
Thermopile open circuit (typically ~350–750 mV)	
Thermocouple open circuit (typically ~20–30 mV)	

8. If the pilot still drops out

- [ ] Thermocouple connection loose or over-tightened; tip not in flame
- [ ] Pilot tube kinked or orifice blocked
- [ ] Vent blockage or door seal leak causing drafts
- [ ] Valve failing or wrong gas pressure: call a licensed technician

Parts info: stove-parts-unlimited.com (SRV10002265 listing). Not manufacturer documentation.