# QUICK REFERENCE HANDOOK .DOC format

Including Aircraft GVI (G650), GVI (G650ER)

Revision 5a March 15th, 2015 GAC DOC. No. GVI-0

2014 Gulfstream Aerospace Corporation

#### DISCLAIMER FOR MAINTENANCE / OPERATIONAL / PLACARDING PROCEDURES MANUAL (GAC DOC. No. GVI-0)

The technical information presented herein has been determined to be correct at time of publication. However, should a direct conflict exist between this and other official publications, e.g., Master Minimum Equipment List (MMEL), Airplane Flight Manuals (AFM), Maintenance Manuals, those publications take precedence.

#### COPYRIGHT 2014 GULFSTREAM AEROSPACE CORPORATION

All rights reserved, including the right to reproduce this publication. No part may be reproduced, stored in any retrieval system, or transmitted in any part or form or by any means, electronic, photocopying, microfilm, microfiche, mechanical, or otherwise, without prior written permission of Gulfstream Aerospace Corporation.

#### TABLE OF CONTENTS

		<u>PAGE</u>	
FRONT	MAT'	TER F-1	
		Table of Contents F-1	
		General Information F-12	
		Revision Log F-15	
		Minimum Navigation Equipment Table	F-17
		En Route Navigation RequirementsF-19	
		Future Air Navigation System (FANS) Requirement	F-20
ATA 21	AI	R CONDITIONING 21-1	
	1.	Cabin Altitude Indicator (Overhead Panel)	21-1
		Cabin Differential Pressure Indicator21-2	
		Cabin Rate of Climb Indicator 21-3	
		Automatic Pressurization Control Systems	21-3
		Manual Pressurization Control System	21-4
	6.	Semi-Auto Pressurization Control System	21-4
	7.	Cabin Altitude Pressure Warning System	21-5
	8.	Pressurization Thrust Outflow Valve Position Indicator	21-5
	9.	Cockpit Zone Temperature Control System & Cabin Zone Temperature Control	
	10.		21-7
	11.	Duct Temperature Indicators (Overhead Panel)	21-7
		Environmental Control System (ECS) Packs	21-8
	13.		21-8
		Thrust Outflow Valve System (TROV)	21-9
		Pressure Relief Valve 21-10	01 11
		Cabin Pressure Indicator and Control Panel	21-11
		Semi Mode CPCS (SMC) 21-12	21 12
		Remote Filter (Pressure Relief Valve PRV)	21-12
		CPAM (Cabin Pressure Acquisition Module)	21-12
	20.	J contract the second contract to the second	
	21.	PSU Fan 21-13	

ATA 22	AUT	O FLIGHT	22-1	
	2. 3. 4. 5. 6. 7.	Autothrottle Systems Performance Management Systems Control Wheel Autopilot Disconne Autothrottle Disconnect Buttons (c Autothrottle Engage/Disengage Sy Touch Control Steering Switches (f Flight Guidance Computer (FGC) Takeoff/Go-Around (TO/GA) Butt	ect Buttons on Thrust Lever Handles) vitches (on Thrust Lever Stem) TCS) / Autopilots (Flight Directors)	22-1 22-1 22-1 22-2 22-2 22-2 22-3
ATA 23	CON	MUNICATIONS	23-1	
	2.		ith Flight Data Recorder (FDR) Installed)	23-1 23-2
	4. 5.	Selective Call System (SELCAL) Emergency Locator Transmitters (I Crewmember Interphone System	ELT) 23-5	23-4
	7.	F ~ J	23-8 23-8 23-9	
	9.	Satellite Communication Systems 2	23-10	22 11
		Prerecorded Passenger Announcen Flight Deck Hand Microphones		23-11
	12. 13. 14.	Flight Deck Headsets Earphones / Alerting Systems (Audio/Visual) (Audio/Visual) (Audio/Visual) (Audio/Visual)	Headphones and Boom Microphones	23-12
	16. 17.	High Frequency (HF) Communica NAVCOM Radio	tion Systems 23-17	23-17
	19.	Modular Radio Cabinet (MRC) Po		23-18
		Headsets Controller Pilot Data Link Commu	23-18 unications (CPDI-C)	23-19
	∠1.	Controller I flot Data Liffk Colliffic	inications (CLDLC)	43-19

<b>ATA 24</b>	EL	LECTRICAL POWER 24-1	
	1.	Engine Generators 24-1	
	2.	APU Generator 24-1	
	3.	Transformer-Rectifier Units (TRUs)24-2	
	4.	Main Airplane Battery Chargers 24-2	
	5.		
	6.		
	7.	Battery Voltmeters 24-3	
	8.	Electrical Power System EICAS Displays	24-4
		Master Power Switch Lights (L GEN, R GEN, APU GEN, EXT PWR)	24-5
		Battery Temperature Indicating System	24-7
		External Power System 24-7	
		Ground Service Bus System 24-8	24.6
		50Hz/60Hz AC Electrical Power Systems	24-8
		IRU Back Up Batteries (Forward and Aft Emergency Avionics Battery)	24-8 24-9
	13.	Remote Interface Unit (RIU) Channel (SSPC Controller Fault L-R)	24-5
ATA 25	EQ	QUIPMENT/FURNISHINGS 25-1	
	1.	Overwater Equipment 25-1	
		Passenger Seats 25-1	
	3.	Crewmember Shoulder Harnesses 25-4	
	4.	Observer Seat(s) 25-4	
	5.	Megaphones 25-6	
	6.		
		"Fasten Seat Belt While Seated" Signs or Placards	25-6
	8.		25-7
		Cargo Restraint Systems 25-9	
		Flight Attendant Seat Assembly 25-10	
		Galley/Cabin Waste Receptacles Access Doors/Covers	25-14
		Exterior Lavatory Door Ashtrays 25-14	
		External Camera System 25-14	25.17
		Emergency Vision Assurance System (EVAS)	25-15
		Pilot Seat(s) 25-15	
		Rudder Pedal Adjustment 25-16	
		Keyed Locks 25-16 Airplane Ladders 25-16	
		Airplane Ladders 25-16 Baggage Compartment Shelves 25-17	
	12. 20	Crewmember Flashlight Holder Assemblies (Including Flashlight)	25-17
		Non-Essential Equipment & Furnishings (NEF)	25-17 25-17

ATA 25	EQ	QUIPMENT/FURNISHINGS	25-18	
	23. 24.	Emergency Medical Kit (EMK) ar First Aid Kit (FAK) and/or Associ		25-18 25-18 25-19
ATA 26	FI	RE PROTECTION	26-1	
	1.	Portable Fire Extinguishers Wing Overheat Warning Systems	26-1	
		APU Fire Detection System	26-1	
	4.			26-2
		Lavatory Smoke Detection System		
		Lavatory Fire Extinguisher System		
	7.	Galley Smoke Detection Systems	26-4	
	8.	Galley Fire Extinguishing System	s26-5	
		Engine Fire Detection Systems	26-5	
		Flame Detectors	26-5	
		Electronic Equipment Rack Overh		26-5
		Passenger Compartment Closet Sr		26-5
		Entranceway Baggage Compartme		26-6
	14.	Cargo Compartment Fire Detectio	n/Suppression Systems	26-6
ATA 27	FL	IGHT CONTROLS	27-1	
	1.	Automatic Ground Spoiler System	n 27-1	
	2.			
	3.		27-1	
		Autopilot Roll Servos	27-1	
	5.		27-1	
		Inboard Spoiler Pair	27-2	
	7.			
		Control Wheel Position Sensors	27-3	
		Control Column Position Sensors		
		Rudder Pedal Position Sensors	27-4	27.4
	11.	1		27-4
	12.	Stick Shakers	27-4	

ATA 28	FU	EL	28-1		
	1.	Fuel Tank Temperature Systems	28-1		
	2.	EICAS or MCDU Fuel Quantity	Indicating Systems	28-1	
	3.	Fuel Quantity Indicating System	Channel	28-2	
	4.	Fuel Low Quantity Warning Syste	ems28-3		
	5.	Fuel Boost Pumps	28-3		
	6.	Fuel Intertank Valve	28-4		
	7.	Heated Fuel Return System (HFR	RS)28-4		
	8.	Fuel Boost Pump Warning Syster	ns28-4		
	9.	Fuel Crossflow Valve	28-5		
	10.	Pressure Fueling System (Single)	Point Refueling)	28-6	
	11.	Ground Service Control Panel	28-6		
	12.	Automatic Fueling System	28-6		
	13.	Fuel Cap Chains	28-6		
	14.	Single Point Refueling Cap	28-7		
	15.	SMC REFUEL Control Menu	28-7		
ATA 29	Н	DRAULIC POWER	29-1		
	1.	Brake Accumulator Pressure Gau	ge (Nose Wheelwell)	29-1	
	2.	Auxiliary Hydraulic Pump Pressu		29-1	
	3.	Power Transfer Unit (PTU) Hydr		29-1	
	4.	PTU Hydraulic Pump (Auto Mod			
	5.	Auxiliary Hydraulic Pump (Auto		29-1	
	6.	Left Hydraulic System Quantity 1	Indicator (Fluid Quantity Indic	ator - Aft Equipment Area)29-2	
	7.	Right Hydraulic System Quantity	Indicator (Fluid Quantity Indi	cator - Aft Équipment Area)	29-2
	8.	Left Hydraulic System Quantity I	Indication (EICAS)	29-2	
	9.	Right Hydraulic System Quantity	Indication (EICAS)	29-2	
	10.	Left Hydraulic Reservoir Temper	ature Sensors	29-3	
	11.	Right Hydraulic Reservoir Tempe	erature Sensors	29-3	
	12.	Hydraulic Reservoir Replenishing	g System	29-3	
	13.	Brake Accumulator Pressure Gau	ge (cockpit BAPI)	29-4	
	14.	Brake Synoptic Page Accumulate		29-4	
	15.	Brake Accumulator Pressure Tran	nsducer (inboard or outboard)	29-4	

ATA 30	ICE AND RAIN PROTECTION	30-1	
	<ol> <li>Cowl Anti-Ice Pressure Indicatio</li> <li>Wing Anti-Ice Systems</li> </ol>	on Systems 30-1	30-1
	3. Windshield Heat Systems	30-2	
	4. Side Window Heat Systems	30-2	
	<ol><li>Anti-Ice Heater Switch Lights</li></ol>	30-3	
	6. Ice Detection Systems	30-3	
	7. Cowl Anti-Ice Systems	30-4	
	8. Cowl Pressure Differential Indicate	ation System	30-5
	9. Windshield Surface Seal Protecti		30-5
	10. Cabin Window Heat System	30-5	
ATA 31	INDICATING/RECORDING SYS	ТЕМ	31-1
	1. Clocks (Cockpit)	31-1	
	2. Flight Data Recorder (FDR) Syst		
	3. Brake Temperature Monitoring S		31-2
	4. G Monitor System	31-3	
	5. Electronic Checklist	31-3	
	6. Security System	31-3	21.2
	7. Engine Cowl Open Indicating Sy		31-3
	8. Airplane Personality Module (Al		
	9. Plastic Guard Switch Covers	31-4 (CMS)	31-4
	10. Configuration Management Systems 11. Lefter Bad Counter Management Systems 11.	ems (CMS)	asures Systems (DIRCM)31
	12. Quick Access Recorder (QAR)	31-4	asures Systems (DIRCIVI)
	13. XM Weather Receiver	31-4	
	13. Aivi weather receiver	31-4	
ATA 32	LANDING GEAR	32-1	
	1. Rudder Pedal Steering System	32-1	
	2. Variable Gain Nose Wheel Steer		22.1
		Hardware (Torque Link Lanyards)	32-1
	4. Tire Pressure Monitoring System	1 32-1	22.1
	5. Nose Wheel Tire Pressure Monit		32-1
		sion Bottle Pressure Gauge (Nose Wheelwell)	32-2
		sion Bottle Pressure Cockpit Indication	32-2 32-2
	<ol><li>Landing Gear Extension/Retraction</li></ol>	ion system	3L- $L$

<b>ATA 33</b>	LI	GHTS	33-1		
	1.	Cockpit/Flight Deck/Flight Comr	partment Instrument Lighting Systems (Excludin	g EFIS and EICAS)	33-1
	2.	Passenger Cabin Interior Illumina	ation Systems	33-1	
	3.	Passenger Lighted Information Si	igns33-2		
	4.	Beacon Light LED Element Bank			
	5.	Wing-tip Strobes (Anti-Collision	Lights) LED Element Banks (per wing-tip)	33-5	
	6.	Tail Position Strobe (Anti-Collision	on Lights) LED Element Banks	33-6	
	7.	Wing-tip Position Light LED Ele		33-6	
	8.	Tail Position Light LED Element	Banks	33-6	
	9.	Wing Inspection Lights	33-7		
	10.	Landing Lights	33-8		
	11.	Taxi Light System	33-8		
	12.	Wing Tip Recognition Lights and	Taxi Lights System	33-8	
	13.		pe Path Marking System Lights	33-9	
	14.			33-9	
	15.	Logo Lights System	33-9		
		Ramp Lights System	33-9		
		Flashlight Charging Systems	33-10	22.10	
		Aft Compartment Lights (Boiler)		33-10	
		Cargo Compartment Light	33-10	22.10	
	20. 21	Pylon Mounted Exterior Baggage	2 Loading Light Systems 33-11	33-10	
	22.	Wheel Well Lights		33-11	
	23.	Exterior Emergency Evacuation I	33-11	33-11	
	23. 24.	Service Door Lights Dim and Test Annunciator Chann			
	25.	Airstair Lights	33-12		
	26.	Dome Light	33-12		
	27.	Baggage Compartment Light	33-12		
	28.	Cockpit Flashlight	33-12		
	20.	Cockpit I lashinght	33 12		
<b>ATA 34</b>	NA	VIGATION	34-1		
	1	Directional Compass Reference S	Sensors (IDS 1.2.3)	34-1	
	2.	Attitude Reference Sensors (IRS		34-1	
	3.	Standby Multi-Function Controlle		34-1	
	3. 4.	Weather Radar Systems	34-5	JT-2	
	т.	Wather Radar Systems	5T 5		

#### 34-5 **ATA 34** NAVIGATION (cont'd) 34-5 5. VOR/ILS Navigation Systems 6. Marker Beacon Systems 34-5 7. Automatic Direction Finding Systems 34-5 8. ATC Transponder and Automatic Altitude Reporting Systems 34-6 9. Distance Measuring Equipment (DME) Systems 34-7 10. Radio Altimeter Systems 34-8 11. Long Range Navigation Systems (IRS, GPS and GNSSU) 34-9 12. Terrain Awareness and Warning System (TAWS) 34-10 13. Lightning Sensor Systems (LSS) 34-13 14. Stormscope 34-13 15. Traffic Alert Collision and Avoidance System (TCAS II) 34-13 16. Microwave Landing Systems (MLS)34-14 17. Guidance Panel Digital Indications and Mode Select Indications 34-14 18. Altitude Alerting System 34-18 19. Display Units 34-18 20. Magnetometers 34-19 21. Head Up Display System22. Slip-Skid Indicators 34-19 34-19 23. Data LAN Management Unit (DLMU) 34-19 24. Air Data Systems (ADS 1-2-3) 34-20 25. Airshow Controller System 34-21 26. Windshear Warning and Flight Guidance System (Reactive) 34-21 27. Windshear Detection and Avoidance System (Predictive) 34-21 28. Cockpit Video Monitors 34-22 29. Heads Up Checklist 34-22 30. Enhanced Vision System (EVS) 34-22 31. Terrain Server Function/EGPWM Modules 34-23 32. Advanced Graphics Modules (AGM) 34-23 33. Advanced Graphics Modules (AGM) Database (does not include charts) 34-24 34. Cockpit Printer 34-24 35. Cursor Control Devices 34-24 36. Multi-function Control Display Units (MCDU) 34-25 37. Charts Function 34-26 34-26 38. Video Function 39. Automatic Dependent Surveillance-Broadcast (ADS-B) System 34-27 40. Synthetic Vision Primary Flight Display (SV PFD) Functions 34-28 41. CAS Scroll Switches 34-28

ATA 35	OXYGEN	35-1	
	1. Passenger Oxygen System and Su		35-1
	2. Cabin Oxygen ON Warning Syste	em35-1	25
	<ol> <li>Oxygen Service Panel Pressure G</li> <li>Portable Oxygen Dispensing Unit</li> </ol>		35-1 35-2
	5. Oxygen Supply Warning Systems		33-2
	6. Protective Breathing Equipment (		35-2
	7. Electronic Equipment Rack Oxyg	gen Pressure Gauges	35-2
	8. Cockpit Oxygen Pressure Indicate	ions	35-2
	<ul><li>9. Passenger Öxygen Control Panel</li><li>10. Therapeutic Oxygen</li></ul>	ALI SELECT (High Alt) Switch 35-3	35-3
	10. Therapeutic Oxygen	33 3	
ATA 36	PNEUMATIC	36-1	
	1. Bleed Air Systems	36-1	
	2. Bleed Air Hot Warning Systems		
	3. Isolation Valve	36-3	26.6
	4. Bleed Air System Switch Capsule Lights		36-3
ATA 38	WATER/WASTE	38-1	
	1. Potable Water Systems	38-1	
	2. Lavatory Waste Systems	38-1	
	3. Lavatory Dump/Drain System	38-2	
	4. Vacuum Toilet Holding Tank Indi	cator	38-2
ATA 45	CENTRAL MAINTENANCE COM	IPUTER	45-1
	1. Central Maintenance Computer (	CMC)	45-1
	2. Aircraft Health and Trend Monito		45-1
ATA 46	NEW TECHNOLOGY	46-1	
	1. Electronic Flight Bag Systems (E	FBs)	46-1

ATA 49	AI	RBORNE AUXILIARY POWER	49-1	
	1.	Auxiliary Power Unit (APU)	49-1	
	2.	APU EGT Indicators (EICAS and	Overhead)	49-1
	3.	APU Tachometers (EICAS and O	verhead)	49-1
	4.	APU "READY" Light System	49-2	
	5.	APU Remote Oil Quantity/Servic	ing System	49-2
	6.	APU Oil Pressure Gauges	49-2	
	7.	APU Oil Temperature Gauges	49-2	
	8.	APU Fuel Pressure Gauges	49-2	
	9.	APU Start Indicator Light	49-3	
	10.	APU Air Load Control Valve	49-3	
	11.	APU External Fire Warning Alarm	n (Fire Warning Bell)	49-3
		APU Air Inlet Door System	49-3	
	13.		49-4	
	14.	Ignition System Channels	49-4	
		EGT Thermocouple System	49-4	
	16.	Temperature Resistance Bulb (T2	) 49-4	
		Inlet Pressure Transmitter (P2)	49-4	
		RPM Speed Sensor Channels	49-5	
		APU Hour Meter	49-5	
	20.	Oil Temperature	49-5	
		APU Start/Engine Cowl Interrupt	System	49-5
		Deprime Solenoid	49-6	
ATA 52	DO	ORS	52-1	
	1.	External / Service Door Warning	Light System	52-1
	2.	Cargo Door Operating System	52-1	
	3.	Cargo Door Warning Light System		
		Lavatory Door	52-2	
	5.	Baggage Door Warning System	52-2	
	6.	Main Entry Door Acoustic Curtain		52-2
	7.	Main Entry Door Warning System		
	8.	Overwing Exit Doors Warning Sy		52-4
	9.	Internal Baggage Door Warning S		52-4
		Internal Pocket Doors	52-4	- <b>-</b> .

ATA 71	POWERPLANT	71-1	
	1. EPA Tank Ejector Pump	71-1	
ATA 73	ENGINE FUEL & CONTROL	73-1	
	<ol> <li>Fuel Flow Indication Systems</li> <li>Fuel Low Pressure Warning Systems</li> <li>Engine FADEC Systems</li> </ol>	73-1 ems (EICAS) 73-2	73-1
ATA 74	IGNITION	74-1	
	<ol> <li>Ignition Systems</li> <li>Ignition ON Indicator Systems</li> </ol>	74-1 74-1	
ATA 77	ENGINE INDICATING	77-1	
	<ol> <li>HP Tachometer Indications EICA</li> <li>Engine Vibration Monitor System</li> <li>Standby Engine Instruments on M</li> </ol>		77-1 77-1
ATA 78	ENGINE EXHAUST	78-1	
	1. Thrust Reversers	78-1	
ATA 79	ENGINE OIL	79-1	
	<ol> <li>Low Oil Pressure Warning Syster</li> <li>Engine Oil Replenishment Syster</li> <li>Imminent Oil Filter Blockage Inc</li> <li>Oil Quantity Indication Systems</li> <li>Oil Filter Pressure Switch Fault I</li> </ol>	m 79-1 lications (EICAS/SMC/Ground Service Control Panel)	79-1 79-2 79-2
ATA 80	STARTING	80-1	
	<ol> <li>Engine Starting Systems</li> <li>Auto Start Systems</li> <li>Start Valve Position Indications</li> <li>Start Valve Position Indicator Lig</li> </ol>	80-1 80-1 80-2 ghts80-3	

P.O. Box 2206, Savannah, Georgia 31402-2206 Telephone (912) 965-3000 Telex 3772775