PILOT OPERATING HANDBOOK PDF FORMAT

Including Aircraft GVI (G650), GVI (G650ER)

Revision 10b April 10th, 2014 GAC DOC. No. GVI-0

2014 Gulfstream Aerospace Corporation

DISCLAIMER FOR MAINTENANCE / OPERATIONAL / PLACARDING PROCEDURES MANUAL (GAC DOC. No. GVI-0)

The technical information presented herein has been determined to be correct at time of publication. However, should a direct conflict exist between this and other official publications, e.g., Master Minimum Equipment List (MMEL), Airplane Flight Manuals (AFM), Maintenance Manuals, those publications take precedence.

COPYRIGHT 2014 GULFSTREAM AEROSPACE CORPORATION

All rights reserved, including the right to reproduce this publication. No part may be reproduced, stored in any retrieval system, or transmitted in any part or form or by any means, electronic, photocopying, microfilm, microfiche, mechanical, or otherwise, without prior written permission of Gulfstream Aerospace Corporation.

			<u>PAGE</u>	
FRONT	MAT	TER	F-1	
		Table of Contents	F-1	
		General Information	F-12	
		Revision Log	F-15	
		Minimum Navigation Equ	ipment Table	F-17
		En Route Navigation Req	uirementsF-19	
		Future Air Navigation Sys	stem (FANS) Requirement	F-20
ATA 21	ΑI	R CONDITIONING	21-1	
	1.	Cabin Altitude Indicator (Overhead Panel)	21-1
	2.	Cabin Differential Pressur	re Indicator21-2	
	3.	Cabin Rate of Climb India	eator 21-3	
	4.	Automatic Pressurization	Control Systems	21-3
	5.	Manual Pressurization Co	ntrol System	21-4
	6.	Semi-Auto Pressurization	Control System	21-4
	7.	Cabin Altitude Pressure V	Varning System	21-5
	8.		flow Valve Position Indicator	21-5
	9.		e Control System & Cabin Zone Tempe	erature Control Systems21-
	10.		perature Indicators (Overhead Panel)	21-7
	11.	Duct Temperature Indicat	ors (Overhead Panel)	21-7
	12.	Environmental Control Sy	stem (ECS) Packs	21-8
	13.	Air Conditioning System	Pack Inlet Valves	21-8
	14.	Thrust Outflow Valve Sys	tem (TROV)	21-9
	15.	Pressure Relief Valve	21-10	
	16.	Cabin Pressure Indicator a	and Control Panel	21-11
	17.	Semi Mode CPCS (SMC)	21-12	
	18.	Remote Filter (Pressure R	elief Valve PRV)	21-12
	19.	CPAM (Cabin Pressure A	cquisition Module)	21-12
	20.	Ram Air System	21-13	
	21.	PSU Fan	21-13	

ATA 22	ΑU	TO FLIGHT	22-1	
	1. 2. 3. 4. 5. 6. 7.	Autothrottle Systems Performance Management System Control Wheel Autopilot Disconne Autothrottle Disconnect Buttons (Autothrottle Engage/Disengage Sy Touch Control Steering Switches (Flight Guidance Computer (FGC) Takeoff/Go-Around (TO/GA) But	ect Buttons on Thrust Lever Handles) witches (on Thrust Lever Stem) (TCS) / Autopilots (Flight Directors)	22-1 22-1 22-1 22-2 22-2 22-2 22-3
ATA 23	CC	OMMUNICATIONS	23-1	
	1. 2.	Communications Systems (VHF, Cockpit Voice Recorder (CVR) (v	UHF) vith Flight Data Recorder (FDR) Installed)	23-1 23-2
	3. 4.	Selective Call System (SELCAL) Emergency Locator Transmitters ((ELT)	23-4
	5. 6. 7.	Crewmember Interphone System Interphone Systems Cockpit Speakers	23-8 23-8	
	8. 9.	Passenger Address Systems (PA) Satellite Communication Systems	23-9	
	10. 11.	Prerecorded Passenger Announcer		23-11
	12. 13.	Alerting Systems (Audio/Visual)		23-12
	15.	Radio Tuning Functions	23-15 23-16	22.15
	16. 17. 18.		23-17 21-18	23-17
	19. 20.	Modular Radio Cabinet (MRC) Po		23-18
	21.	Controller Pilot Data Link Commu		23-19

ATA 24	EL	ECTRICAL POWER	24-1	
	1.	Engine Generators	24-1	
	2.	APU Generator	24-1	
	3.	Transformer-Rectifier Units (TR	Us)24-2	
	4.	Main Airplane Battery Chargers	24-2	
	5.	Main Airplane Batteries	24-3	
	6.	Battery Ammeters (Overhead Pa	nel)24-3	
	7.	Battery Voltmeters	24-3	
	8.	Electrical Power System EICAS	Displays	24-4
	9.	Master Power Switch Lights (L G	GEN, R GEN, APU GEN, EXT PWR)	24-5
	10.	Battery Temperature Indicating S	System	24-7
	11.	External Power System	24-7	
	12.	Ground Service Bus System	24-8	
	13.	50Hz/60Hz AC Electrical Power	Systems	24-8
	14.	IRU Back Up Batteries (Forward	l and Aft Emergency Avionics Battery)	24-8
	15.	Remote Interface Unit (RIU) Cha	annel (SSPC Controller Fault L-R)	24-9
ATA 25	EÇ	QUIPMENT/FURNISHINGS	25-1	
	1.	Overwater Equipment	25-1	
	2.	Passenger Seats	25-1	
	3.	Crewmember Shoulder Harnesse	es 25-4	
	4.	Observer Seat(s)	25-4	
	5.	Megaphones	25-6	
	6.	Flotation Devices	25-6	
	7.	"Fasten Seat Belt While Seated"	Signs or Placards	25-6
	8.	Storage Bins/Cabin, Galley and I	Lavatory Storage Compartment/Closets	25-7
	9.	Cargo Restraint Systems	25-9	
	10.	Flight Attendant Seat Assembly	25-10	
	11.	Galley/Cabin Waste Receptacles	Access Doors/Covers	25-14
	12.	Exterior Lavatory Door Ashtrays	25-14	
		External Camera System	25-14	
	14.	Emergency Vision Assurance Sy	stem (EVAS)	25-15
	15.	Pilot Seat(s)	25-15	
	16.	Rudder Pedal Adjustment	25-16	
	17.	Keyed Locks	25-16	
	18.	Airplane Ladders	25-16	
	19.	Baggage Compartment Shelves	25-17	
	20.	Crewmember Flashlight Holder	Assemblies (Including Flashlight)	25-17
	21	Non-Essential Equipment & Furi	nishings (NEF)	25-17

ATA 25	EQ	QUIPMENT/FURNISHINGS	25-18	
	22. 23. 24.	Emergency Medical Kit (EMK) ar		25-18 25-18 25-19
	25.	· · · · · · · · · · · · · · · · · · ·	25-20	23-19
ATA 26	FII	RE PROTECTION	26-1	
	1.	Portable Fire Extinguishers	26-1	
	2.	Wing Overheat Warning Systems	26-1	
	3.	APU Fire Detection System	26-1	
	4.	Rear Baggage Compartment Smol		26-2
	5.	Lavatory Smoke Detection System		
	6.	Lavatory Fire Extinguisher System		
	7.	Galley Smoke Detection Systems		
	8.	Galley Fire Extinguishing Systems		
	9.	Engine Fire Detection Systems	26-5	
	10.		26-5	
	11.	1 · I		26-5
		Passenger Compartment Closet Sr		26-5
	13.	, ee e 1		26-6
	14.	Cargo Compartment Fire Detection	n/Suppression Systems	26-6
ATA 27	FL	IGHT CONTROLS	27-1	
	1.	Automatic Ground Spoiler System	127-1	
	2.	Control Wheel Pitch Trim Switche	es27-1	
	3.	Autopilot Pitch Servos	27-1	
	4.	Autopilot Roll Servos	27-1	
	5.	Single FCC Channel	27-1	
	6.	Inboard Spoiler Pair	27-2	
	7.	Backup Flight Control Unit (BFC)	,	
	8.		27-3	
	9.			
		Rudder Pedal Position Sensors	27-4	
	11.	1		27-4
	12.	Stick Shakers	27-4	

ATA 28	FU	EL	28-1		
	1.	Fuel Tank Temperature Systems	28-1		
	2.	EICAS or MCDU Fuel Quantity	Indicating Systems	28-1	
	3.	Fuel Quantity Indicating System	Channel	28-2	
	4.	Fuel Low Quantity Warning Syst	ems	28-3	
	5.	Fuel Boost Pumps	28-3		
	6.	Fuel Intertank Valve	28-4		
	7.	Heated Fuel Return System (HFR	RS)28-4		
	8.	Fuel Boost Pump Warning System	ms28-4		
	9.	Fuel Crossflow Valve	28-5		
	10.	Pressure Fueling System (Single	Point Refueling)	28-6	
	11.	Ground Service Control Panel	28-6		
	12.	Automatic Fueling System	28-6		
	13.	Fuel Cap Chains	28-6		
	14.	Single Point Refueling Cap	28-7		
	15.	SMC REFUEL Control Menu	28-7		
ATA 29	НУ	DRAULIC POWER	29-1		
	1.	Brake Accumulator Pressure Gau	ige (Nose Wheelwell)	29-1	
	2.	Auxiliary Hydraulic Pump Pressu	ire Indication	29-1	
	3.	Power Transfer Unit (PTU) Hydr	aulic Pressure Indication	29-1	
	4.	PTU Hydraulic Pump (Auto Mod	le)29-1		
	5.	Auxiliary Hydraulic Pump (Auto	Mode)	29-1	
	6.	Left Hydraulic System Quantity I	Indicator (Fluid Quantity Indicate	or - Aft Equipment Area)29-2	
	7.	Right Hydraulic System Quantity	Indicator (Fluid Quantity Indica	tor - Aft Equipment Area)	29-2
	8.	Left Hydraulic System Quantity I	Indication (EICAS)	29-2	
	9.	Right Hydraulic System Quantity	Indication (EICAS)	29-2	
	10.	Left Hydraulic Reservoir Temper	rature Sensors	29-3	
	11.	Right Hydraulic Reservoir Tempe	erature Sensors	29-3	
	12.	Hydraulic Reservoir Replenishing	g System	29-3	
	13.	Brake Accumulator Pressure Gau		29-4	
	14.	Brake Synoptic Page Accumulate	or Pressure Indication	29-4	
	15.	Brake Accumulator Pressure Tran	nsducer (inboard or outboard)	29-4	

ATA 30	IC	E AND RAIN PROTECTION	30-1	
	1.	Cowl Anti-Ice Pressure Indication	Systems	30-1
	2.	Wing Anti-Ice Systems	30-1	
	3.	Windshield Heat Systems	30-2	
	4.	Side Window Heat Systems	30-2	
	5.	Anti-Ice Heater Switch Lights	30-3	
	6.	Ice Detection Systems	30-3	
	7.	Cowl Anti-Ice Systems	30-4	
	8.	Cowl Pressure Differential Indicat	tion System	30-5
	9.	Windshield Surface Seal Protection	on Systems	30-5
	10.	Cabin Window Heat System	30-5	
ATA 31	IN	DICATING/RECORDING SYST	EM	31-1
	1.	Clocks (Cockpit)	31-1	
	2.	Flight Data Recorder (FDR) Syste		
	3.	Brake Temperature Monitoring Sy	ystem (BTMS)	31-2
	4.	G Monitor System	31-3	
	5.	Electronic Checklist	31-3	
	6.	Security System	31-3	
	7.	Engine Cowl Open Indicating Sys		31-3
	8.	Airplane Personality Module (AP)		
	9.	Plastic Guard Switch Covers	31-4	
	10.	Configuration Management System		31-4
	11.		em (IRCM) or Directional InfraRed Counter Mea	sures Systems (DIRCM)
	12.	Quick Access Recorder (QAR)	31-4	
	13.	XM Weather Receiver	31-4	
ATA 32	LA	NDING GEAR	32-1	
	1.	Rudder Pedal Steering System	32-1	
	2.	Variable Gain Nose Wheel Steering		
	3.	Nose Wheel Steering Accessory F		32-1
	4.	Tire Pressure Monitoring System		
	5.	Nose Wheel Tire Pressure Monito		32-1
	6.		on Bottle Pressure Gauge (Nose Wheelwell)	32-2
	7.	Emergency Landing Gear Extensi	on Bottle Pressure Cockpit Indication	32-2
	8.	Landing Gear Extension/Retraction	n System	32-2

ATA 33	LI	GHTS	33-1		
	1.	Cockpit/Flight Deck/Flight Com	partment Instrument Lighting Systems (Excluding	ng EFIS and EICAS)	33-1
	2.	Passenger Cabin Interior Illumin		33-1	
	3.	Passenger Lighted Information S	Signs33-2		
	4.	Beacon Light LED Element Ban	ks33-5		
	5.		n Lights) LED Element Banks (per wing-tip)	33-5	
	6.	Tail Position Strobe (Anti-Collis	sion Lights) LED Element Banks	33-6	
	7.	Wing-tip Position Light LED El	ement Banks (per wing-tip)	33-6	
	8.	Tail Position Light LED Elemen	t Banks	33-6	
	9.	Wing Inspection Lights	33-7		
	10.	Landing Lights	33-8		
	11.	Taxi Light System	33-8		
	12.	Wing Tip Recognition Lights an		33-8	
	13.	Floor Proximity Emergency Esc		33-9	
	14.	Pulse Light Systems (Identification	ion Lights)	33-9	
	15.	Logo Lights System	33-9		
	16.	Ramp Lights System	33-9		
	17.	Flashlight Charging Systems	33-10		
	18.	Aft Compartment Lights (Boiler		33-10	
	19.	Cargo Compartment Light	33-10		
	20.	Pylon Mounted Exterior Baggag		33-10	
	21.	2	33-11		
	22.	Exterior Emergency Evacuation		33-11	
	23.	Service Door Lights	33-11		
	24.	Dim and Test Annunciator Chan			
	25.	Airstair Lights	33-12		
	26.	Dome Light	33-12		
	27.	Baggage Compartment Light	33-12		
	28.	Cockpit Flashlight	33-12		
ATA 34	NA	AVIGATION	34-1		
	1.	Directional Compass Reference	Sensors (IRS 1-2-3)	34-1	
	2.	Attitude Reference Sensors (IRS		34-1	
	3.	Standby Multi-Function Control		34-2	
	4.	Weather Radar Systems	34-5		
		·			

ATA 34	NA	VIGATION (cont'd)	34-5	
	5.	VOR/ILS Navigation Systems	34-5	
	6.	Marker Beacon Systems	34-5	
	7.	Automatic Direction Finding Sys	tems	34-5
	8.	ATC Transponder and Automatic	e Altitude Reporting Systems	34-6
	9.	Distance Measuring Equipment (DME) Systems	34-7
	10.	Radio Altimeter Systems	34-8	
	11.	Long Range Navigation Systems	(IRS, GPS and GNSSU)	34-9
	12.	Terrain Awareness and Warning	System (TAWS)	34-10
	13.	Lightning Sensor Systems (LSS)	34-13	
	14.	Stormscope	34-13	
	15.	Traffic Alert Collision and Avoid	lance System (TCAS II)	34-13
	16.	Microwave Landing Systems (M.	LS)34-14	
		Guidance Panel Digital Indication		34-14
	18.	Altitude Alerting System	34-18	
	19.	Display Units	34-18	
	20.	Magnetometers	34-19	
	21.	Head Up Display System	34-19	
		Slip-Skid Indicators	34-19	
	23.	Data LAN Management Unit (DI	LMU)	34-19
	24.	Air Data Systems (ADS 1-2-3)	34-20	
	25.	Airshow Controller System	34-21	
	26.	Windshear Warning and Flight G	buidance System (Reactive)	34-21
	27.	Windshear Detection and Avoida		34-21
	28.	Cockpit Video Monitors	34-22	
	29.	Heads Up Checklist	34-22	
	30.	Enhanced Vision System (EVS)	34-22	
	31.	Terrain Server Function/EGPWM	1 Modules	34-23
	32.	Advanced Graphics Modules (AC	GM)	34-23
	33.	Advanced Graphics Modules (AC	GM) Database (does not include charts)	34-24
	34.	Cockpit Printer	34-24	
	35.	Cursor Control Devices	34-24	
	36.	Multi-function Control Display U	Jnits (MCDU)	34-25
		Charts Function	34-26	
	38.	Video Function	34-26	
		Automatic Dependent Surveilland		34-27
	40.	-		34-28
		CAS Scroll Switches	± • ·	

TABLE OF CONTENTS (CONTINUED)

ATA 35	OXYGEN	35-1	
	1. Passenger Oxygen System and S	Supply	35-1
	2. Cabin Oxygen ON Warning Sys	tem35-1	
	3. Oxygen Service Panel Pressure	Gauges	35-1
	4. Portable Oxygen Dispensing Un	its (Bottle and Mask)	35-2
	5. Oxygen Supply Warning System		
	6. Protective Breathing Equipment	(PBE)	35-2
	7. Electronic Equipment Rack Oxy	gen Pressure Gauges	35-2
	8. Cockpit Oxygen Pressure Indica	tions	35-2
	9. Passenger Oxygen Control Pane	l ALT SELECT (High Alt) Switch	35-3
	10. Therapeutic Oxygen	35-3	
ATA 36	PNEUMATIC	36-1	
	1. Bleed Air Systems	36-1	
	2. Bleed Air Hot Warning Systems	36-2	
	3. Isolation Valve	36-3	
	4. Bleed Air System Switch Capsu	le Lights	36-3
ATA 38	WATER/WASTE	38-1	
	1. Potable Water Systems	38-1	
	2. Lavatory Waste Systems	38-1	
	3. Lavatory Dump/Drain System	38-2	
	4. Vacuum Toilet Holding Tank In	dicator	38-2
ATA 45	CENTRAL MAINTENANCE CO	MPUTER	45-1
	1. Central Maintenance Computer	(CMC)	45-1
	2. Aircraft Health and Trend Monit		45-1
ATA 46	NEW TECHNOLOGY	46-1	
	Electronic Flight Bag Systems ()	EFBs)	46-1

TA 49	Al	RBORNE AUXILIARY POWEI	R 49-1	
	1.	Auxiliary Power Unit (APU)	49-1	
	2.	APU EGT Indicators (EICAS and	d Overhead)	49-1
	3.	APU Tachometers (EICAS and C		49-1
	4.	APU "READY" Light System	49-2	
	5.	APU Remote Oil Quantity/Service	cing System	49-2
	6.	APU Oil Pressure Gauges	49-2	
	7.	APU Oil Temperature Gauges	49-2	
	8.	APU Fuel Pressure Gauges	49-2	
	9.	APU Start Indicator Light	49-3	
	10.	APU Air Load Control Valve	49-3	
	11.	APU External Fire Warning Alar	rm (Fire Warning Bell)	49-3
	12.	APU Air Inlet Door System	49-3	
	13.	Surge Control Valve	49-4	
	14.	Ignition System Channels	49-4	
	15.	EGT Thermocouple System	49-4	
	16.	Temperature Resistance Bulb (T2	2)49-4	
	17.	Inlet Pressure Transmitter (P2)	49-4	
	18.	RPM Speed Sensor Channels	49-5	
	19.	APU Hour Meter	49-5	
	20.	Oil Temperature	49-5	
	21.	APU Start/Engine Cowl Interrup	t System	49-5
	22.	Deprime Solenoid	49-6	
TA 52	DC	OORS	52-1	
	1.	External / Service Door Warning	Light System	52-1
	2.	Cargo Door Operating System	52-1	
	3.	Cargo Door Warning Light Syste	em52-2	
	4.	Lavatory Door	52-2	
	5.	Baggage Door Warning System	52-2	
	6.	Main Entry Door Acoustic Curta	in/Door System	52-2
	7.	Main Entry Door Warning System		
	8.	Overwing Exit Doors Warning S		52-4
	9.	Internal Baggage Door Warning		52-4
	10.	Internal Pocket Doors	52-4	

ATA 71	POWERPLANT	71-1	
	1. EPA Tank Ejector Pump	71-1	
ATA 73	ENGINE FUEL & CONTROL	73-1	
	 Fuel Flow Indication Systems Fuel Low Pressure Warning Syst Engine FADEC Systems 	73-1 ems (EICAS) 73-2	73-1
ATA 74	IGNITION	74-1	
	 Ignition Systems Ignition ON Indicator Systems 	74-1 74-1	
ATA 77	ENGINE INDICATING	77-1	
	 HP Tachometer Indications EICA Engine Vibration Monitor System Standby Engine Instruments on M 		77-1 77-1
ATA 78	ENGINE EXHAUST	78-1	
	1. Thrust Reversers	78-1	
ATA 79	ENGINE OIL	79-1	
	 Low Oil Pressure Warning Syste Engine Oil Replenishment Syste Imminent Oil Filter Blockage Inc Oil Quantity Indication Systems Oil Filter Pressure Switch Fault I 	n 79-1 lications (EICAS/SMC/Ground Service Control Panel)	79-1 79-2 79-2
ATA 80	STARTING	80-1	
	 Engine Starting Systems Auto Start Systems Start Valve Position Indications Start Valve Position Indicator Light 	80-1 80-1 80-2 ghts80-3	

P.O. Box 2206, Savannah, Georgia 31402-2206 Telephone (912) 965-3000 Telex 3772775