

Make: 1Beyond
Model: Automate VX
Device Type: Recorder



General Information	
SIMPL Windows Name:	Automate VX v1.0
Category:	Lecture Capture
Version:	1.00
Summary:	Controls all standard functions and provides true feedback
General Notes:	To be used only with Automate VX hardware. The module utilizes the SIMPL# technology and will only work on the 3-Series Controller. Must pulse Initialize once IP Address, Port, or Request Type are set or changed
Crestron Hardware Required:	3-series processor only
Setup of Crestron Hardware:	N/A
Vendor Setup	Default Port: 3579. IP address or hostname, along with username and password required for Automate VX

Control:		
Initialize	D	Pulse to initialize the module. This must be done once IP Address, Port, or Request Type are set or changed, including at the start of the program.
IP_Address\$	S	Sets IP Address or Hostname of Automate
Port	A	Sets port to use to connect to Automate on. If none supplied, the default 3579 is used.
Username\$	S	Sets username to log into Automate
Password\$	S	Sets password to log into Automate
Login	D	Pulse to log in. Upon success this will poll Automate for its current status. This should be done after Initialization if Login_FB is low.
Toggle_AutoSwitch	D	Pulse to toggle AutoSwitch state.
Start_AutoSwitch	D	Pulse to start AutoSwitch.
Stop_AutoSwitch	D	Pulse to stop AutoSwitch.
Toggle_Recording	D	Pulse to toggle recording state.
Start_Recording	D	Pulse to start recording.
Stop_Recording	D	Pulse to stop recording.
Toggle_ISO_Recording	D	Pulse to toggle ISO recording state.
Start_ISO_Recording	D	Pulse to start ISO recording.
Stop_ISO_Recording	D	Pulse to stop ISO recording.
Toggle_Stream	D	Pulse to toggle stream state.
Start_Stream	D	Pulse to start stream.

Stop_Stream	D	Pulse to stop stream.
Toggle_Output	D	Pulse to toggle output state.
Start_Output	D	Pulse to start output.
Stop_Output	D	Pulse to stop output.
Get_AutoSwitch_Status	D	Pulse to query AutoSwitch status.
Get_Record_Status	D	Pulse to query recoding status.
Get_ISO_Record_Status	D	Pulse to query ISO recoding status.
Get_Stream_Status	D	Pulse to query stream status.
Get_Output_Status	D	Pulse to query output status.
Get_Current_Layout	D	Pulse to query currently active layout.
Get_Layout_Names	D	Pulse to update Number_Of_Layouts and Layout_Names\$
Layout<A-F>	D	Selects system layout.
Get_Current_Room_Config	D	Pulse to query currently active room configuration.
Get_Room_Config_Names	D	Pulse to update Number_Of_Room_Configs and Room_Config_Names\$
Room_Config<1-4>	D	Selects room configuration. Does not work when AutoSwitch is enabled.
Camera_Select<1-8>	D	Selects camera to control. Does not work when AutoSwitch is enabled.
Camera<1-8>Preset	A	Sends preset number to specified camera

Feedback:		
Initialized_FB	D	Feedback that the module has been initialized.
Login_FB	D	Feedback that the module is logged in and communicating with Automate.
AutoSwitch_Enabled_FB	D	Feedback that AutoSwitch is enabled.
AutoSwitch_Disabled_FB	D	Feedback that AutoSwitch is disabled.
Recording_Started_FB	D	Feedback that recording has started.
Recording_Stopped_FB	D	Feedback that recording has stopped.
ISO_Recording_Started_FB	D	Feedback that ISO recording has started.
ISO_Recording_Stopped_FB	D	Feedback that ISO recording has stopped.
Stream_Started_FB	D	Feedback that stream has started.
Stream_Stopped_FB	D	Feedback that stream has stopped.
Output_Started_FB	D	Feedback that output has started.
Output_Stopped_FB	D	Feedback that output has stopped.
Set_Layout_FB<A-F>	D	Feedback of current layout.
Number_Of_Layouts	A	Displays current number of layouts stored on Automate
Layout_Name\$<A-F>	S	Displays individual names of available layouts stored on Automate
Room_Config_FB<1-4>	D	Feedback of current room configuration.
Number_Of_Room_Configs	A	Displays current number of room configurations stored on Automate

Room_Config_Name\$<1-4>	S	Displays individual names of available room configurations stored on Automate
Camera_Select_FB<1-8>	D	Feedback of currently selected camera.
Recording_Status\$	S	Provides text confirmation of current recording status.
Error_Message\$	S	Displays error message provided by Automate System, if one is to occur.
Error_Status	A	Provides error code, if one is to occur
Camera_Preset_FB<1-8>	A	Diplays which preset each camera is on.

Parameter:

Request_Type	Sets the request type to be HTTP or HTTPS. Be sure to have correct ports set.
--------------	---

Testing:

OPS USED FOR TESTING:	RMC3: v1.600.0092
SIMPL WINDOWS USED FOR TESTING:	4.11.06
DEVICE DB USED FOR TESTING:	106.05.001.00
CRES DB USED FOR TESTING:	80.05.003.00
SAMPLE PROGRAM:	Automate VX Demo 1.0.smw
REVISION HISTORY:	V1.0 - Initial Release