

Make: 1Beyond

Model: Automate VX

Device Type: Recorder



General Information	
SIMPL Windows Name:	Automate VX v1.6.1
Category:	Lecture Capture / Video Processor
Version:	1.60
Summary:	Controls all standard functions and provides true feedback
General Notes:	To be used only with Automate VX hardware. The module utilizes the SIMPL# HTTP and HTTPS technology and will only work on a 3 or 4-Series Controller. All feedback is break before make.
Crestron Hardware Required:	3-series or 4-series processor only
Setup of Crestron Hardware:	N/A
Vendor Setup	Default Port: 3579 (4443 HTTPS). IP address or hostname, along with username and password required for Automate VX
Vendor Software Version:	v3.4.7523.23079 or Higher

Control:		
IP_Address\$	S	Sets IP Address or Hostname of Automate. Upon change, this will check to see if a token has already been obtained for the provided IP, and if so, will automatically log in.
Port	A	Sets port to use to connect to Automate on. If none supplied, the default 3579 (4443 HTTPS) is used.
Username\$	S	Sets username to log into Automate
Password\$	S	Sets password to log into Automate
Login	D	Pulse to log in. Upon success this will poll Automate for its current status. Should be done if Login_FB is low and after IP Address, Username, and Password have been provided. If no Username or Password is provided, it will use the last ones provided.
Toggle_AutoSwitch	D	Pulse to toggle AutoSwitch state.
Start_AutoSwitch	D	Pulse to start AutoSwitch.
Stop_AutoSwitch	D	Pulse to stop AutoSwitch.
Toggle_Recording	D	Pulse to toggle recording state.

Start_Recording	D	Pulse to start recording.
Stop_Recording	D	Pulse to stop recording.
Pause_Recording	D	Pulse to pause recording.
Toggle_ISO_Recording	D	Pulse to toggle ISO recording state.
Start_ISO_Recording	D	Pulse to start ISO recording.
Stop_ISO_Recording	D	Pulse to stop ISO recording.
Toggle_Stream	D	Pulse to toggle stream state.
Start_Stream	D	Pulse to start stream.
Stop_Stream	D	Pulse to stop stream.
Toggle_Output	D	Pulse to toggle output state.
Start_Output	D	Pulse to start output.
Stop_Output	D	Pulse to stop output.
Sleep	D	Pulse to put system to sleep.
Wake	D	Pulse to wake system from sleep.
Go_Home	D	Pulse to call home shot in system.
Get_AutoSwitch_Status	D	Pulse to query AutoSwitch status.
Get_Record_Status	D	Pulse to query recoding status.
Get_ISO_Record_Status	D	Pulse to query ISO recoding status.
Get_Stream_Status	D	Pulse to query stream status.
Get_Output_Status	D	Pulse to query output status.
Get_Copy_Status	D	Pulse to query status of file copy.
Get_Storage_Space_Available	D	Pulse to available and total storage space in GB.
Get_Current_Layout	D	Pulse to query currently active layout.
Get_Layouts	D	Pulse to update Number_Of_Layouts and Layout_Names\$
Change_Layout<A-Z>	D	Selects system layout.
Get_Current_Room_Config	D	Pulse to query currently active room configuration.
Get_Room_Configs	D	Pulse to update Number_Of_Room_Configs and Room_Config_Names\$
Change_Room_Config<1-99>	D	Selects room configuration. Does not work when AutoSwitch is enabled.
Force_Room_Config<1-99>	D	Will check the Auto Switch Status, stop Auto Switch if it was running, change room config and then restart Auto Switch if had been running when Force_Room_Config is called.
Get_Camera_Status	D	Pulse to query currently active camera.
Manual_Switch_Camera_<1-8>	D	Switches which camera output is live. Does not work when AutoSwitch is enabled.
Live_Camera_Preset	A	Calls the preset on the live camera.
Call_Camera_<1-8>_Preset	A	Calls the preset for camera <1-8>. This works independently of current live camera.

Copy_Files_Destination	S	Sets file path of where to copy recordings on the machine. NOTE: use \\ for each \ used in file path e.g. "D:\\Destination"
Copy_Log_Destination	S	Sets file path of where to copy log file on the machine. NOTE: use \\ for each \ used in file path e.g. "D:\\Destination"
Delete_Source_File	A	(DEFAULT) 0 = False, will not delete files after copy. 1 = True, will delete files from source folder once copy is completed
Copy_Files	D	Pulse to start copying files to specified desitination.
Call_Plugin_<1-3>	D	Pulse to trigger plugin, using the provided name and any args.
Plugin_<1-3>_Name\$	S	REQUIRED - name of plugin to call ie: Test.bat.
Plugin_Arg1\$	S	First argument to pass to plugin. If not used, pass empty string "" to clear last arg used.
Plugin_Arg2\$	S	Second argument to pass to plugin. If not used, pass empty string "" to clear last arg used.
Plugin_Arg3\$	S	Third argument to pass to plugin. If not used, pass empty string "" to clear last arg used.

Feedback:

Login_FB	D	Feedback that the module is logged in and communicating with Automate.
AutoSwitch_Enabled_FB	D	Feedback that AutoSwitch is enabled.
AutoSwitch_Disabled_FB	D	Feedback that AutoSwitch is disabled.
Recording_Started_FB	D	Feedback that recording has started.
Recording_Stopped_FB	D	Feedback that recording has stopped.
Pause_Enabled	D	Feedback that shows select allows for pausing recordings
Record_State	A	Feedback of the current recording state: 0 = Stopped 1 = Recording 2 = Paused
ISO_Recording_Started_FB	D	Feedback that ISO recording has started.
ISO_Recording_Stopped_FB	D	Feedback that ISO recording has stopped.
Stream_Started_FB	D	Feedback that stream has started.
Stream_Stopped_FB	D	Feedback that stream has stopped.
Output_Started_FB	D	Feedback that output has started.
Output_Stopped_FB	D	Feedback that output has stopped.

Sleep_FB	D	Feedback that system is in sleep state.
Wake_FB	D	Feedback that system is awake and active.
Go_Home_FB	D	Feedback that system has successfully called the home shot.
Change_Layout_<A-Z>_FB	D	Feedback of current layout.
Number_Of_Layouts	A	Displays current number of layouts stored on Automate.
Layout_Name\$<A-Z>	S	Displays individual names of available layouts stored on Automate.
Change_Room_Config_<1-99>_FB	D	Feedback of current room configuration.
Number_Of_Room_Configs	A	Displays current number of room configurations stored on Automate.
Room_Config_Name\$<1-99>	S	Displays individual names of available room configurations stored on Automate.
Manual_Switch_Camera_<1-8>_FB	D	Feedback of currently selected camera.
Recording_Status\$	S	Provides text confirmation of current recording status.
Error_Message\$	S	Displays error message provided by Automate System, if one is to occur.
Error_Status	A	Provides error code, if one is to occur.
Call_Camera_<1-8>_Preset_FB	A	Displays the current preset of the camera. NOTE: There is currently no way to poll for this information. The feedback is provided after a user sets a preset from the Crestron module and handles the response. If preset is set outside of Crestron system, then this will be out of sync until a preset is called again from within the module.
Copy_Files_Success	D	Will pulse to confirm successful copying of files.
Copy_Files_In_Progress	D	Will latch while files are being copied. Copy Files should not be triggered again until this process completes.
Storage_Space_Available_GB	A	Provides available disk space for recordings in GB.
Storage_Space_Total_GB	A	Provides total disk space for recordings in GB.
Call_Plugin_<1-3>_Completed_FB	D	Will pulse to confirm when plugin has completed. This will trigger even if an error is returned.

Parameter:

Request_Type	Sets the request type to be HTTP or HTTPS. Be sure to have correct ports set.
--------------	---

Testing:

OPS USED FOR TESTING:	RMC3: v1.601.4033.23895
SIMPL WINDOWS USED FOR TESTING:	4.14.21
DEVICE DB USED FOR TESTING:	115.08.002.00
CRES DB USED FOR TESTING:	90.00.004.00

SAMPLE PROGRAM:	Automate VX Demo 1.6.1.smw
REVISION HISTORY:	V1.0 - Initial Release
	V1.1 - Added Support for Copy File Command
	V1.2 - Added Support for Storage Space Available and Call Plugin
	v1.5 - Removed call for Initializing Module. Added Support for Pause Recording, Copy File Status, Go Home, and Sleep/Wake. Implemented new feedback for Record State, Copy Status and Sleep Wake. Compiled for 4 series.
	v1.6 - Added support for Force_Room_Config API.
	v1.6.1 - Fixed issue with logging into VX after getting a 401 return code.