



AVProEdge MxNet 1G
Crestron Simpl Driver

PRODUCT MANUAL



PRODUCT MANUAL

[Click Here](#)

INTRODUCTION

AVPro Edge MXNet is a driver by Janus Technology for configuring and controlling the MXNet AVoIP system from AVPro Edge. MXNet provides scalable AVoIP distribution from small to very large (hundreds of sources and displays) systems, whilst also providing a rich feature set including video wall functionality.

Before setting the driver, please make sure that the AvPro Edge MX Net is correctly setup.

We have provided a simple demo program and Vision tools XPanel design, showing how the product can be used. We'd recommend running this program prior to integrating into your custom site to confirm that the MX Net has been setup and the module can communicate correctly.

The Crestron driver consists of a Communication.umc which Communicates to the MXNet Control Box. Separate helper modules control switching, creating and controlling a Video Wall, favourites (saving and recalled switch configuration) and passthrough controls. These helper modules are connected via serial signals to the Communication.umc.

Note you only need to use the helper.umc's that are required for your install.

UMC Helpers:

SingleSwitch - perform a switch on the index of the output, the analog value will be the requested input. The switch is executed through a change event. This helper can be connected to, Combined, Video and audio switch signals in the Communication.umc.

MultiSwitch - this works in a similar way to the SingleSwitch helper but does not execute on change, to perform the switch(s) the synchronise digital signal needs to be pulsed. this helper allows you to setup many switches before performing an execute.

Favourite - allows you to save and recall part or all of a switch configuration and is connected to the FAVOURITES signal in the Communication.umc

IRSend – functionality to send IR Codes (Pronto and Global Cache formats) to transmitters and receivers. Command will execute on a signal change and is connected to the IR signal in the Communication.umc

SerialSend – functionality to send serial commands to the transmitters and receivers. Commands will execute on a signal change and is connected to the Serial signal in the Communication.umc

SerialSettings – functionality to set serial settings on transmitter and receiver. You can set different settings across the transmitters and receivers by having more than one instance of this helper.umc. The settings are sent by pulsing “SEND_SETTINGS”. the module is connected to the SERIAL_SETTINGS signal in the Communication.umc

VideoWall - This helper is designed to create and manage ONE video wall (You will need One instance of the helper per wall) and is connected to the FAVOURITES signal in the Communication.umc.

Configure TX Audio Type – setting the different Audio Types on individual Transmitters, execute on pulse

Configure TX EDID - setting the different Edid Modes on individual Transmitters, execute on pulse

Configure RX CEC - For using CEC controls on individual Receivers to control Displays, On and Off are executed on pulse, CEC Hex are executed on the serial changing.

Configure RX OSD - For Turning OSD on and off on individual Receivers, On and Off are executed on pulse.

Configure RX RESOLUTION - For setting the different Resolutions on individual Receivers, execute on pulse

Display Light - For Turning the front LEDs On, off and flashing on individual Receivers and Transmitters and are executed.

MV41 – If you system has a AC-MXNET-1g-MV41 v2 you can control, layout, source and audio selections as well as preset

CRESTRON HARDWARE REQUIRED

- Any Ethernet-enabled processor – need to be a 4 Series or higher

FEATURES

This switcher driver provides the following functionality:

- Switching (Combined, Audio and Video)
- Video Wall Controls
- AC-MXNET-1G-MV41V2
- Encoder and Decoder Controls
- Controlling Devices through IR,CEC and serial Passthrough

VENDOR FIRMWARE:

This module has been tested with MXnet, running API version

- Controller: V2.03
- Encoders: V3.33
- Decoders: V3.32 / V4.18

MXNET CONFIGURATION

NOTE Before setting the driver, please make sure that the AvPro Edge MX Net is correctly setup.

The MX Net controller must be configured with a static IP address in the same range as the Crestron processor in order for the two to communicate:

1. Choose the Controller Settings tab.
2. Enter the static IP address information into the Connection section, and click Apply.

In order to map between the physical MXNet devices, and virtual port numbers it is necessary to assign Alias names to the devices.

By conventions these will be 'IN1', 'OUT1' etc, designation Input / Output device and port number.

Out of the box, the MXNet devices will not have these Alias names configured, so it is necessary to configured these as a first step.

The following Functions are provided in the driver to assist in configuration of the matrix, and made accessible from the supplied test panel:

Note that the name must comply with the following conventions:

For Transmitter (input) devices: IN[number]-[name]

For Receiver (output) devices: OUT[number]-[name]

It is important that each name begins with “IN” or “OUT”, which is then followed by the input or output number. You must then add a hyphen (-) followed by an appropriate description for the device (note that no spaces are allowed). For example, in the screenshot above, the first input is named IN1-BluRayPlayer.

MODULE DEFINITIONS

Comms Modules

Handles all the requests coming in from the helper.umc and contains useful digital signals to reconfigure the system.

INPUTS

Names	Type	Description
COMBINED_SWITCH	STRING	Command received from COMBINED switching module
VIDEO_SWITCH	STRING	Command received from Single and Mult Switch module for video
AUDIO_SWITCH	STRING	Command received from Single and Mult Switch module for Audio
VIDEO_WALL	STRING	Command received from VIDEO WALL module
FAVOURITES	STRING	Command received from FAVOURITES switching module
SERIAL_SETTINGS	STRING	Command received from SERIAL_SETTINGS module
CUSTOM_COMMAND	STRING	Send a custom command to the MXNet
CONFIGURE_TX_DEVICES	STRING	Command received from CONFIGURE_TX_DEVICES module ConfigureTX_AudioType ConfigureTX_EDID Configure_Display_Light
CONFIGURE_RX_DEVICES	STRING	Command received from CONFIGURE_RX_DEVICES module RX_Resolution ConfigureRX_OSD ConfigureRX_CEC Configure_Display_Light
REDISCOVER_UNITS	DIGITAL	forces rediscovery of devices
REBOOT_ALL_DEVICES	DIGITAL	reboots all devices
AUTO_CONFIGURE_ALIASES	DIGITAL	automatically configures aliases. If any devices already have valid alias names configured, then these will remain unaltered. All other devices will be assigned alias names in ascending sequence, filling in any gaps in the numbering sequence.
CLEAR_ALL_ALIAS	DIGITAL	resets configuration names to factory default. Note use with caution
STREAM_CONTROL	DIGITAL	Controls whether Stream On/Off commands are sent when switching.

		0 – (default if not driven) Stream commands are not sent 1 – Stream commands are sent when switching (Stream Off when Input 0 (Disconnect), Stream On in all other cases)
--	--	--

PARAMETERS

Names	Type	Description
IP ADDRESS	STRING	The IP address of the AVProEdge MxNet controller.
PORT	INTEGER	TCP Port number Defaults is (24)
POLL_TIME	SEC	Time between status requests, 0 = disable poll

FEEDBACK

Names	Type	Description
VIDEO_SWITCH_FEEDBACK	STRING	Message to be fed back into Video switch (helper) module
AUDIO_SWITCH_FEEDBACK	STRING	Message to be fed back into Audio switch (helper) module
HOT_PLUG_FEEDBACK	STRING	Message to be fed back into Hot Plug (helper) module

Note: the following Single- and Multi-switching helper modules can be used for video, audio, and combined TX/RX switching:

SINGLE SWITCH

perform a switch on the index of the output, the analog value will be the requested input. The switch is executed through a change event. This helper can be connected to, Combined, Video and audio switch signals in the Communication.umc

CONTROL

Names	Type	Description
RX	STRING	Consumes COMMS feedback for switch to update statuses
[OUTPUT_x]	ANALOG	Assign input value for OUTPUT_x, switch will be performed on change
RX	STRING	Consumes COMMS feedback for switch to update statuses

FEEDBACK

Names	Type	Description
TX	STRING	Feeds into [xxx_SWITCH] of COMMS module
[OUTPUT_STATUS_x]	ANALOG	Current Input value for the OUTPUT_x. Setting a Input of 0 Turns off the video stream.
TX	STRING	Feeds into [xxx_SWITCH] of COMMS module

MULTI SWITCH

this works in a similar way to the SingleSwitch helper but does not executed on change, to perform the switch(s) the synchronise digital signal needs to be pulsed. this helper allows you to setup many switches before performing an execute.

Names	Type	Description
RX	STRING	Consumes COMMS feedback for switch to update statuses
SYNCHRONISE	DIGITAL	Executes Outputs changes
[OUTPUT_x]	ANALOG	Assign input value for OUTPUT_x

Names	Type	Description
TX	STRING	Command sent to COMMS module
[OUTPUT_STATUS_x]	ANALOG	Current Input value for the OUTPUT_x
TX	STRING	Command sent to COMMS module

VIDEO WALL

This helper is designed to create and manage ONE video wall (You will need One instance of the helper per wall) and is connected to the FAVOURITES signal in the Communication.umc.

Names	Type	Description
CREATE_VIDEO_WALL	DIGITAL	Create a video wall using the specified parameters.
REMOVE_VIDEO_WALL	DIGITAL	Remove all
[INPUT]	ANALOG	Specify an input to use as the source for the video wall.
SCREEN X IMAGE X SCREEN Y IMAGE Y	ANALOG ANALOG ANALOG ANALOG	Screen Width, Height - the overall size of the television in mm (e.g. "600,550"). Image Width, Height - the size of the actual screen in mm (e.g. "550,500").
SET BEZEL GAP SETTINGS	DIGITAL	Execute the requested Bezel Settings.
LAYOUT	STRING	Set the layout name to recall. (use RECALL_LAYOUT to recall).
RECALL_LAYOUT	DIGITAL	Recall the layout selected by name in the LAYOUT signal.
RECALL_MOSAIC_LAYOUT	DIGITAL	Recall a mosaic layout which has been created on mentor.

Names	Type	Description
Wall Name	STRING	Choose a wall name (Name must be Unique)
Wall size	Dropdown	The video wall screen configuration selection from the following options 2x2, x2 (top-row inverted), 3x3
Outputs	STRING	The outputs that make up the video wall. These can be expressed as comma separated values, as a range, or as a combination of the two (so, for example, "1-4", "1,2,3,4" and "1,2-4" are all the same)

Names	Type	Description
VIDEOWALL_COMMANDS	STRING	Feeds into [VIDEOWALL] on COMMS module

SERIAL SETTINGS

functionality to set serial settings on transmitter and receiver. You can set different settings across the transmitters and receivers by having more than one instance of this helper.umc. The settings are sent by pulsing "SEND_SETTINGS". the module is connected to the SERIAL_SETTINGS signal in the Communication.umc

Names	Type	Description
SEND_SETTINGS	STRING	The serial settings to be sent

Names	Type	Description
IN_PORT_NUMBERS	STRING	Transmitters to be set to this configuration these can be expressed as comma separated values, as a range, or as a combination of the two (so, for example, "1-4", "1,2,3,4" and "1,2-4" are all the same)
OUT_PORT_NUMBERS	STRING	Receives to be set to this configuration these can be expressed as comma separated values, as a range, or as a combination of the two (so, for example, "1-4", "1,2,3,4" and "1,2-4" are all the same)
BAUD_RATE	DIGITAL	The baud rate
PARITY	DIGITAL	The type of parity
DATABITS	DIGITAL	The number of databits

Names	Type	Description
SERIAL_SETTINGS	STRING	Feeds into [SERIAL_SETTINGS] on COMMS module

SERIAL Comms

functionality to send serial commands and receive serial feedback on the transmitters and receivers. You will need to add the COMMS module into your program for this to work, but all intermodule communication is handled internally and the installer will not need to do any connecting.

Names	Type	Description
IN[x] to device	STRING	The serial string to be sent to device from the transmitter matching the prefix alias number
OUTx[x] to device	STRING	The serial string to be sent to device from the receiver matching the prefix alias number

Names	Type	Description
IN[x] from device	STRING	The serial string received from a device coming from the matching transmitter with the prefix alias number
OUTxx[] from device	STRING	The serial string received from a device coming from the matching receiver with the prefix alias number

SEND IR

functionality to send IR commands on the transmitters and receivers. You will need to add the COMMS module into your program for this to work, but all intermodule communication is handled internally and the installer will not need to do any connecting.

Names	Type	Description
IR_TX_[x]	STRING	The IR string to be sent Example of string <pre>"0000 0068 0024 0000 0155 00b2 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0042 0015 0043 0015 0043 0015 0043 0015 0043 0015 0043 0015 0043 0016 0042 0016 0016 0016 0042 0016 0016 0015 0043 0016 0016 0016 0016 0015 0043 0016 0016 0016 0042 0015 0017 0015 0043 0016 0016 0015 0043 0016 062c 0156 0058 0016 07c5"</pre>
IR_RX_[x]	STRING	The IR string to be sent Example of string <pre>"0000 0068 0024 0000 0155 00b2 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0042 0015 0043 0015 0043 0015 0043 0015 0043 0015 0043 0016 0042 0016 0016 0016 0042 0016 0016 0015 0043 0016 0016 0016 0016 0015 0043 0016 0016 0016 0042 0015 0017 0015 0043 0016 0016 0015 0043 0016 062c 0156 0058 0016 07c5"</pre>

Configure TX AudioType

setting the different Audio Types on individual Transmitters, execute on pulse

Names	Type	Description
HDMI x	DIGITAL	Set Audio type to HDMI for the Transmitter x when pulsed
ANALOG x	DIGITAL	Set Audio type to Analog for the Transmitter x when pulsed
AUTO x	DIGITAL	Set Audio type to Auto for the Transmitter x when pulsed
AUTO 1 x	DIGITAL	Set Audio type to Auto 1 for the Transmitter x when pulsed
AUTO 2 x	DIGITAL	Set Audio type to Auto 2 for the Transmitter x when pulsed

Names	Type	Description
CONFIGURE_TX_CMD	STRING	Command sent to Comms module

Configure TX EDID

For setting the different Edid Modes on individual Transmitters, execute on pulse

Names	Type	Description
1080P_2CH_x	DIGITAL	Set EDID to 1080P 2CH for the Transmitter x when pulsed
1080P_6CH_x	DIGITAL	Set EDID to 1080P 6CH for the Transmitter x when pulsed
1080P_3D_2CH_x	DIGITAL	Set EDID to 1080P 3D 2CH for the Transmitter x when pulsed
1080P_3D_6CH_x	DIGITAL	Set EDID to 1080P 3D 6CH for the Transmitter x when pulsed
4k30HZ_3D_2CH_x	DIGITAL	Set EDID to 4k30HZ 3D 2CH for the Transmitter x when pulsed
4k30HZ_3D_6CH_x	DIGITAL	Set EDID to 4k30HZ 3D 6CH for the Transmitter x when pulsed
4k30HZ_3D_8CH_x	DIGITAL	Set EDID to 4k30HZ 3D 8CH for the Transmitter x when pulsed
1080P_2CH_HDR_x	DIGITAL	Set EDID to 1080P 2CH HDR for the Transmitter x when pulsed
1080P_6CH_HDR_x	DIGITAL	Set EDID to 1080P 6CH HDR for the Transmitter x when pulsed
1080P_3D_2CH_HDR_x	DIGITAL	Set EDID to 1080P 3D 2CH HDR for the Transmitter x when pulsed
1080P_3D_6CH_HDR_x	DIGITAL	Set EDID to 1080P 3D 6CH HDR for the Transmitter x when pulsed
4k30HZ_3D_2CH_HDR_x	DIGITAL	Set EDID to 4k30HZ 3D 2CH HDR for the Transmitter x when pulsed
4k30HZ_3D_6CH_HDR_x	DIGITAL	Set EDID to 4k30HZ 3D 6CH_HDR for the Transmitter x when pulsed
4k30HZ_3D_8CH_HDR_x	DIGITAL	Set EDID to 4k30HZ 3D 8CH HDR for the Transmitter x when pulsed
1920X1200_2D_2CH_HDR_x	DIGITAL	Set EDID to 1920X1200 2D 2CH HDR for the Transmitter x when pulsed
USER_EDID_x	DIGITAL	Set EDID to USER EDID for the Transmitter x when pulsed

Names	Type	Description
CONFIGURE_TX_CMD	STRING	Command sent to Comms module

Configure TX CEC

For using CEC controls on individual Receivers to control Displays, On and Off are executed on pulse, CEC Hex are executed on the serial changing.

Names	Type	Description
TX_CEC_ON_x	DIGITAL	Turn on display using CEC when pulsed
TX_CEC_OFF_x	DIGITAL	Turn off display using CEC when pulsed
CEC_HEX_x	STRING	Send the Hex to the CEC on the TX, example CEC commands have been provided in the demo program.

Names	Type	Description
CONFIGURE_TX_CMD	STRING	Command sent to Comms module

Configure RX CEC

For using CEC controls on individual Receivers to control Displays, On and Off are executed on pulse, CEC Hex are executed on the serial changing.

Names	Type	Description
RX_CEC_ON_x	DIGITAL	Turn on display using CEC when pulsed
RX_CEC_OFF_x	DIGITAL	Turn off display using CEC when pulsed
CEC_HEX_x	STRING	Send the Hex to the CEC on the RX, example CEC commands have been provided in the demo program.

Names	Type	Description
CONFIGURE_RX_CMD	STRING	Command sent to Comms module

Configure RX OSD

For Turning OSD on and off on individual Receivers, On and Off are executed on pulse.

Names	Type	Description
RX_OSD_ON_x	DIGITAL	Turn on OSD when pulsed
RX_OSD_OFF_x	DIGITAL	Turn off OSD when pulsed

Names	Type	Description
CONFIGURE_RX_CMD	STRING	Command sent to Comms module

Configure RX Resolution

For setting the different Resolutions on individual Receivers, execute on pulse

Names	Type	Description
280x720_50FPS_x	DIGITAL	Set RX Resolution x to 280x720 50FPS when pulsed
280x720_60FPS_x	DIGITAL	Set RX Resolution x to 280x720 60FPS when pulsed
920x1080_24FPS_x	DIGITAL	Set RX Resolution x to 920x1080 24FPS when pulsed
920x1080_50FPS_x	DIGITAL	Set RX Resolution x to 920x1080 50FPS when pulsed
920x1080_60FPS_x	DIGITAL	Set RX Resolution x to 920x1080 60FPS when pulsed
840x2160_30FPS_x	DIGITAL	Set RX Resolution x to 840x2160 30FPS when pulsed
PASSTHROUGH_x		Set RX Resolution x to Passthrough when pulsed

Names	Type	Description
CONFIGURE_RX_CMD	STRING	Command sent to Comms module

Configure Display Light

For Turning the front LEDs On, off and flashing on individual Receivers and Transmitters and are executed.

Names	Type	Description
LIGHT_ON_TX_1	DIGITAL	normal operation, lights on for Transmitter x
LIGHT_ON_RX_1	DIGITAL	normal operation, lights on for Receiver x
LIGHT_OFF_TX_1	DIGITAL	lights off, useful in situations where the light may be visible in a darkened room for Transmitter x
LIGHT_OFF_RX_1	DIGITAL	lights off, useful in situations where the light may be visible in a darkened room for Receiver x

Names	Type	Description
CONFIGURE_TX_CMD	STRING	Command sent to Comms module
CONFIGURE_RX_CMD	STRING	Command sent to Comms module

Configure RX Display Image

Select a image to be displayed on the RX. Values between 0 and 5 are accepted.

Names	Type	Description
DISPLAY_IMAGE_X	ANALOG	Value of image to be selected

Names	Type	Description
CONFIGURE_RX_CMD	STRING	Command sent to Comms module

FAVOURITES

Allows you to save and recall part or all of a switch configuration and is connected to the FAVOURITES signal in the Communication.umc

Names	Type	Description
Select_All	DIGITAL	Select all outputs
Clear_All	DIGITAL	De-select all outputs
[Output_x]	DIGITAL	ANALOG selected output
[Create_Favourite_x]	DIGITAL	Create a favourite for the outputs selected using SELECT_OUTPUT_x
[Recall_Favourite_x]	DIGITAL	Recall a configuration for the outputs previously stored as a favourite

Names	Type	Description
FAVOURITE	STRING	Command sent to Comms module
[Output_Feedback_x]	DIGITAL	Feedback from selected output

HOT PLUG

Provides detection feedback for each input and output. This helper can be connected to HOT_PLUG_FEEDBACK signal in the Communication.umc

Names	Type	Description
RX	STRING	Consumes COMMS feedback to update statuses

Names	Type	Description
[INPUT_DETECT_x]	DIGITAL	Hot plug status for input
[OUTPUT_DETECT_x]	DIGITAL	Hot plug status for output

HOT PLUG

Provides detection feedback for each input and output. This helper can be connected to HOT_PLUG_FEEDBACK signal in the Communication.umc

Names	Type	Description
RX	STRING	Consumes COMMS feedback to update statuses

Names	Type	Description
[INPUT_DETECT_x]	DIGITAL	Hot plug status for input
[OUTPUT_DETECT_x]	DIGITAL	Hot plug status for output

RX Volume

functionality to Controls volume to the receivers. You will need to add the COMMS module into your program for this to work, but all intermodule communication is handled internally and the installer will not need to do any connecting.

Names	Type	Description
Set Volume x	ANALOG	Sets the volume level 0 to 65535
Volume Up/Down x	DIGITAL	Increments the volume by one
Mute On	DIGITAL	Mutes receivers
Mute Off	DIGITAL	UnMutes receivers
Mute Toggle	DIGITAL	Toggles Mute on receivers

Names	Type	Description
CURRENT_VOLUME_x	ANALOG	Output volume level 0 to 65535
CURRENT_NATIVE_VOLUME_X	STRING	Output volume level 0 to Devices Max
CURRENT_PRECENT_VOLUME_X	STRING	Output volume level 0 to 100
IS_MUTED	DIGITAL	High = Muted Low = Unmuted

MV41 – Setup.

[Quick start guide](#)

MV41

This helper is designed to create and manage ONE MV41 (You will need One instance of the helper per MV41)

Names	Type	Description
CONNECTED	DIGITAL	Set to High if you wish to control the Equipment
FULL_SCREEN_SOURCE	ANALOG	On change, Source for FullScreen mode
LAYOUT_PIP_BL	DIGITAL	Pulse to change to required layout
LAYOUT_PIP_BR	DIGITAL	
LAYOUT_PIP_TL	DIGITAL	
LAYOUT_PIP_TR	DIGITAL	
LAYOUT_2x2	DIGITAL	
LAYOUT_3_LEFT	DIGITAL	
LAYOUT_3_LEFT_LETTERBOX	DIGITAL	
LAYOUT_3_BOTTOM	DIGITAL	
LAYOUT_3_BOTTOM_PILLARBOX	DIGITAL	Changes to requested Input
LAYOUT_FULL_SCREEN	DIGITAL	
SELECT_TILE_SOURCE_X	ANALOG	
TILE_SELECT_X	DIGITAL	
TILE_SOURCE	ANALOG	
AUDIO_SOURCE_X	DIGITAL	
AUDIO_FOLLOW	DIGITAL	
AUDIO_HDMI	DIGITAL	
PRESET_NUMBER	ANALOG	Select 1-20d presets store
PRESET_TAKE	DIGITAL	Pulse to restore preset (**PRESET NUMBER**)
SAVE_PRESET_NAME	STRING	give your Preset a Name before saving (this name will appear in **PRESET NAME[x]**)

SAVE_PRESET_NUMBER	ANALOG	Give your Preset a Number before saving (1-20d) if a preset already exists, that preset will be overwritten.
SAVE_PRESET	DIGITAL	Pulse to save current layout/sources and audio to the preset.
ASPECT_1_85x1_BLACK_EDGE_DELETE	ANALOG	Set Video Aspect Ratio Mode Vertical Captor Deletes The Black Edge Value range is 0-800 Video Vertical value of the black edge to be deleted
ASPECT_2_35x1_BLACK_EDGE_DELETE	ANALOG	Set Video Aspect Ratio Mode Vertical Captor Deletes The Black Edge Value range is 0-800 Video Vertical value of the black edge to be deleted
OUTPUT_ASPECT_4x3	DIGITAL	(Does Not Apply to Video PIP Mode)
OUTPUT_ASPECT_16x9	DIGITAL	
OUTPUT_ASPECT_21x9	DIGITAL	
OUTPUT_ASPECT_1.85x1	DIGITAL	
OUTPUT_ASPECT_2.35x1	DIGITAL	
API_PASSTHROUGH		Send Api Command Direct through the Module

Names	Type	Description
PORT	STRING	Default 5000d (AvPro Edge to add how to obtain each MV41 port number)

Names		Type	Description
CONNECTION_STATE		DIGITAL	Feedback on the connection state to the [! MODEL !] high = Connected.
MV_CONNECTION_STATUS		STRING	A readable name of the current connection state, eg (Connected, Disconnected)
CURRENT_FULLSCREEN_SOURCE		ANALOG	Integer value of input on fullscreen
FULLSCREEN_SOURCE_IS		STRING	Friendly name of input on fullscreen
LAYOUT_IS_PIP_BL	Main area = Tile 1 Pip area = Tile 2	DIGITAL	high = tile is currently active, when **SWITCH SOURCE IN SELECTED TILE** is pulse that tile will change.
LAYOUT_ IS_PIP_BR		DIGITAL	
LAYOUT_ IS_PIP_TL		DIGITAL	
LAYOUT_ IS_PIP_TR		DIGITAL	
LAYOUT_ IS_2x2	Top Left = Tile 1 Top right = Tile 2	DIGITAL	

	Bottom Left = Tile 3 Bottom Right= Tile 4		
LAYOUT_IS_3_LEFT	Main = Tile 1	DIGITAL	
LAYOUT_IS_3_LEFT_LETTERBOX	Top = Tile 2 Middle = Tile 3 Bottom= Tile 4	DIGITAL	
LAYOUT_IS_3_BOTTOM	Main = Tile 1	DIGITAL	
LAYOUT_IS_3_BOTTOM_PILLARBOX	Left = Tile 2 Middle = Tile 3 Right= Tile 4	DIGITAL	
LAYOUT_IS_FULL_SCREEN		DIGITAL	
TILE_IS_SOURCE_X		ANALOG	Current source number for each tile.
TILE_IS_SOURCE_NAME_X		STRING	Friendly name of input on that Tile
TILE_SELECTED_X		DIGITAL	high = tile is currently active, when **SWITCH SOURCE IN SELECTED TILE** is pulse that tile will change.
CURRENT_AUDIO_SOURCE		ANALOG	Current source number for the playing audio.
AUDIO_IS_FOLLOW		DIGITAL	Multiview Audio Mode to Follow Note:If Use VIDEO PIP Mode,MVAUD MODE Automatically Follow MVAUD IN
AUDIO_IS_HDMI		DIGITAL	Multiview Audio Mode to HDMI Note:If Use VIDEO PIP Mode,MVAUD MODE Automatically Follow MVAUD IN
LAST_PRESET_NAME		STRING	The name of the last selected preset.
LAST_PRESET_NUMBER		ANALOG	The number index of the last selected preset.
PRESET_NAME_X		STRING	list of all the preset names by there index positions.
ASPECT_1_85x1_BLACK_EDGE_DELETE_IS		ANALOG	

ASPECT_2_35x1_BLACK_EDGE_DELETE_IS	ANALOG	high = Current OUTPUT aspect
OUTPUT_ASPECT_IS_4x3	DIGITAL	
OUTPUT_ASPECT_IS_16x9	DIGITAL	
OUTPUT_ASPECT_IS_21x9	DIGITAL	
OUTPUT_ASPECT_IS_1.85x1	DIGITAL	
OUTPUT_ASPECT_IS_2.35x1	DIGITAL	

SUPPORT

If you require support for this driver please fill in a support request at <https://support.janustechnology.co.uk/>

Please ensure you provide the following information.

- Driver version you are using.
- Platform you are using e.g. Crestron Home or SIMPL windows
- Firmware version of your AVPro Edge MXnet
- Firmware version of your Crestron system.
- A full description of the issue you are having and how to recreate the issue.

TROUBLESHOOTING

- Confirm that correct IP address is entered into the IP address field
- Confirm that correct Port is entered.
- Check the AVPro Edge Fresco can be pinged from the control system controller. If the ping fails check your network configuration and cabling.
- Check the Fresco webpage under the connection tab. Can you see commands being sent from the driver.
- We recommend using a static IP address. Ensure this is done in either the device or router.

CHANGE LOG

Version	Date	Firmware	Enhancement/Bugs
2.0.0x	30/07/2025	MXnet V4.27.1 AC-MXnet-1G-MV41v2 1.00	Added AC-MXnet-1G-MV41v2 Only compatible for 4 series
1.8.0	14/06/2023	1.0	Added Output Volume

DISCLAIMER OF LIABILITY

The company shall not be liable for any issues, damages, or costs that may arise from the use of our driver software. While we strive to ensure that all versions of our driver are backward compatible, we cannot guarantee that this will always be the case. Users are advised to thoroughly test the driver in their specific environments and configurations before deployment to ensure compatibility and proper functionality. The company makes every effort to provide a reliable and functional product, but the driver is provided “as is” without warranties of any kind, either express or implied. The user assumes full responsibility for any loss, damage, or disruption caused using our driver, including, but not limited to, hardware malfunctions, data loss, or system failures. By using our driver, you acknowledge that you have read and understood this disclaimer, and you agree to release and hold harmless the company from any and all liabilities associated with its use.

By Janus Technology