

GENERAL INFORMATION:

SIMPLWINDOWS NAME:	AVProEdge_CXxx_Demo
CATEGORY:	A/V Matrix switch
SUMMARY:	This Crestron driver provides two-way control of the AVPro Edge CX62, CX42 and CX84 video matrix via TCP/IP, or RS232.
GENERAL NOTES:	Refer to AVPro Edge documentation for more information.
CRESTRON HARDWARE REQUIRED:	Any Ethernet-enabled series 3 or 4 processor.
SETUP OF CRESTRON HARDWARE:	N/A
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	The matrix should be installed, configured and tested according to AVPro Edge documentation prior to integration with this driver
CABLE DIAGRAM:	N/A

CONTROL:

SERIAL_RX*	S	Serial command received from device
HDBT	A	Sets HDBT to Input
HDMI	A	Sets HDMI to Input
HDBT2**	A	Sets HDBT2 to Input
HDMI2**	A	Sets HDMI2 to Input
AUDIO HDBT**	A	Sets Breakaway Audio for HDBT to Input
AUDIO HDMI**	A	Sets Breakaway Audio for HDMI to Input
AUDIO HDBT2**	A	Sets Breakaway Audio for HDBT2 to Input
AUDIO HDMI2**	A	Sets Breakaway Audio for HDMI2 to Input
SINGLE_SWITCH_MODE	A	Individual switching
DOUBLE_SWITCH_MODE	A	Switching both Outputs
HDBT_VIDEO_4k_2K	D	Set video to 4k.2k mode HDBT
HDBT_VIDEO_ICT_MODE	D	Set video to ICT mode HDBT
ALL_OUTPUTS_EX_AUDIO_ENABLE	A	Sets Ex-Audio Output Enable***
HDBT_AUDIO_EX_MIC_INPUT_ENABLE	D	Sets EX-Audio Route to Microphone Input Enable***
HDBT_STREAM_OFF	A	Sets Output HDBT Stream to Off
HDMI_STREAM_OFF	A	Sets Output HDMI Stream to Off
ALL_OUTPUT_STREAM_OFF	A	Sets Outputs Stream to Off
HDBT_STREAM_ON	A	Sets Output HDBT Stream to On

HDMI_STREAM_ON	A	Sets Output HDMI Stream to On
ALL_OUTPUT_STREAM_ON	D	Sets Outputs Stream to On
HDBT_MUTE_ON	D	Set HDBT Audio Mute to ON
HDMI_MUTE_ON	D	Set HDMI Audio Mute to ON
ALL_OUTPUT_MUTE_ON	D	Set all Audio Mute to ON
HDBT_MUTE_OFF	D	Set HDBT Audio Mute to OFF
HDMI_MUTE_OFF	D	Set HDMI Audio Mute to OFF
ALL_OUTPUT_MUTE_OFF	D	Set all Audio Mute to OFF
HDBT_SIGNAL_GEN_ENABLE***	D	Set HDBT Output Signal Generator Enable
HDMI_SIGNAL_GEN_ENABLE***	D	Set HDMI Output Signal Generator Enable
MIC VOLUME	A	Sets the Mic Volume
ZONE_X_VOLUME_SET	A	Sets the volume level of specified output (Range 0 to 65525)
ZONE_X_VOLUME_UP	D	Increases the volume by 1 of specified zone
ZONE_X_VOLUME_DOWN	D	Decreases the volume by 1 of specified zone
CUSTOM COMMAND	S	Sends API Passthrough Command
SET_PASSTHROUGH_BAUD_RATE	A	Sets the baud rate for serial passthrough commands
RS232_PASSTHROUGH_DATA	S	Sends Serial Passthrough command

*serial only

** CX84 Only

*** Execute of signal going high, When Signal does Low Disable is performed

PARAMETERS:

IP_ADDRESS	IP Address of matrix
PORT	Port number for TCP/IP connection (DEFAULT 23)
MODEL	Device model to be controlled
POLL_TIME	Poll time in seconds 1d = 1 second.

FEEDBACK (AVSwitch_IP):

CONNECTION_STATE	D	Connected = 1, Disconnected = 0
CONNECTION_STATUS	S	String description of connection state
HDBT_FB	A	The input currently connected to HDBT
HDMI_FB	A	The input currently connected to HDMI
HDBT2**	A	The input currently connected to HDBT2
HDMI2**	A	The input currently connected to HDMI2
AUDIO HDBT**	A	Current Breakaway Audio for HDBT set to Input

AUDIO HDMI**	A	Current Breakaway Audio for HDMI set to Input
AUDIO HDBT2**	A	Current Breakaway Audio for HDBT2 set to Input
AUDIO HDMI2**	A	Current Breakaway Audio for HDMI2 set to Input
SERIAL_TX*	S	Serial command sent to device
MIC_VOLUME_FB	A	The current volume level of the mic
ZONE_X_CURRENT_VOLUME_FB	A	The current volume level of specified zone (Range 0 to 65525)
ZONE_X_NATIVE_VOLUME_FB	S	The current volume level of specified zone (Range 0 to 100)
ZONE_X_PERCENTAGE_VOLUME_FB	S	The current volume level of specified zone (Range 0 to CX Max Volume)**

*serial only

** CX84 and CX84-AUHD Only

** CX Has different Max Volume depending on Firmware