

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Lighting Control
Manufacturer: ABB
Firmware Version: 2.1.0117
Model(s): IPR/S 2.1

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.05.0000-b007	2.01.0001-b001	1.2.3

Version History

Module Version	Date	Notes
1_0_0_0	4/6/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example:
InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example:
InterfaceName.connectionCounter = 5
- DevicesTemperatureScale variable must be set accordingly. Default value is 'Celsius'. Devices Temperature Scale can be set to 'Celsius' or 'Fahrenheit'. Example: InterfaceName.DevicesTemperatureScale = 'Celsius'
- ControllerIPAddress variable must be set accordingly. It should be the IP address assigned to the controller on which the module is loaded. Default value is '192.168.0.1'. Example:
InterfaceName.ControllerIPAddress = '192.168.0.1'

Control Commands, States, and Qualifiers:

Dimmer	'Up' 'Down' 'Stop'
['GroupAddress']	'String'
Scaling	0 to 255 in steps of 1
['GroupAddress']	'String'
Switch	'On' 'Off'
['GroupAddress']	'String'
ThermostatSetpoint	-999° to 999° in steps of 0.01°
['GroupAddress']	'String'
['Scale']	'Fahrenheit' 'Celsius'

Status Available:

AmbientTemperature	-999° to 999° in steps of 0.01°
['GroupAddress']	'String'
['Scale']	'Fahrenheit' 'Celsius'
ConnectionStatus	'Connected' 'Disconnected'
Scaling	0 to 255 in steps of 1
['GroupAddress']	'String'
Switch	'On' 'Off'
['GroupAddress']	'String'
ThermostatSetpoint	-999° to 999° in steps of 0.01°
['GroupAddress']	'String'
['Scale']	'Fahrenheit' 'Celsius'

Network communication:

When configuring the Ethernet interface, be sure the device settings match that of the GS interface settings.

Port Type:	Ethernet
Default Listen Port:	3671
Default Reply Port:	3672
Logon Credentials Supported:	No
Multi-Connection Capabilities:	No
Port Changeability:	Yes

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device:

In the KNX software (ETS), these options need to be adjusted:

- Devices like dimmers and relay controllers must be set to generate Status responses. Both the ABB KNX Router IPR/S 2.1 and the module perform better when this option is enabled.
- In the Router properties the following settings need to be used:
 - In the KNX → LAN settings, the setting “Telegram acknowledge for group telegrams” must be set to “always”.
 - In the IP settings, we advise to use “fixed” for “IP address assignment” and to use “special setup for IP”.
 - By default the Router will be on “Multicast”, this should be changed to “Unicast”.
 - In “Unicast” mode the “IP routing unicast address 1” should be set to the address of the Pro Controller.