
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: Allnet
Firmware Version: N/A
Model(s): ALL4076

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.06.0002-b002	1.4.1

Version History

Module Version	Date	Notes
1_1_0_0	1/3/2018	Initial Version

Module Notes

- If login credentials are required, devicePassword and deviceUsername must be set accordingly.
Example: InterfaceName.devicePassword = 'extron'

Supported Classes and Examples

HTTPClass
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 'admin', 'password', Model='ALL4076')

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	Value
ActuatorSwitching	'On'	'Off'
Qualifier Key	Qualifier Value	
'Actuator ID'	'1' – '6'	
# ActuatorSwitching example InterfaceName.Set('ActuatorSwitching', 'On', {'Actuator ID': '1'})		

Status Available N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Undetermined

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device