

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scripter Modules, refer to the "[Guide to Using Scripter Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: APC
Firmware Version: N/A
Model(s): AP7921B

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scripter Version
2.06.0002-b002	1.4.1

Version History

Module Version	Date	Notes
1_0_3_0	12/6/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly.
devicePassword and deviceUsername default values are apc and apc respectively.
Example: `InterfaceName.devicePassword = 'extron'`
- DisplayID variable must be set accordingly. Default value is '1'. DisplayID ranges from '1' to '4'.
Example: `InterfaceName.DisplayID = '1'`

Supported Classes and Examples

EthernetClass

<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='AP7921B')</code>

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command PowerOutlet	Value 'On'	Value 'Off'
Qualifier Key 'Number'	Qualifier Value '1' – '8'	Qualifier Value 'All'
# PowerOutlet example InterfaceName.Set('PowerOutlet', 'On', {'Number': '1'})		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	Value
PowerOutlet	'On'	'Off'
Qualifier Key	Qualifier Value	Qualifier Value
'Number'	'1' – '8'	'All'
# PowerOutlet examples InterfaceName.Update('PowerOutlet', {'Number': '1'}) Value = InterfaceName.ReadStatus('PowerOutlet', {'Number': '1'}) InterfaceName.SubscribeStatus('PowerOutlet', None, FeedbackHandler)		
Command	Value	
SerialNumber	'String'	
# SerialNumber examples InterfaceName.Update('SerialNumber') Value = InterfaceName.ReadStatus('SerialNumber') InterfaceName.SubscribeStatus('SerialNumber', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	Yes
Default Username:	apc
Default Password:	apc
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Power Outlet On Number 1	o10n 1:1\x0D\x0A
Power Outlet Off Number 8	o10ff 1:8\x0D\x0A
Power Outlet On Number 8	o10n 1:8\x0D\x0A
Power Outlet Off Number All	o10ff 1:all\x0D\x0A
Power Outlet On Number All	o10n 1:all\x0D\x0A

Appendix B. Update Commands

Power Outlet Number 8	olStatus 1:all\x0D\x0A
Power Outlet Number All	olStatus 1:all\x0D\x0A
Serial Number	about\x0D\x0A