

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: APC
Firmware Version: N/A
Model(s): AP7920, AP7930, AP7932

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.03.0000-b006	2.3.0

Version History

Module Version	Date	Notes
1_1_2_0	5/21/2019	Fixed PowerOutlet command for models AP7930 and AP7932. Added Reboot value to the PowerOutlet command.
1_1_1_0	10/3/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly. devicePassword and deviceUsername default values are apc and apc respectively.
Example: `InterfaceName.devicePassword = 'apc'`
`InterfaceName.deviceUsername = 'apc'`

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='AP7920')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	Value	Value
PowerOutlet	'On'	'Off'	'Reboot'
Qualifier Key	Qualifier Value	Qualifier Value	Qualifier Value
'Outlet'	'1' – '24'	'1' – '8' ¹	'All'
# PowerOutlet example InterfaceName.Set('PowerOutlet', 'On', {'Outlet': '1'})			

¹ Only supported by AP7920 model.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
Value = InterfaceName.ReadStatus('ConnectionStatus')		
InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
Refresh ¹	None	
InterfaceName.Update('Refresh')		
Value = InterfaceName.ReadStatus('ConnectionStatus')		
InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		

¹ This command can be used to keep the TCP connection open. No status is return.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	Yes
Default Username:	apc
Default Password:	apc
Multi-Connection	No
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Power Outlet Off Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D1\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D1\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet 24	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D24\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D8\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D8\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D9\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet Off Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D25\x0D1\x0D2\x0Dyes\x0D\x0D
Power Outlet On Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D1\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D1\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet 24	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D24\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D8\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D8\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D9\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet On Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D25\x0D1\x0D1\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D1\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet 1	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D1\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet 24	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D24\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D8\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet 8	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D8\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D9\x0D1\x0D3\x0Dyes\x0D\x0D
Power Outlet Reboot Outlet All	\x1B\x1B\x1B\x1B\x1B\x1B\x1B1\x0D2\x0D1\x0D\x0D25\x0D1\x0D3\x0Dyes\x0D\x0D

Appendix B. Update Commands

Refresh	\x1B
---------	------