

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Media Player
Manufacturer: Apart
Firmware Version: N/A
Model(s): PMR4000R MKII

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.06.0002-b002	1.4.1

Version History

Module Version	Date	Notes
1_1_0_0	12/21/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly.
Example: `InterfaceName.deviceUsername = 'admin'`
`InterfaceName.devicePassword = 'password'`

Supported Classes and Examples

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 'admin', 'password', Model='PMR4000R  
MKII')
```

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AudioMute	Value 'On'	Value 'Off'	
# AudioMute example InterfaceName.Set('AudioMute', 'On')			
Command ControlMode	Value 'Play' 'Previous'	Value 'Pause'	Value 'Next'
# ControlMode example InterfaceName.Set('ControlMode', 'Play')			
Command Input	Value 'Ethernet Radio'	Value 'Music Player'	Value 'FM Radio'
# Input example InterfaceName.Set('Input', 'Ethernet Radio')			
Command Power	Value 'On'	Value 'Off'	
# Power example InterfaceName.Set('Power', 'On')			
Command Preset	Value '0' – '8'		
# Preset example InterfaceName.Set('Preset', '0')			
Command Rate	Value 'Rewind' 'Fast Forward'	Value 'Pause'	Value 'Play'
Qualifier Key 'Speed'	Qualifier Value 1 to 126 in steps of 1		
# Rate example InterfaceName.Set('Rate', 'Rewind', {'Speed': 126})			
Command RepeatMode	Value 'On'	Value 'Off'	
# RepeatMode example InterfaceName.Set('RepeatMode', 'On')			

Global Scripter Module Communication Sheet

Command ShuffleMode	Value 'On'	Value 'Off'
# ShuffleMode example InterfaceName.Set('ShuffleMode', 'On')		
Command Volume	Value 1 to 32 in steps of 1	
# ShuffleMode example InterfaceName.Set('Volume', 32)		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
AudioMute	'On'	'Off'	
# AudioMute examples InterfaceName.Update('AudioMute') Value = InterfaceName.ReadStatus('AudioMute') InterfaceName.SubscribeStatus('AudioMute', None, FeedbackHandler)			
Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
ControlMode	'Play'	'Pause'	'Next'
	'Previous'		
# ControlMode examples InterfaceName.Update('ControlMode') Value = InterfaceName.ReadStatus('ControlMode') InterfaceName.SubscribeStatus('ControlMode', None, FeedbackHandler)			
Command	Value	Value	Value
Input	'Ethernet Radio'	'Music Player'	'FM Radio'
# Input examples InterfaceName.Update('Input') Value = InterfaceName.ReadStatus('Input') InterfaceName.SubscribeStatus('Input', None, FeedbackHandler)			
Command	Value	Value	
Power	'On'	'Off'	
# Power examples			

<pre>InterfaceName.Update('Power') Value = InterfaceName.ReadStatus('Power') InterfaceName.SubscribeStatus('Power', None, FeedbackHandler)</pre>			
Command	Value		
Preset	'0' – '8'		
<pre># Preset examples InterfaceName.Update('Preset') Value = InterfaceName.ReadStatus('Preset') InterfaceName.SubscribeStatus('Preset', None, FeedbackHandler)</pre>			
Command	Value	Value	Value
RateStatus	'Rewind'	'Pause'	'Play'
	'Fast Forward'		
<pre># RateStatus examples InterfaceName.Update('RateStatus') Value = InterfaceName.ReadStatus('RateStatus') InterfaceName.SubscribeStatus('RateStatus', None, FeedbackHandler)</pre>			
Command	Value	Value	
RepeatMode	'On'	'Off'	
<pre># RepeatMode examples InterfaceName.Update('RepeatMode') Value = InterfaceName.ReadStatus('RepeatMode') InterfaceName.SubscribeStatus('RepeatMode', None, FeedbackHandler)</pre>			
Command	Value		
SessionID ¹	'String'		
<pre># SessionID examples InterfaceName.Update('SessionID') Value = InterfaceName.ReadStatus('SessionID') InterfaceName.SubscribeStatus('SessionID', None, FeedbackHandler)</pre>			
Command	Value	Value	
ShuffleMode	'On'	'Off'	
<pre># ShuffleMode examples InterfaceName.Update('ShuffleMode') Value = InterfaceName.ReadStatus('ShuffleMode') InterfaceName.SubscribeStatus('ShuffleMode', None, FeedbackHandler)</pre>			
Command	Value		
Volume	1 to 32 in steps of 1		
<pre># Volume examples InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)</pre>			

¹ Send SessionID before attempting to send any other command. This will send the specified deviceUsername and devicePassword to the device.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Default Password:	1234
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device