

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Building Management Systems
Manufacturer: Artistic Licence
Firmware Version: N/A
Model(s): Art-Net 3

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.02.0000-b013	2.2.0

Version History

Module Version	Date	Notes
1_0_0_1	4/4/2019	Fixed module variables.
1_0_0_0	3/1/2018	Initial Version

Module Notes

- Network variable must be set accordingly. Default value is '0'. Physical ranges from 0 to 127.
Example: `InterfaceName.Network = '0'`
- Physical variable must be set accordingly. Default value is '0'. Universe ranges from 0 to 255.
Example: `InterfaceName.Physical = '0'`
- Universe variable must be set accordingly. Default value is '0'. Universe ranges from 0 to 255.
Example: `InterfaceName.Universe = '0'`
- Due to the complexity of the protocol, command strings are not included.

Supported Classes and Examples

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 6454, Model='Art-Net 3')</code>

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command DMX512Data	Value 0 to 255
Qualifier Key 'Slot'	Qualifier Value 1 to 512
# DMX512Data example InterfaceName.Set('DMX512Data', 255, {'Slot': 512})	

Status Available

N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	6454
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Undetermined

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device