

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Audio Processor
 Manufacturer: Attero Tech
 Firmware Version: N/A
 Model(s): unD6IO-BT

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0000-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_1_0	8/27/2019	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 49494, Model='unD6IO-BT')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value		
ActivatePairing	None		
# ActivatePairing example InterfaceName.Set('ActivatePairing', None)			
Command	Value		Value
ButtonLock	'Lock'	'Unlock'	
# ButtonLock example InterfaceName.Set('ButtonLock', 'Lock')			
Command	Value		
ClearBluetoothPairings	None		
# ClearBluetoothPairings example InterfaceName.Set('ClearBluetoothPairings', None)			
Command	Value		
CloseBluetoothConnection	None		
# CloseBluetoothConnection example InterfaceName.Set('CloseBluetoothConnection', None)			
Command	Value	Value	Value
LineInput	'RCA Left'	'3.5mm'	'RCA and 3.5mm'
Qualifier Key	Qualifier Value	Qualifier Value	
'Input'	'3' – '4'	'3 and 4'	
# LineInput example InterfaceName.Set('LineInput', 'RCA Left', {'Input': '3'})			
Command	Value		Value
OutputMute	'On'		'Off'
Qualifier Key	Qualifier Value		Qualifier Value
'Channel'	'1' – '2'		'All'
# OutputMute example InterfaceName.Set('OutputMute', 'On', {'Channel': '1'})			
Command	Value		
OutputVolume	-60 to 0 in steps of 1		
Qualifier Key	Qualifier Value		Qualifier Value
'Channel'	'1' – '2'		'All'
# OutputVolume example InterfaceName.Set('OutputVolume', 0, {'Channel': '1'})			
Command	Value		
PresetRecall	'1' – '9'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command	Value		
PresetSave	'1' – '9'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, BluetoothStatus, LineInput, OutputMute, and OutputVolume do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command BluetoothStatus	Value 'Idle'	Value 'Discoverable'	Value 'Connected'
# BluetoothStatus example Value = InterfaceName.ReadStatus('BluetoothStatus') InterfaceName.SubscribeStatus('BluetoothStatus', None, FeedbackHandler)			
Command ButtonLock	Value 'Lock'	Value 'Unlock'	
# ButtonLock example InterfaceName.Update('ButtonLock') Value = InterfaceName.ReadStatus('ButtonLock') InterfaceName.SubscribeStatus('ButtonLock', None, FeedbackHandler)			
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'	
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command LineInput	Value 'RCA Left'	Value '3.5mm'	Value 'RCA and 3.5mm'
Qualifier Key 'Input'	Qualifier Value '3' – '4'	Qualifier Value '3 and 4'	
# LineInput example Value = InterfaceName.ReadStatus('LineInput', {'Input': '3'}) InterfaceName.SubscribeStatus('LineInput', None, FeedbackHandler)			
Command OutputMute	Value 'On'	Value 'Off'	
Qualifier Key 'Channel'	Qualifier Value '1' – '2'	Qualifier Value 'All'	
# OutputMute example Value = InterfaceName.ReadStatus('OutputMute', {'Channel': '1'}) InterfaceName.SubscribeStatus('OutputMute', None, FeedbackHandler)			
Command OutputVolume	Value -60 to 0 in steps of 1		
Qualifier Key 'Channel'	Qualifier Value '1' – '2'	Qualifier Value 'All'	
# OutputVolume example Value = InterfaceName.ReadStatus('OutputVolume', {'Channel': '1'}) InterfaceName.SubscribeStatus('OutputVolume', None, FeedbackHandler)			

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Device Listen Port:	49494
Device Reply Port:	49494
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Undetermined
Listen Port Changeability:	Undetermined
Listen Port Changeability:	Undetermined

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Activate Pairing None	BTB \x0D
Button Lock Lock	BTL 1 \x0D
Button Lock Unlock	BTL 0 \x0D
Clear Bluetooth Pairings None	CBC \x0D
Close Bluetooth Connection None	BCC \x0D
Line Input 3.5mm Input 3	IS 3 B \x0D
Line Input 3.5mm Input 3 and 4	IS 0 B \x0D
Line Input 3.5mm Input 4	IS 4 B \x0D
Line Input RCA and 3.5mm Input 3	IS 3 A+B \x0D
Line Input RCA and 3.5mm Input 3 and 4	IS 0 A+B \x0D
Line Input RCA and 3.5mm Input 4	IS 4 A+B \x0D
Line Input RCA Left Input 3	IS 3 A \x0D
Line Input RCA Left Input 3 and 4	IS 0 A \x0D
Line Input RCA Left Input 4	IS 4 A \x0D
Output Mute Off Channel 1	OM 1 0 \x0D
Output Mute Off Channel 2	OM 2 0 \x0D
Output Mute Off Channel All	OM 0 0 \x0D
Output Mute On Channel 1	OM 1 1 \x0D
Output Mute On Channel 2	OM 2 1 \x0D
Output Mute On Channel All	OM 0 1 \x0D
Output Volume 0 Channel 1	OV 1 0 \x0D
Output Volume 0 Channel 2	OV 2 0 \x0D
Output Volume 0 Channel All	OV 0 0 \x0D
Output Volume -60 Channel 1	OV 1 -60 \x0D
Output Volume -60 Channel 2	OV 2 -60 \x0D
Output Volume -60 Channel All	OV 0 -60 \x0D
Preset Recall 1	LOAD 1 \x0D
Preset Recall 9	LOAD 9 \x0D
Preset Save 1	SAVE 1 \x0D
Preset Save 9	SAVE 9 \x0D

Appendix B. Update Commands

Button Lock	QUERY\x0D
-------------	-----------

