

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Audio Processor
Manufacturer: Atlas
Firmware Version: N/A
Model(s): BB-88

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.03.0000-b006	2.01.0001-b001	1.1.1

Version History

Module Version	Date	Notes
1_1_0_0	11/30/2016	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example:
InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example:
InterfaceName.connectionCounter = 5
- If a password is required on the device, please set devicePassword in the module. Example:
InterfaceName.devicePassword = 'Password'. Call InterfaceName.SetPassword() before calling Set or Update to login.

Control Commands, States, and Qualifiers:

PresetNumber	Integer
PresetString	String
SetBoolean	'True' 'False'
['Control Object/Group']	String
SetNumber	Integer
['Control Object/Group']	String
SetString	String
['Control Object/Group']	String

Status Available:

ConnectionStatus	'Connected' 'Disconnected'
GetBoolean	'True' 'False'
['Control Object/Group']	String
GetNumber	Integer
['Control Object/Group']	String
GetString	String
['Control Object/Group']	String

Network communication:

When configuring the Ethernet interface, be sure the device settings match that of the GS interface settings.

Port Type:	Ethernet
Default Port:	10007
Logon Credentials Supported:	Yes
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device:

Appendix A. Set Commands

* All applicable commands use “TestObject” as an example value for the Control Object/Group qualifier.

PresetNumber 1	PRESET 1\r
PresetNumber 2	PRESET 2\r
PresetString TestString	PRESET “TestString”\r
SetBoolean True	SET “TestObject” TRUE\r
SetBoolean False	SET “TestObject” FALSE\r
SetNumber 1	SET “TestObject” 1\r
SetNumber 2	SET “TestObject” 2\r
SetString TestString	SET “TestObject” TestString\r

Appendix B. Query Commands

* All queries use “TestObject” as an example value for the Control Object/Group qualifier.

GetBoolean	GET “TestObject”\r
GetNumber	GET “TestObject”\r
GetString	GET “TestObject”\r