
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Controller
Manufacturer: Antrax
Firmware Version: V1.3.2
Model(s): MultiBox-pro LAN+

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.08.0002-b001	1.4.2

Version History

Module Version	Date	Notes
1_0_0_0	4/23/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Classes and Examples

EthernetClass

```
InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='MultiBox-pro LAN+')
```

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command Power	Value 'On'	Value 'Off'
Qualifier Key 'Port'	Qualifier Value '1' – '4'	
# Power example InterfaceName.Set('Power', 'On', {'Port': '1'})		
Command Reset	Value None	
Qualifier Key 'Port'	Qualifier Value '1' – '4'	
# Reset example InterfaceName.Set('Reset', None, {'Port': '1'})		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	
ActivePowerStatus	Watts	
# ActivePowerStatus examples InterfaceName.Update('ActivePowerStatus') Value = InterfaceName.ReadStatus('ActivePowerStatus') InterfaceName.SubscribeStatus('ActivePowerStatus', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	Value
Power	'On'	'Off'
Qualifier Key	Qualifier Value	
'Port'	'1' – '4'	
# Power examples InterfaceName.Update('Power', {'Port': '1'}) Value = InterfaceName.ReadStatus('Power', {'Port': '1'}) InterfaceName.SubscribeStatus('Power', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	23
Logon Credentials	No
Supported:	
Multi-Connection	Yes
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Power Off Port 1	port\x0D1 state set 0\x0Dback\x0D
Power On Port 1	port\x0D1 state set 1\x0Dback\x0D
Power Off Port 4	port\x0D4 state set 0\x0Dback\x0D
Power On Port 4	port\x0D4 state set 1\x0Dback\x0D
Reset None Port 1	port\x0D1 reset\x0Dback\x0D
Reset None Port 4	port\x0D4 reset\x0Dback\x0D

Appendix B. Update Commands

Active Power Status	linesensor\x0D1 1 value show\x0Dback\x0D
Power Port 1	port\x0D1 state show\x0Dback\x0D
Power Port 4	port\x0D4 state show\x0Dback\x0D