

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: Audio Technica
Firmware Version: v1.5.5 (ATUC-50CU), v1.5.0 (ATUC-50DU)
Model(s): ATUC-50

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.06.0002-b002	1.4.1

Version History

Module Version	Date	Notes
1_1_0_0	12/4/2017	Deleted commands: Level Meter Change, Level Meter Status. Fixed Delegate Talk Control. Added Wait Status with Delegate Talk Control.
1_0_0_0	5/26/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- Update DelegateTalkControl must be called before every Set DelegateTalkControl because the control string varies based on the DelegateTalkControl's status.
Example: `InterfaceName.Update('DelegateTalkControl', {'DU': 1234})`
`InterfaceName.Set('DelegateTalkControl', 'On', {'DU': 1234})`

Supported Classes and Examples

EthernetClass

<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 17300, Model='ATUC-50')</code>
--

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command DelegateTalkControl	Value 'On'	Value 'Off'	
Qualifier Key 'DU'	Qualifier Value 0 – 999999999		
# DelegateTalkControl example InterfaceName.Set('DelegateTalkControl', 'On', {'DU': 1E+08})			
Command PresetRecall	Value '1' – '8'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command PresetSave	Value '1' – '8'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command Reboot	Value None		
# Reboot example InterfaceName.Set('Reboot', None)			
Command SoundRecording	Value 'Start'	Value 'Stop'	Value 'Pause'
# SoundRecording example InterfaceName.Set(' SoundRecording ', 'Start')			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
DelegateTalkControl	'On'	'Off'	'Wait'
Qualifier Key	Qualifier Value		
'DU'	0 – 99999999		
# DelegateTalkControl examples InterfaceName.Update('DelegateTalkControl', {'DU': 1E+08}) Value = InterfaceName.ReadStatus('DelegateTalkControl', {'DU': 1E+08}) InterfaceName.SubscribeStatus('DelegateTalkControl', None, FeedbackHandler)			
Command	Value		
Firmware	'String'		
# Firmware examples InterfaceName.Update('Firmware') Value = InterfaceName.ReadStatus('Firmware') InterfaceName.SubscribeStatus('Firmware', None, FeedbackHandler)			
Command	Value	Value	Value
SoundRecording	'Start'	'Stop'	'Pause'
# SoundRecording examples InterfaceName.Update('SoundRecording') Value = InterfaceName.ReadStatus('SoundRecording') InterfaceName.SubscribeStatus('SoundRecording', None, FeedbackHandler)			

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	17300
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Yes
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Preset Recall 8	callp S 0000 00 NC 8 \x0D
Preset Save 1	savep S 0000 00 NC 1 \x0D
Preset Save 8	savep S 0000 00 NC 8 \x0D
Reboot None	rboot S 0000 00 NC \x0D
Sound Recording Pause	recmd S 0000 00 NC 1 \x0D
Sound Recording Start	recmd S 0000 00 NC 2 \x0D
Sound Recording Stop	recmd S 0000 00 NC 0 \x0D

Appendix B. Update Commands

Delegate Talk Control DU 99999999	gtalk 0 0000 00 NC 99999999 \x0D
Firmware	gvers 0 0000 00 NC \x0D
Sound Recording	recst 0 0000 00 NC \x0D