

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: Audio Technica
Firmware Version: N/A
Model(s): ATUC-50

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_1_4_0	2/24/2020	Added notes for 'DU' parameter in Delegate Talk Control command. Added support for firmware version 2.0.0 protocol. Added status for Recording Elapsed Time, Recording Remaining Time and Preset Bank Name. Added commands: Aux Level, Aux Nominal Level, Interpretation Return Level, Interpretation Return Nominal Level, Mic/ Line Gain, Mic/ Line Level, Mic/ Line Type, Output Level, Output Source.
1_1_0_0	12/4/2017	Deleted commands: Level Meter Change, Level Meter Status. Fixed Delegate Talk Control. Added Wait Status with Delegate Talk Control.
1_0_0_0	5/26/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 17300, Model='ATUC-50')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AuxLevel ¹	Value 0 to 511 in steps of 1		
# AuxLevel example InterfaceName.Set('AuxLevel', 511)			
Command AuxNominalLevel ¹	Value '0dbV'	Value '-10dbV'	Value '-20dbV'
# AuxNominalLevel example InterfaceName.Set('AuxNominalLevel', '0dbV')			
Command DelegateTalkControl	Value 'On'	Value 'Off'	
Qualifier Key 'DU'	Qualifier Value 0 – 100000000		
# DelegateTalkControl example InterfaceName.Set('DelegateTalkControl', 'On', {'DU': 100000000})			
Command InterpretationReturnLevel ²	Value 0 to 511 in steps of 1		
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# InterpretationReturnLevel example InterfaceName.Set('InterpretationReturnLevel', 511, {'Input': '1'})			
Command InterpretationReturnNominalLevel ²	Value '0dbV'	Value '+4dbV'	
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# InterpretationReturnNominalLevel example InterfaceName.Set('InterpretationReturnNominalLevel', '0dbV', {'Input': '1'})			
Command MicLineGain ³	Value 0 to 44 in steps of 1		
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineGain example InterfaceName.Set('MicLineGain', 44, {'Input': '1'})			
Command MicLineLevel ³	Value 0 to 511 in steps of 1		
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineLevel example InterfaceName.Set('MicLineLevel', 511, {'Input': '1'})			
Command MicLineType ³	Value 'Mic'	Value 'Line +4dBu'	Value 'Line'
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineType example			

InterfaceName.Set('MicLineType', 'Mic', {'Input': '1'})			
Command OutputLevel ⁴	Value 0 to 511 in steps of 1		
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# OutputLevel example InterfaceName.Set('OutputLevel', 511, {'Output': '1'})			
Command OutputSource ⁴	Value 'Floor' 'Group 2' 'Language 2' 'Remote Language 2' 'Mic/ Line 1&2 Mix'	Value 'Group 0' 'Group 3' 'Language 3' 'Mic/ Line 1'	Value 'Group 1' 'Language 1' 'Remote Language 1' 'Mic/ Line 2'
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# OutputSource example InterfaceName.Set('OutputSource', 'Floor', {'Output': '1'})			
Command PresetRecall	Value '1' – '8'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command PresetSave	Value '1' – '8'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command Reboot	Value None		
# Reboot example InterfaceName.Set('Reboot', None)			
Command SoundRecording	Value 'Start'	Value 'Stop'	Value 'Pause'
# SoundRecording example InterfaceName.Set('SoundRecording', 'Start')			

¹ Requires update of either 'Aux Level' or 'Aux Nominal Level'.² Requires update of either 'Interpretation Return Level' or 'Interpretation Return Nominal Level'.³ Requires update of either 'Mic/ Line Gain', 'Mic/ Line Level' or 'Mic/ Line Type'.⁴ Requires update of either 'Output Level' or 'Output Source'.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value		
AuxLevel	0 to 511 in steps of 1		
# AuxLevel example InterfaceName.Update('AuxLevel') Value = InterfaceName.ReadStatus('AuxLevel') InterfaceName.SubscribeStatus('AuxLevel', None, FeedbackHandler)			
Command	Value	Value	Value
AuxNominalLevel	'0dbV'	'-10dbV'	'-20dbV'
# AuxNominalLevel example InterfaceName.Update('AuxNominalLevel') Value = InterfaceName.ReadStatus('AuxNominalLevel') InterfaceName.SubscribeStatus('AuxNominalLevel', None, FeedbackHandler)			
Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
DelegateTalkControl	'On'	'Off'	'Wait'
Qualifier Key	Qualifier Value		
'DU'	0 – 100000000		
# DelegateTalkControl example InterfaceName.Update('DelegateTalkControl', {'DU': 100000000}) Value = InterfaceName.ReadStatus('DelegateTalkControl', {'DU': 100000000}) InterfaceName.SubscribeStatus('DelegateTalkControl', None, FeedbackHandler)			
Command	Value		
Firmware	'String'		
# Firmware example InterfaceName.Update('Firmware') Value = InterfaceName.ReadStatus('Firmware') InterfaceName.SubscribeStatus('Firmware', None, FeedbackHandler)			
Command	Value		
InterpretationReturnLevel	0 to 511 in steps of 1		
Qualifier Key	Qualifier Value		
'Input'	'1' – '2'		
# InterpretationReturnLevel example InterfaceName.Update('InterpretationReturnLevel', {'Input': '1'}) Value = InterfaceName.ReadStatus('InterpretationReturnLevel', {'Input': '1'}) InterfaceName.SubscribeStatus('InterpretationReturnLevel', None, FeedbackHandler)			

Global Scripter Module
Communication Sheet

Command InterpretationReturnNominalLevel	Value '0dbV'	Value '+4dbV'	
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# InterpretationReturnNominalLevel example InterfaceName.Update('InterpretationReturnNominalLevel', {'Input': '1'}) Value = InterfaceName.ReadStatus('InterpretationReturnNominalLevel', {'Input': '1'}) InterfaceName.SubscribeStatus('InterpretationReturnNominalLevel', None, FeedbackHandler)			
Command MicLineGain	Value 0 to 44 in steps of 1		
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineGain example InterfaceName.Update('MicLineGain', {'Input': '1'}) Value = InterfaceName.ReadStatus('MicLineGain', {'Input': '1'}) InterfaceName.SubscribeStatus('MicLineGain', None, FeedbackHandler)			
Command MicLineLevel	Value 0 to 511 in steps of 1		
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineLevel example InterfaceName.Update('MicLineLevel', {'Input': '1'}) Value = InterfaceName.ReadStatus('MicLineLevel', {'Input': '1'}) InterfaceName.SubscribeStatus('MicLineLevel', None, FeedbackHandler)			
Command MicLineType	Value 'Mic'	Value 'Line +4dBu'	Value 'Line'
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
# MicLineType example InterfaceName.Update('MicLineType', {'Input': '1'}) Value = InterfaceName.ReadStatus('MicLineType', {'Input': '1'}) InterfaceName.SubscribeStatus('MicLineType', None, FeedbackHandler)			
Command OutputLevel	Value 0 to 511 in steps of 1		
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# OutputLevel example InterfaceName.Update('OutputLevel', {'Output': '1'}) Value = InterfaceName.ReadStatus('OutputLevel', {'Output': '1'}) InterfaceName.SubscribeStatus('OutputLevel', None, FeedbackHandler)			
Command OutputSource	Value 'Floor' 'Group 2' 'Language 2' 'Remote Language 2' 'Mic/ Line 1&2 Mix'	Value 'Group 0' 'Group 3' 'Language 3' 'Mic/ Line 1'	Value 'Group 1' 'Language 1' 'Remote Language 1' 'Mic/ Line 2'
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# OutputSource example InterfaceName.Update('OutputSource', {'Output': '1'}) Value = InterfaceName.ReadStatus('OutputSource', {'Output': '1'}) InterfaceName.SubscribeStatus('OutputSource', None, FeedbackHandler)			
Command PresetBankName	Value 'String'		

Global Scripter Module Communication Sheet

Qualifier Key 'Number'	Qualifier Value '1' – '8'		
# PresetBankName example InterfaceName.Update('PresetBankName', {'Number': '1'}) Value = InterfaceName.ReadStatus('PresetBankName', {'Number': '1'}) InterfaceName.SubscribeStatus('PresetBankName', None, FeedbackHandler)			
Command RecordingElapsedTime	Value 'String'		
# RecordingElapsedTime example InterfaceName.Update('RecordingElapsedTime') Value = InterfaceName.ReadStatus('RecordingElapsedTime') InterfaceName.SubscribeStatus('RecordingElapsedTime', None, FeedbackHandler)			
Command RecordingRemainingTime	Value 'String'		
# RecordingRemainingTime example InterfaceName.Update('RecordingRemainingTime') Value = InterfaceName.ReadStatus('RecordingRemainingTime') InterfaceName.SubscribeStatus('RecordingRemainingTime', None, FeedbackHandler)			
Command SoundRecording	Value 'Start'	Value 'Stop'	Value 'Pause'
# SoundRecording example InterfaceName.Update('SoundRecording') Value = InterfaceName.ReadStatus('SoundRecording') InterfaceName.SubscribeStatus('SoundRecording', None, FeedbackHandler)			

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet

Default Port: 17300

Logon Credentials Supported: No

Multi-Connection Capabilities: Yes

Port Changeability: Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Delegate Talk Control Off DU 0	takof S 0000 00 NC 1,0 \x0D
Delegate Talk Control Off DU 99999999	takof S 0000 00 NC 1,99999999 \x0D
Delegate Talk Control On DU 0	takof S 0000 00 NC 1,0 \x0D
Delegate Talk Control On DU 99999999	takof S 0000 00 NC 1,99999999 \x0D
Preset Recall 1	callp S 0000 00 NC 1 \x0D
Preset Recall 8	callp S 0000 00 NC 8 \x0D
Preset Save 1	savep S 0000 00 NC 1 \x0D
Preset Save 8	savep S 0000 00 NC 8 \x0D
Reboot None	rboot S 0000 00 NC \x0D
Sound Recording Pause	recmd S 0000 00 NC 1 \x0D
Sound Recording Start	recmd S 0000 00 NC 2 \x0D
Sound Recording Stop	recmd S 0000 00 NC 0 \x0D

Appendix B. Update Commands

Aux Level	gxinp 0 0000 00 NC \x0D
Aux Nominal Level	gxinp 0 0000 00 NC \x0D
Delegate Talk Control DU 0	gtalk 0 0000 00 NC \x0D
Delegate Talk Control DU 99999999	gtalk 0 0000 00 NC \x0D
Firmware	gvers 0 0000 00 NC \x0D
Interpretation Return Level Input 1	giinp 0 0000 00 NC \x0D
Interpretation Return Level Input 2	giinp 0 0000 00 NC \x0D
Interpretation Return Nominal Level Input 1	giinp 0 0000 00 NC \x0D
Interpretation Return Nominal Level Input 2	giinp 0 0000 00 NC \x0D
Mic/ Line Gain Input 1	gminp 0 0000 00 NC \x0D
Mic/ Line Gain Input 2	gminp 0 0000 00 NC \x0D
Mic/ Line Level Input 1	gminp 0 0000 00 NC \x0D
Mic/ Line Level Input 2	gminp 0 0000 00 NC \x0D
Mic/ Line Type Input 1	gminp 0 0000 00 NC \x0D
Mic/ Line Type Input 2	gminp 0 0000 00 NC \x0D
Output Level Output 1	gaout 0 0000 00 NC \x0D
Output Level Output 4	gaout 0 0000 00 NC \x0D
Output Source Output 1	gaout 0 0000 00 NC \x0D
Output Source Output 4	gaout 0 0000 00 NC \x0D
Preset Bank Name Number 1	gnamb 0 0000 00 NC \x0D
Preset Bank Name Number 8	gnamb 0 0000 00 NC \x0D
Sound Recording	recst 0 0000 00 NC \x0D