

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Lighting Control
Manufacturer: Avolites
Firmware Version: N/A
Model(s): Titan Mobile

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.12.0000-b001	2.8.0

Version History

Module Version	Date	Notes
1_0_0_0	4/28/2021	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- Username and Password is not needed when defining the HTTP Interface.

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 4430, Model='Titan Mobile')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command FadeTime	Value 'String' ¹
# FadeTime example InterfaceName.Set('FadeTime', 'String')	
Command FirePlaybackAtLevel ²	Value None
Qualifier Key 'Always Refire'	Qualifier Value 'True' Qualifier Value 'False'
# FirePlaybackAtLevel example InterfaceName.Set('FirePlaybackAtLevel', None, {'Always Refire': 'True'})	
Command FirePlaybackLevel	Value 'String' ³
# FirePlaybackLevel example InterfaceName.Set('FirePlaybackLevel', 'String')	
Command FireUserNumber	Value 'String' ⁴
# FireUserNumber example InterfaceName.Set('FireUserNumber', 'String')	
Command KillPlayback ⁵	Value None
# KillPlayback example InterfaceName.Set('KillPlayback', None)	
Command KillUserNumber	Value 'String' ⁴
# KillUserNumber example InterfaceName.Set('KillUserNumber', 'String')	
Command ReleaseAllPlaybacks ⁶	Value None
Qualifier Key 'Use Master Release Time'	Qualifier Value 'True' Qualifier Value 'False'
# ReleaseAllPlaybacks example InterfaceName.Set('ReleaseAllPlaybacks', None, {'Use Master Release Time': 'True'})	

¹ Integer number between 0 and 300.

² Uses 'Fire Playback Level' and 'Fire User Number' as input. Only executes when correct input is supplied.

³ Integer number between 0 and 100.

⁴ Integer number between 1 and 999999999.

⁵ Uses 'Kill User Number' as input. Only executes when correct input is supplied.

⁶ Uses 'Fade Time' as input. Only executes when correct input is supplied.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
SoftwareVersion	'String'	
# SoftwareVersion example InterfaceName.Update('SoftwareVersion') Value = InterfaceName.ReadStatus('SoftwareVersion') InterfaceName.SubscribeStatus('SoftwareVersion', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type: Ethernet (HTTP)

Default Port: 4430

Logon Credentials No

Supported:

Multi-Connection Undetermined

Capabilities:

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device