
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scripter Modules, refer to the "[Guide to Using Scripter Modules](#)" document.

Device Specifications

Device Type: Controller
Manufacturer: Barco
Firmware Version: N/A
Model(s): BCMC Server

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scripter Version
2.08.0002-b001	1.4.2

Version History

Module Version	Date	Notes
1_0_0_0	7/20/2018	Initial Version

Module Notes

- This module does not support status.

Supported Classes and Examples

EthernetClass

<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23500, Model='BMC Server')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command WallPower	Value 'On'	Value 'Idle'
Qualifier Key 'Wall Name'	Qualifier Value 'String'	
# WallPower example InterfaceName.Set('WallPower', 'On', {'Wall Name': 'String'})		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	23500
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Undetermined

Appendix A. Set Commands

Wall Power Idle Wall Name testString	testString set Opstate wall idle\x0D\x0A
Wall Power On Wall Name testString	testString set Opstate wall on\x0D\x0A