

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Processor
Manufacturer: Barco
Firmware Version: N/A
Model(s): ECU 100, ECU 110, Control Room Management Suite, ECU 200

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.12.0000-b001	2.8.0

Version History

Module Version	Date	Notes
1_0_4_0	3/3/2021	Fixed command strings, added line feeds (\x0A).
1_0_3_0	12/3/2018	Initial Version

Module Notes

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 4585, Model='ECU 100')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	
CloseApplicationWindow ¹	'Close Window'	'Close All Windows'
Qualifier Key	Qualifier Value	
'Display'	'String'	
Qualifier Key	Qualifier Value	
'Window'	'String'	
# CloseApplicationWindow example InterfaceName.Set('CloseApplicationWindow', 'Close Window', {'Display': 'String', 'Window': 'String'})		
Command	Value	
Enable	'Enable'	'Disable'
Qualifier Key	Qualifier Value	
'Tiles'	'String'	
Qualifier Key	Qualifier Value	
'Perspective'	'String'	
# Enable example InterfaceName.Set('Enable', 'Enable', {'Tiles': 'String', 'Perspective': 'String'})		
Command	Value	
Identify	None	
Qualifier Key	Qualifier Value	
'Perspective'	'String'	
# Identify example InterfaceName.Set('Identify', None, {'Perspective': 'String'})		
Command	Value	
Load	None	
Qualifier Key	Qualifier Value	
'Display'	'String'	
Qualifier Key	Qualifier Value	
'Layout'	'String'	
# Load example InterfaceName.Set('Load', None, {'Display': 'String', 'Layout': 'String'})		
Command	Value	
Share ²	'Share'	'Unshare'
Qualifier Key	Qualifier Value	
'Tiles'	'String'	
Qualifier Key	Qualifier Value	
'Displays'	'String'	
Qualifier Key	Qualifier Value	
'Perspectives'	'String'	
# Share example InterfaceName.Set('Share', 'Share', {'Tiles': 'String', 'Displays': 'String', 'Perspectives': 'String'})		

Command Show	Value None
Qualifier Key 'Tiles'	Qualifier Value 'String'
Qualifier Key 'Perspectives'	Qualifier Value 'String'
Qualifier Key 'Sources'	Qualifier Value 'String'
# Show example InterfaceName.Set('Show', None, {'Tiles': 'String', 'Perspectives': 'String', 'Sources': 'String'})	
Command Swap	Value None
Qualifier Key 'Perspective'	Qualifier Value 'String'
Qualifier Key 'Tiles'	Qualifier Value 'String'
# Swap example InterfaceName.Set('Swap', None, {'Perspective': 'String', 'Tiles': 'String'})	
Command Update	Value None
Qualifier Key 'New Value'	Qualifier Value 'String'
Qualifier Key 'System Variable'	Qualifier Value 'String'
# Update example InterfaceName.Set('Update', None, {'New Value': 'String', 'System Variable': 'String'})	

¹ The Close Window command has optional parameters Window and Display. The Close All Windows command has an optional parameter of Display only. The Window parameter has no effect on the Close All Windows command.

² Displays and Tiles parameters are optional for Share while the Unshare command has Perspectives and Displays as optional parameters. The Tiles parameter has no effect on the Unshare command.

Status Available

N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type: Ethernet (TCP)

Default Port: 4585

Logon Credentials No

Supported:

Multi-Connection Undetermined

Capabilities:

Port Changeability: Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication.

Notes for the Device

Appendix A. Set Commands

Close Application Window Close All Windows Display testString Window testString	closeAllWindows testString\x0D\x0A
Close Application Window Close Window Display testString Window testString	closeWindow testString testString\x0D\x0A
Enable Disable Tiles testString Perspective testString	disable testString testString\x0D\x0A
Enable Enable Tiles testString Perspective testString	enable testString testString\x0D\x0A
Identify None Perspective testString	identify testString\x0D\x0A
Load None Layout testString Display testString	load testString testString\x0D\x0A
Share Unshare Tiles testString Displays testString Perspectives testString	unshare testString testString\x0D\x0A
Show None Sources testString Tiles testString Perspectives testString	show testString testString testString\x0D\x0A
Swap None Tiles testString Perspective testString	swap testString testString\x0D\x0A
Update None System Variable testString New Value testString	update testString testString\x0D\x0A