

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Processor
 Manufacturer: Barco
 Firmware Version: N/A
 Model(s): UniSee

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.08.0002-b001	1.4.2

Version History

Module Version	Date	Notes
1_0_0_0	7/30/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

EthernetClass

```
InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23500, Model='UniSee')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command DisplayMode	Value 'Actual Size'	Value 'Fit to Screen'	Value 'Aspect Ratio'
Qualifier Key 'Horizontal Position'	Qualifier Value Integer value		
Qualifier Key 'Vertical Position'	Qualifier Value Integer value		
# DisplayMode example InterfaceName.Set('DisplayMode', 'Actual Size', {'Horizontal Position': 1, 'Vertical Position':2 })			
Command Input	Value 'DisplayPort 1' 'HDMI 2'	Value 'DisplayPort 2'	Value 'HDMI 1'
Qualifier Key 'Horizontal Position'	Qualifier Value Integer value		
Qualifier Key 'Vertical Position'	Qualifier Value Integer value		
# Input example InterfaceName.Set('Input', 'DisplayPort 1', {'Horizontal Position':3 , 'Vertical Position':4 })			
Command Power	Value 'On'	Value 'Idle'	
Qualifier Key 'Horizontal Position'	Qualifier Value Integer value		
Qualifier Key 'Vertical Position'	Qualifier Value Integer value		
# Power example InterfaceName.Set('Power', 'On', {'Horizontal Position':1 , 'Vertical Position':3 })			

To address all displays in video wall, use 0

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
DisplayMode	'Actual Size'	'Fit to Screen'	'Aspect Ratio'
	'Mixed' ¹	'Unknown' ¹	
Qualifier Key	Qualifier Value		
'Horizontal Position'	Integer value		
Qualifier Key	Qualifier Value		
'Vertical Position'	Integer value		
# DisplayMode examples InterfaceName.Update('DisplayMode', {'Horizontal Position': 1,'Vertical Position': 1}) Value = InterfaceName.ReadStatus('DisplayMode', {'Horizontal Position': 1,'Vertical Position': 1}) InterfaceName.SubscribeStatus('DisplayMode', None, FeedbackHandler)			
Command	Value	Value	Value
Input	'DisplayPort 1'	'DisplayPort 2'	'HDMI 1'
	'HDMI 2'	'Mixed' ¹	'Unknown' ¹
Qualifier Key	Qualifier Value		
'Horizontal Position'	Integer value		
Qualifier Key	Qualifier Value		
'Vertical Position'	Integer value		
# Input examples InterfaceName.Update('Input', {'Horizontal Position':2 ,'Vertical Position': 2}) Value = InterfaceName.ReadStatus('Input', {'Horizontal Position': 2,'Vertical Position': 2}) InterfaceName.SubscribeStatus('Input', None, FeedbackHandler)			
Command	Value	Value	Value

Global Scripter Module Communication Sheet

Power	'On' 'Idle' 'Mixed' ¹ 'Unknown' ¹
Qualifier Key 'Horizontal Position'	Qualifier Value Integer value
Qualifier Key 'Vertical Position'	Qualifier Value Integer value
# Power examples InterfaceName.Update('Power', {'Horizontal Position': 3, 'Vertical Position': 3}) Value = InterfaceName.ReadStatus('Power', {'Horizontal Position': 3, 'Vertical Position': 3}) InterfaceName.SubscribeStatus('Power', None, FeedbackHandler)	
Command WallSize	Qualifier Value 'String'
# WallSize examples InterfaceName.Update('WallSize') Value = InterfaceName.ReadStatus('WallSize') InterfaceName.SubscribeStatus('WallSize', None, FeedbackHandler)	

To address all displays in video wall, use 0

¹ Only available when Horizontal Position and Vertical Position parameters are set to 0 (all displays)

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	23500
Logon Credentials Supported:	No
Multi-Connection	Yes
Capabilities:	
Port Changeability:	No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Display Mode Actual Size Vertical Position 0 Horizontal Position 0	MyWall set DisplayMode wall ActualSize\x0D\x0A
Display Mode Aspect Ratio Vertical Position 0 Horizontal Position 0	MyWall set DisplayMode wall AspectRatio\x0D\x0A
Display Mode Fit to Screen Vertical Position 0 Horizontal Position 0	MyWall set DisplayMode wall FitToScreen\x0D\x0A
Display Mode Actual Size Vertical Position 32767 Horizontal Position 0	MyWall set DisplayMode 0,32767 ActualSize\x0D\x0A
Display Mode Aspect Ratio Vertical Position 32767 Horizontal Position 0	MyWall set DisplayMode 0,32767 AspectRatio\x0D\x0A
Display Mode Fit to Screen Vertical Position 32767 Horizontal Position 0	MyWall set DisplayMode 0,32767 FitToScreen\x0D\x0A
Display Mode Actual Size Vertical Position 0 Horizontal Position 32767	MyWall set DisplayMode 32767,0 ActualSize\x0D\x0A
Display Mode Aspect Ratio Vertical Position 0 Horizontal Position 32767	MyWall set DisplayMode 32767,0 AspectRatio\x0D\x0A
Display Mode Fit to Screen Vertical Position 0 Horizontal Position 32767	MyWall set DisplayMode 32767,0 FitToScreen\x0D\x0A
Display Mode Actual Size Vertical Position 32767 Horizontal Position 32767	MyWall set DisplayMode 32767,32767 ActualSize\x0D\x0A
Display Mode Aspect Ratio Vertical Position 32767 Horizontal Position 32767	MyWall set DisplayMode 32767,32767 AspectRatio\x0D\x0A
Display Mode Fit to Screen Vertical Position 32767 Horizontal Position 32767	MyWall set DisplayMode 32767,32767 FitToScreen\x0D\x0A
Input DisplayPort 1 Vertical Position 0 Horizontal Position 0	MyWall set SelInput wall DisplayPort1\x0D\x0A
Input DisplayPort 2 Vertical Position 0 Horizontal Position 0	MyWall set SelInput wall DisplayPort2\x0D\x0A
Input HDMI 1 Vertical Position 0 Horizontal Position 0	MyWall set SelInput wall HDMI1\x0D\x0A
Input HDMI 2 Vertical Position 0 Horizontal Position 0	MyWall set SelInput wall HDMI2\x0D\x0A
Input DisplayPort 1 Vertical Position 32767 Horizontal Position 0	MyWall set SelInput 0,32767 DisplayPort1\x0D\x0A
Input DisplayPort 2 Vertical Position 32767 Horizontal Position 0	MyWall set SelInput 0,32767 DisplayPort2\x0D\x0A
Input HDMI 1 Vertical Position 32767 Horizontal Position 0	MyWall set SelInput 0,32767 HDMI1\x0D\x0A
Input HDMI 2 Vertical Position 32767 Horizontal Position 0	MyWall set SelInput 0,32767 HDMI2\x0D\x0A

Global Scripter Module Communication Sheet

Revision: 7/30/2018

Input DisplayPort 1 Vertical Position 0 Horizontal Position 32767	MyWall set SelInput 32767,0 DisplayPort1\x0D\x0A
Input DisplayPort 2 Vertical Position 0 Horizontal Position 32767	MyWall set SelInput 32767,0 DisplayPort2\x0D\x0A
Input HDMI 1 Vertical Position 0 Horizontal Position 32767	MyWall set SelInput 32767,0 HDMI1\x0D\x0A
Input HDMI 2 Vertical Position 0 Horizontal Position 32767	MyWall set SelInput 32767,0 HDMI2\x0D\x0A
Input DisplayPort 1 Vertical Position 32767 Horizontal Position 32767	MyWall set SelInput 32767,32767 DisplayPort1\x0D\x0A
Input DisplayPort 2 Vertical Position 32767 Horizontal Position 32767	MyWall set SelInput 32767,32767 DisplayPort2\x0D\x0A
Input HDMI 1 Vertical Position 32767 Horizontal Position 32767	MyWall set SelInput 32767,32767 HDMI1\x0D\x0A
Input HDMI 2 Vertical Position 32767 Horizontal Position 32767	MyWall set SelInput 32767,32767 HDMI2\x0D\x0A
Power Idle Vertical Position 0 Horizontal Position 0	MyWall set OpState wall idle\x0D\x0A
Power On Vertical Position 0 Horizontal Position 0	MyWall set OpState wall on\x0D\x0A
Power Idle Vertical Position 32767 Horizontal Position 0	MyWall set OpState 0,32767 idle\x0D\x0A
Power On Vertical Position 32767 Horizontal Position 0	MyWall set OpState 0,32767 on\x0D\x0A
Power Idle Vertical Position 0 Horizontal Position 32767	MyWall set OpState 32767,0 idle\x0D\x0A
Power On Vertical Position 0 Horizontal Position 32767	MyWall set OpState 32767,0 on\x0D\x0A
Power Idle Vertical Position 32767 Horizontal Position 32767	MyWall set OpState 32767,32767 idle\x0D\x0A
Power On Vertical Position 32767 Horizontal Position 32767	MyWall set OpState 32767,32767 on\x0D\x0A

Appendix B. Update Commands

Display Mode Vertical Position 0 Horizontal Position 0	MyWall get DisplayMode wall\x0D\x0A
Display Mode Vertical Position 32767 Horizontal Position 0	MyWall get DisplayMode 0,32767\x0D\x0A
Display Mode Vertical Position 0 Horizontal Position 32767	MyWall get DisplayMode 32767,0\x0D\x0A
Display Mode Vertical Position 32767 Horizontal Position 32767	MyWall get DisplayMode 32767,32767\x0D\x0A
Input Vertical Position 0 Horizontal Position 0	MyWall get SelInput wall\x0D\x0A
Input Vertical Position 32767 Horizontal Position 0	MyWall get SelInput 0,32767\x0D\x0A
Input Vertical Position 0 Horizontal Position 32767	MyWall get SelInput 32767,0\x0D\x0A
Input Vertical Position 32767 Horizontal Position 32767	MyWall get SelInput 32767,32767\x0D\x0A
Power Vertical Position 0 Horizontal Position 0	MyWall get OpState wall\x0D\x0A
Power Vertical Position 32767 Horizontal Position 0	MyWall get OpState 0,32767\x0D\x0A
Power Vertical Position 0 Horizontal Position 32767	MyWall get OpState 32767,0\x0D\x0A
Power Vertical Position 32767 Horizontal Position 32767	MyWall get OpState 32767,32767\x0D\x0A
Wall Size	MyWall get WallSize\x0D\x0A