

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Video Projector
Manufacturer: Barco
Firmware Version: N/A
Model(s): SLM R12+

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.04.0000-b007	2.01.0001-b001	1.2.2

Version History

Module Version	Date	Notes
1_0_0_0	1/12/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example: InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example: InterfaceName.connectionCounter = 5
- Device ID variable must be set accordingly. Default value is '1'. Device ID ranges from '0' to '255'. Example: InterfaceName.Device ID '1'
- For Serial Over Ethernet support, SerialOverEthernetClass must be used. Example: InterfaceName = ModuleName.SerialOverEthernetClass('192.168.254.254', PortNum, Model='ModelName')

Control Commands, States, and Qualifiers:

Freeze	'On'	'Off'
Input	'1' – '4'	
Keypad	'0' – '9'	
MenuNavigation	'Up'	'Down' 'Left'
	'Right'	'Menu' 'Enter'
	'Exit'	
Power	'On'	'Off'
VideoMute	'On'	'Off'

Status Available:

ConnectionStatus	'Connected'	'Disconnected'
Freeze	'On'	'Off'
Input	'1' – '4'	
LampUsage	Hours	
OperationHours	Hours	
Power	'On'	'Off'
VideoMute	'On'	'Off'

Cable and Adapter Requirements:

Captive Screw to Female DB9 RS-232 Serial Cable

Notes for the Device:

Serial communication:

Port Type: RS-232

Baud Rate: 9600

Data Bits: 8

Parity: None

Stop Bits: One

Flow Control: None

Pin Assignments Diagram

General Notes:

Appendix A. Set Commands

Freeze Off	\xFE\x01&#J\xFF
Freeze On	\xFE\x01'K\xFF
Input 1	\xFE\x011\x013\xFF
Input 2	\xFE\x011\x024\xFF
Input 3	\xFE\x011\x035\xFF
Input 4	\xFE\x011\x046\xFF
Keypad 0	\xFE\x010\x19J\xFF
Keypad 1	\xFE\x010\x10A\xFF
Keypad 2	\xFE\x010\x11B\xFF
Keypad 3	\xFE\x010\x12C\xFF
Keypad 4	\xFE\x010\x13D\xFF
Keypad 5	\xFE\x010\x14E\xFF
Keypad 6	\xFE\x010\x15F\xFF
Keypad 7	\xFE\x010\x16G\xFF
Keypad 8	\xFE\x010\x17H\xFF
Keypad 9	\xFE\x010\x18I\xFF
Menu Navigation Down	\xFE\x010\x056\xFF
Menu Navigation Enter	\xFE\x010\x0A;\xFF
Menu Navigation Exit	\xFE\x010\x089\xFF
Menu Navigation Left	\xFE\x010\x078\xFF
Menu Navigation Menu	\xFE\x010\x09:\xFF
Menu Navigation Right	\xFE\x010\x067\xFF
Menu Navigation Up	\xFE\x010\x045\xFF
Power Off	\xFE\x01fg\xFF
Power On	\xFE\x01ef\xFF

Appendix B. Query Commands

Input	\xFE\x0123\xFF
Lamp Usage	\xFE\x01de\xFF
Operation Hours	\xFE\x01bc\xFF
Power	\xFE\x01gh\xFF