

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Controller
Manufacturer: Bosch
Firmware Version: N/A
Model(s): DCNM-WAP

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.01.0000-b010	2.1.0

Version History

Module Version	Date	Notes
1_4_0_0	12/18/2018	Added commands SpeakersList, RequestToSpeakList, and ClearRequestToSpeakListAndSpeakers List. Removed Login command.
1_3_3_0	11/9/2018	Added Standby State to Set Power command.
1_3_2_1	9/11/2018	Remove incorrect import
1_3_2_0	8/21/2018	Added Login command
1_3_1_0	7/9/2018	- Added MicrophoneRequestStatus and SeatName commands. - Fixed MicrophoneStatus and Authentication.

Global Scripter Module Communication Sheet

		• Added IndividualVotingResults. • Changed VotingResult command name to VotingResults. • Removed 'Mode' and 'Name' qualifier and added 'Result' qualifier to VotingResults. Fixed 'Close' Microphone command.
1_2_0_1	3/16/2018	Fixed login credentials
1_2_0_0	1/16/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: InterfaceName.connectionCounter = 5
- Once the Seat Names are acquired from the system and they are changed by third party software, then the Seat Names will be updated in the module when MicrophoneStatus changes to 'Active' or MicrophoneRequestStatus changes to 'Waiting' or 'First on Waiting'.

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'admin', 'password', Model='DCNM-WAP')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command ClearRequestToSpeakListAndSpeakersList	Value None		
# ClearRequestToSpeakListAndSpeakersList example InterfaceName.Set('ClearRequestToSpeakListAndSpeakersList', None)			
Command Microphone	Value 'Open'	Value 'Close'	
Qualifier Key 'Mic'	Qualifier Value '1' – '80'		
# Microphone example InterfaceName.Set('Microphone', 'Open', {'Mic': '1'})			
Command Power	Value 'On'	Value 'Off'	Value 'Standby'
# Power example InterfaceName.Set('Power', 'On')			
Command VotingState	Value 'On'	Value 'Off'	
# VotingState example InterfaceName.Set('VotingState', 'On')			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus and SeatName do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls. SeatName will be updated in the module when MicrophoneStatus changes to 'Active' or MicrophoneRequestStatus changes to 'Waiting' or 'First on Waiting'.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
IndividualVotingResults ¹	'Yes/For'	'No/Against'	'Abstain'
	'Dnpv'	'Present'	'Not Voted'
	'Not Present'		
Qualifier Key	Qualifier Value		
'Name'	'String'		
# IndividualVotingResults examples InterfaceName.Update('IndividualVotingResults', {'Name': 'String'}) Value = InterfaceName.ReadStatus('IndividualVotingResults', {'Name': 'String'}) InterfaceName.SubscribeStatus('IndividualVotingResults', None, FeedbackHandler)			
Command	Value	Value	Value
MicrophoneRequestStatus ¹	'Waiting'	'Not Waiting'	'First on Waiting'
Qualifier Key	Qualifier Value		
'Mic'	'1' – '80'		
# MicrophoneRequestStatus examples InterfaceName.Update('MicrophoneRequestStatus', {'Mic': '1'}) Value = InterfaceName.ReadStatus('MicrophoneRequestStatus', {'Mic': '1'}) InterfaceName.SubscribeStatus('MicrophoneRequestStatus', None, FeedbackHandler)			
Command	Value	Value	

MicrophoneStatus ¹	'Active' 'Inactive'		
Qualifier Key 'Mic'	Qualifier Value '1' – '80'		
# MicrophoneStatus examples InterfaceName.Update('MicrophoneStatus', {'Mic': '1'}) Value = InterfaceName.ReadStatus('MicrophoneStatus', {'Mic': '1'}) InterfaceName.SubscribeStatus('MicrophoneStatus', None, FeedbackHandler)			
Command Power	Value 'On'	Value 'Off'	Value 'Standby'
# Power examples InterfaceName.Update('Power') Value = InterfaceName.ReadStatus('Power') InterfaceName.SubscribeStatus('Power', None, FeedbackHandler)			
Command RequestToSpeakList	Value '0' – '140'		
Qualifier Key 'Index'	Qualifier Value '1' – '25'		
# RequestToSpeakList examples InterfaceName.Update('RequestToSpeakList', {'Index': '1'}) Value = InterfaceName.ReadStatus('RequestToSpeakList', {'Index': '1'}) InterfaceName.SubscribeStatus('RequestToSpeakList', None, FeedbackHandler)			
Command SeatName	Qualifier Value 'String'		
Qualifier Key 'Mic'	Qualifier Value '1' – '80'		
# SeatName examples Value = InterfaceName.ReadStatus('SeatName', {'Mic': '1'}) InterfaceName.SubscribeStatus('SeatName', None, FeedbackHandler)			
Command SpeakersList	Value '0' – '140'		
Qualifier Key 'Index'	Qualifier Value '1' – '25'		
# SpeakersList examples InterfaceName.Update('SpeakersList', {'Index': '1'}) Value = InterfaceName.ReadStatus('SpeakersList', {'Index': '1'}) InterfaceName.SubscribeStatus('SpeakersList', None, FeedbackHandler)			
Command VotingResults	Value –		
Qualifier Key 'Result'	Qualifier Value 'Present' 'Abstain' 'No'	Qualifier Value 'For' 'Dnpv' 'Not Voted'	Qualifier Value 'Against' 'Yes'
# VotingResults examples			

```
InterfaceName.Update('VotingResults', {'Result': 'Present'})  
Value = InterfaceName.ReadStatus('VotingResults', {'Result': 'Present'})  
InterfaceName.SubscribeStatus('VotingResults', None, FeedbackHandler)
```

Command

VotingState

Value

'On'

Value

'Off'

```
# VotingState examples  
InterfaceName.Update('VotingState')  
Value = InterfaceName.ReadStatus('VotingState')  
InterfaceName.SubscribeStatus('VotingState', None, FeedbackHandler)
```

¹ Qualifier parameters is not required when calling the Update method with this command because the response returns statuses for all qualifier states.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Multi-Connection	No
Capabilities:	
Port Changeability:	Np

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device