

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

---

## Device Specifications

Device Type: Other  
Manufacturer: ControlByWeb  
Firmware Version: N/A  
Model(s): WebRelay-Quad

## Tested on the Following Software and Firmware Versions

| IP Link Pro Control Processor Firmware | Global Scriptor Version |
|----------------------------------------|-------------------------|
| 3.00.0000-b022                         | 2.0.0                   |

## Version History

| Module Version | Date      | Notes           |
|----------------|-----------|-----------------|
| 1_2_0_0        | 11/7/2018 | Initial Version |

---

## Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.  
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.  
Example: `InterfaceName.connectionCounter = 5`

## Supported Class and Example

### HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'admin', 'password', Model='WebRelay-Quad')
```

## Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

|                                                                                                |                                                   |
|------------------------------------------------------------------------------------------------|---------------------------------------------------|
| Command<br><b>PulseRelay</b>                                                                   | Value<br>None                                     |
| Qualifier Key<br><b>'Number'</b>                                                               | Qualifier Value<br>'1' – '4'                      |
| Qualifier Key<br><b>'Pulse Time'</b>                                                           | Qualifier Value<br>Float value in 0.1 increments  |
| # PulseRelay example<br>InterfaceName.Set('PulseRelay', None, {'Number': '1', 'Pulse Time': }) |                                                   |
| Command<br><b>Relay</b>                                                                        | Value<br>'On'                      Value<br>'Off' |
| Qualifier Key<br><b>'Number'</b>                                                               | Qualifier Value<br>'1' – '4'                      |
| # Relay example<br>InterfaceName.Set('Relay', 'On', {'Number': '1'})                           |                                                   |

## Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

### Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

### Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

|                                                                                                                                                                                  |                 |                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|----------------|
| Command                                                                                                                                                                          | Value           | Value          |
| ConnectionStatus                                                                                                                                                                 | 'Connected'     | 'Disconnected' |
| # ConnectionStatus examples<br>Value = InterfaceName.ReadStatus('ConnectionStatus')<br>InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)                  |                 |                |
| Command                                                                                                                                                                          | Value           | Value          |
| Relay <sup>1</sup>                                                                                                                                                               | 'On'            | 'Off'          |
| Qualifier Key                                                                                                                                                                    | Qualifier Value |                |
| 'Number'                                                                                                                                                                         | '1' – '4'       |                |
| # Relay examples<br>InterfaceName.Update('Relay')<br>Value = InterfaceName.ReadStatus('Relay', {'Number': '1'})<br>InterfaceName.SubscribeStatus('Relay', None, FeedbackHandler) |                 |                |

<sup>1</sup> Update does not require the qualifier. The response of the Update command will return status for all 4 qualifier values

---

---

## Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

|                                     |              |
|-------------------------------------|--------------|
| <b>Port Type:</b>                   | Ethernet     |
| <b>Default Port:</b>                | 80           |
| <b>Logon Credentials Supported:</b> | Yes          |
| <b>Default Password:</b>            | webrelay     |
| <b>Multi-Connection</b>             | Undetermined |
| <b>Capabilities:</b>                |              |
| <b>Port Changeability:</b>          | Yes          |

---

---

## Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

## Notes for the Device