
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Projector
Manufacturer: Christie
Firmware Version: N/A
Model(s): CP4230, CP42LH, CP4325-RGB, CP4220

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.00.0000-b022	2.0.0

Version History

Module Version	Date	Notes
1_0_0_0	10/31/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- CommunityString variable must be set accordingly to operate via SNMP (v2C). Default value is 'public'.
CommunityString must match the device's setting.
Example: `InterfaceName.CommunityString = 'public'`
- This module supports status only. Set commands are unavailable.

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 161, Model='CP4230')</code>

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command Active3DFile	Qualifier Value 'String'
# Active3DFile examples InterfaceName.Update('Active3DFile') Value = InterfaceName.ReadStatus('Active3DFile') InterfaceName.SubscribeStatus('Active3DFile', None, FeedbackHandler)	
Command ActiveChannelFile	Qualifier Value 'String'
# ActiveChannelFile examples InterfaceName.Update('ActiveChannelFile') Value = InterfaceName.ReadStatus('ActiveChannelFile') InterfaceName.SubscribeStatus('ActiveChannelFile', None, FeedbackHandler)	
Command ActiveCLUTFile	Qualifier Value 'String'
# ActiveCLUTFile examples InterfaceName.Update('ActiveCLUTFile') Value = InterfaceName.ReadStatus('ActiveCLUTFile') InterfaceName.SubscribeStatus('ActiveCLUTFile', None, FeedbackHandler)	
Command ActiveCSCFile	Qualifier Value 'String'
# ActiveCSCFile examples InterfaceName.Update('ActiveCSCFile') Value = InterfaceName.ReadStatus('ActiveCSCFile') InterfaceName.SubscribeStatus('ActiveCSCFile', None, FeedbackHandler)	
Command ActiveDegammaFile	Qualifier Value 'String'
# ActiveDegammaFile examples InterfaceName.Update('ActiveDegammaFile') Value = InterfaceName.ReadStatus('ActiveDegammaFile') InterfaceName.SubscribeStatus('ActiveDegammaFile', None, FeedbackHandler)	

Global Scripter Module Communication Sheet

Revision: 10/31/2018

Command ActiveEDIDFile	Qualifier Value 'String'
<pre># ActiveEDIDFile examples InterfaceName.Update('ActiveEDIDFile') Value = InterfaceName.ReadStatus('ActiveEDIDFile') InterfaceName.SubscribeStatus('ActiveEDIDFile', None, FeedbackHandler)</pre>	
Command ActiveILSFile	Qualifier Value 'String'
<pre># ActiveILSFile examples InterfaceName.Update('ActiveILSFile') Value = InterfaceName.ReadStatus('ActiveILSFile') InterfaceName.SubscribeStatus('ActiveILSFile', None, FeedbackHandler)</pre>	
Command ActiveMCGDLeftFile	Qualifier Value 'String'
<pre># ActiveMCGDLeftFile examples InterfaceName.Update('ActiveMCGDLeftFile') Value = InterfaceName.ReadStatus('ActiveMCGDLeftFile') InterfaceName.SubscribeStatus('ActiveMCGDLeftFile', None, FeedbackHandler)</pre>	
Command ActiveMCGDRightFile	Qualifier Value 'String'
<pre># ActiveMCGDRightFile examples InterfaceName.Update('ActiveMCGDRightFile') Value = InterfaceName.ReadStatus('ActiveMCGDRightFile') InterfaceName.SubscribeStatus('ActiveMCGDRightFile', None, FeedbackHandler)</pre>	
Command ActiveScreenFile	Qualifier Value 'String'
<pre># ActiveScreenFile examples InterfaceName.Update('ActiveScreenFile') Value = InterfaceName.ReadStatus('ActiveScreenFile') InterfaceName.SubscribeStatus('ActiveScreenFile', None, FeedbackHandler)</pre>	
Command ActiveSourceFile	Qualifier Value 'String'
<pre># ActiveSourceFile examples InterfaceName.Update('ActiveSourceFile') Value = InterfaceName.ReadStatus('ActiveSourceFile') InterfaceName.SubscribeStatus('ActiveSourceFile', None, FeedbackHandler)</pre>	
Command ActiveTCGDFile	Qualifier Value 'String'
<pre># ActiveTCGDFile examples InterfaceName.Update('ActiveTCGDFile') Value = InterfaceName.ReadStatus('ActiveTCGDFile') InterfaceName.SubscribeStatus('ActiveTCGDFile', None, FeedbackHandler)</pre>	
Command ActiveWarpFile	Qualifier Value 'String'
<pre># ActiveWarpFile examples InterfaceName.Update('ActiveWarpFile')</pre>	

Global Scripter Module Communication Sheet

Revision: 10/31/2018

Value = InterfaceName.ReadStatus('ActiveWarpFile') InterfaceName.SubscribeStatus('ActiveWarpFile', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
CPULoadPercentage	Integer in %	
# CPULoadPercentage examples InterfaceName.Update('CPULoadPercentage') Value = InterfaceName.ReadStatus('CPULoadPercentage') InterfaceName.SubscribeStatus('CPULoadPercentage', None, FeedbackHandler)		
Command	Value	Value
CSenseBoardOnline	'True'	'False'
# CSenseBoardOnline examples InterfaceName.Update('CSenseBoardOnline') Value = InterfaceName.ReadStatus('CSenseBoardOnline') InterfaceName.SubscribeStatus('CSenseBoardOnline', None, FeedbackHandler)		
Command	Value	Value
Dolby3DSystem	'Enabled'	'Disabled'
# Dolby3DSystem examples InterfaceName.Update('Dolby3DSystem') Value = InterfaceName.ReadStatus('Dolby3DSystem') InterfaceName.SubscribeStatus('Dolby3DSystem', None, FeedbackHandler)		
Command	Value	
FreeMemorySpace	Integer in MB	
# FreeMemorySpace examples InterfaceName.Update('FreeMemorySpace') Value = InterfaceName.ReadStatus('FreeMemorySpace') InterfaceName.SubscribeStatus('FreeMemorySpace', None, FeedbackHandler)		
Command	Value	
FreePrimaryDiskSpace	Integer in MB	
# FreePrimaryDiskSpace examples InterfaceName.Update('FreePrimaryDiskSpace') Value = InterfaceName.ReadStatus('FreePrimaryDiskSpace') InterfaceName.SubscribeStatus('FreePrimaryDiskSpace', None, FeedbackHandler)		
Command	Qualifier Value	
LvpsStatusDescription	'String'	
Qualifier Key	Qualifier Value	
'ID'	'1' – '10'	
# LvpsStatusDescription examples InterfaceName.Update('LvpsStatusDescription', {'ID': '1'}) Value = InterfaceName.ReadStatus('LvpsStatusDescription', {'ID': '1'}) InterfaceName.SubscribeStatus('LvpsStatusDescription', None, FeedbackHandler)		

Global Scripter Module Communication Sheet

Revision: 10/31/2018

Command LvpsStatusValue	Qualifier Value 'String'	
Qualifier Key 'ID'	Qualifier Value '1' – '10'	
<pre># LvpsStatusValue examples InterfaceName.Update('LvpsStatusValue', {'ID': '1'}) Value = InterfaceName.ReadStatus('LvpsStatusValue', {'ID': '1'}) InterfaceName.SubscribeStatus('LvpsStatusValue', None, FeedbackHandler)</pre>		
Command MarriageRingTamper	Qualifier Value 'String'	
<pre># MarriageRingTamper examples InterfaceName.Update('MarriageRingTamper') Value = InterfaceName.ReadStatus('MarriageRingTamper') InterfaceName.SubscribeStatus('MarriageRingTamper', None, FeedbackHandler)</pre>		
Command NewDrive	Value 'Detected'	Value 'Undetected'
<pre># NewDrive examples InterfaceName.Update('NewDrive') Value = InterfaceName.ReadStatus('NewDrive') InterfaceName.SubscribeStatus('NewDrive', None, FeedbackHandler)</pre>		
Command NumberOfConfiguredDASDevices	Value Integer	
<pre># NumberOfConfiguredDASDevices examples InterfaceName.Update('NumberOfConfiguredDASDevices') Value = InterfaceName.ReadStatus('NumberOfConfiguredDASDevices') InterfaceName.SubscribeStatus('NumberOfConfiguredDASDevices', None, FeedbackHandler)</pre>		
Command NumberOfConfiguredNASDevices	Value Integer	
<pre># NumberOfConfiguredNASDevices examples InterfaceName.Update('NumberOfConfiguredNASDevices') Value = InterfaceName.ReadStatus('NumberOfConfiguredNASDevices') InterfaceName.SubscribeStatus('NumberOfConfiguredNASDevices', None, FeedbackHandler)</pre>		
Command NumberOfContentDrives	Value Integer	
<pre># NumberOfContentDrives examples InterfaceName.Update('NumberOfContentDrives') Value = InterfaceName.ReadStatus('NumberOfContentDrives') InterfaceName.SubscribeStatus('NumberOfContentDrives', None, FeedbackHandler)</pre>		
Command NumberOfIngestDrives	Value Integer	
<pre># NumberOfIngestDrives examples InterfaceName.Update('NumberOfIngestDrives') Value = InterfaceName.ReadStatus('NumberOfIngestDrives') InterfaceName.SubscribeStatus('NumberOfIngestDrives', None, FeedbackHandler)</pre>		
Command	Qualifier Value	

Global Scripter Module Communication Sheet

Revision: 10/31/2018

PhysicalSecurityEnclosureTamper	'String'		
# PhysicalSecurityEnclosureTamper examples InterfaceName.Update('PhysicalSecurityEnclosureTamper') Value = InterfaceName.ReadStatus('PhysicalSecurityEnclosureTamper') InterfaceName.SubscribeStatus('PhysicalSecurityEnclosureTamper', None, FeedbackHandler)			
Command	Value		
PlayBackAudioBufferPercentage	Integer in %		
# PlayBackAudioBufferPercentage examples InterfaceName.Update('PlayBackAudioBufferPercentage') Value = InterfaceName.ReadStatus('PlayBackAudioBufferPercentage') InterfaceName.SubscribeStatus('PlayBackAudioBufferPercentage', None, FeedbackHandler)			
Command	Value		
PlayBackAudioDelayInMilliseconds	Integer in steps of 1ms		
# PlayBackAudioDelayInMilliseconds examples InterfaceName.Update('PlayBackAudioDelayInMilliseconds') Value = InterfaceName.ReadStatus('PlayBackAudioDelayInMilliseconds') InterfaceName.SubscribeStatus('PlayBackAudioDelayInMilliseconds', None, FeedbackHandler)			
Command	Value	Value	Value
PlayBackAudioSampleRate	'Auto'	'48k'	'96k'
# PlayBackAudioSampleRate examples InterfaceName.Update('PlayBackAudioSampleRate') Value = InterfaceName.ReadStatus('PlayBackAudioSampleRate') InterfaceName.SubscribeStatus('PlayBackAudioSampleRate', None, FeedbackHandler)			
Command	Value	Value	
PlayBackBufferUnderrunError	'True'	'False'	
# PlayBackBufferUnderrunError examples InterfaceName.Update('PlayBackBufferUnderrunError') Value = InterfaceName.ReadStatus('PlayBackBufferUnderrunError') InterfaceName.SubscribeStatus('PlayBackBufferUnderrunError', None, FeedbackHandler)			
Command	Value	Value	
PlayBackContentProcessingError	'True'	'False'	
# PlayBackContentProcessingError examples InterfaceName.Update('PlayBackContentProcessingError') Value = InterfaceName.ReadStatus('PlayBackContentProcessingError') InterfaceName.SubscribeStatus('PlayBackContentProcessingError', None, FeedbackHandler)			
Command	Value		
PlayBackCurrentCPLOffsetInMillisec onds	Integer in steps of 1 ms		
# PlayBackCurrentCPLOffsetInMilliseconds examples InterfaceName.Update('PlayBackCurrentCPLOffsetInMilliseconds') Value = InterfaceName.ReadStatus('PlayBackCurrentCPLOffsetInMilliseconds') InterfaceName.SubscribeStatus('PlayBackCurrentCPLOffsetInMilliseconds', None, FeedbackHandler)			
Command	Qualifier Value		
PlayBackCurrentCPLUID	'String'		
# PlayBackCurrentCPLUID examples			

Global Scripter Module Communication Sheet

Revision: 10/31/2018

InterfaceName.Update('PlayBackCurrentCPLUUID') Value = InterfaceName.ReadStatus('PlayBackCurrentCPLUUID') InterfaceName.SubscribeStatus('PlayBackCurrentCPLUUID', None, FeedbackHandler)			
Command PlayBackDolbyConfigFile	Qualifier Value 'String'		
# PlayBackDolbyConfigFile examples InterfaceName.Update('PlayBackDolbyConfigFile') Value = InterfaceName.ReadStatus('PlayBackDolbyConfigFile') InterfaceName.SubscribeStatus('PlayBackDolbyConfigFile', None, FeedbackHandler)			
Command PlayBackDurationInSeconds	Value Integer in steps of 1 sec		
# PlayBackDurationInSeconds examples InterfaceName.Update('PlayBackDurationInSeconds') Value = InterfaceName.ReadStatus('PlayBackDurationInSeconds') InterfaceName.SubscribeStatus('PlayBackDurationInSeconds', None, FeedbackHandler)			
Command PlayBackLoadedContentUUID	Qualifier Value 'String'		
# PlayBackLoadedContentUUID examples InterfaceName.Update('PlayBackLoadedContentUUID') Value = InterfaceName.ReadStatus('PlayBackLoadedContentUUID') InterfaceName.SubscribeStatus('PlayBackLoadedContentUUID', None, FeedbackHandler)			
Command PlayBackLoadedStage	Value 'Prep Assets' 'Loaded'	Value 'Security' None	Value 'Prep Subtitles'
# PlayBackLoadedStage examples InterfaceName.Update('PlayBackLoadedStage') Value = InterfaceName.ReadStatus('PlayBackLoadedStage') InterfaceName.SubscribeStatus('PlayBackLoadedStage', None, FeedbackHandler)			
Command PlayBackLoadedState	Value 'loadSuccess' 'loadErrorCplIssue' 'loadErrorNotMarried' 'loadErrorIdNotFound' 'loadErrorCplIssue' 'loadErrorContentIssue' 'loadErrorValidate' 'loadErrorKdmMissing' 'loadErrorHfrLicenseReq uired'	Value 'loadErrorContentCurre ntlyLoaded' 'loadErrorCplIValidate' 'loadErrorContentCurre ntlyLoaded' 'loadErrorKeyNotFound' 'loadErrorCplIValidate' 'loadErrorSmFatal' 'loadErrorPrepSuite' 'loadErrorAssetsHashFai lure' 'loadErrorTdl'	Value 'loadErrorContentNotLo aded' 'loadSuccess' 'loadErrorContentNotLo aded' 'loadErrorPlayOk' 'loadErrorKdmValidate' 'loadErrorSmIssue' 'loadErrorMissingAssets' 'loadErrorPrepFailure' 'loadErrorKdmHasExpire d'

Global Scripter Module Communication Sheet

Revision: 10/31/2018

'loadErrorKdmNotYetValid'	'loadErrorKdmExtendBeyond6Hours'	'loadErrorRemoveSlaveOffline'
'loadErrorRemoveSlaveLoadFailure'	'loadErrorNoValidKdms'	'loadErrorCplNoError'
'loadErrorCplNotWellFormatted'	'loadErrorCplIntegrityValidationError'	'loadErrorCplSignatureValidationError'
'loadErrorCplSchemaValidationError'	'loadErrorCplCertificateValidationError'	'loadErrorCplLogValidationError'
'loadErrorCplUnspecifiedError'	'loadErrorKdmNoError'	'loadErrorKdmNotWellFormatted'
'loadErrorKdmIntegrityValidationError'	'loadErrorKdmSignatureValidationError'	'loadErrorKdmSchemaValidationError'
'loadErrorKdmCertificateValidationError'	'loadErrorKdmAdditionalValidationError'	'loadErrorKdmLogValidationError'
'loadErrorKdmStructureInvalid'	'loadErrorKdmValidationError'	'loadErrorKdmUnspecifiedError'
'loadErrorPlayOkNoError'	'loadErrorPlayOkCplNotValidated'	'loadErrorPlayOkCplValidationError'
'loadErrorPlayOkKdmNotValidated'	'loadErrorPlayOkPlayNotAllowed'	'loadErrorPlayOkTdValidationError'
'loadErrorPlayOkUnableToContactProjector'	'loadErrorPlayOkKeyMissing'	'loadErrorPlayOkCrossCheckError'
'loadErrorPlayOkLogPlayOkError'	'loadErrorPlayOkPlayOkNotAllowedInCurrentState'	'loadErrorPlayOkPlayOkRspbNotInTd'
'loadErrorPlayOkAssetHashError'	'loadErrorPlayOkAssetMissing'	'loadErrorPlayOkKeyTypeInconsistent'
'loadErrorPlayOkProjectorTypeInconsistent'	'loadErrorPlayOkMarriageStateUnknown'	'loadErrorPlayOkPlayOkKdmHasExpired'
'loadErrorPlayOkUnspecifiedError'	'loadErrorPrepSuiteNoError'	'loadErrorPrepSuiteCplNotAllowedPlay'
'loadErrorPrepSuiteKeysExpired'	'loadErrorPrepSuiteTdValidationError'	'loadErrorPrepSuiteProjectorDisconnected'
'loadErrorPrepSuiteKeysNotYetValid'	'loadErrorPrepSuiteSetLinkToSmError'	'loadErrorPrepSuiteKeysExtendBeyondSixHours'
'loadErrorPrepSuiteLoadContentKeysError'	'loadErrorPrepSuiteLogPrepSuiteFailed'	'loadErrorPrepSuiteCmdNotAllowedRightNow'
'loadErrorPrepSuiteAssetHashError'	'loadErrorPrepSuiteAssetMissing'	'loadErrorPrepSuiteUnexpectedError'

Global Scripter Module Communication Sheet

Revision: 10/31/2018

	'loadErrorPrepSuiteRspb LogUploadError'	'loadErrorPrepSuiteSetF mToSmError'	'loadErrorPrepSuiteCros sCheckError'
	'loadErrorPrepSuiteCplN otFound'	'loadErrorPrepSuiteUns pecifiedError'	'loadErrorMarriageNoEr ror'
	'loadErrorMarriageNotA llowedWhilePlaying'	'loadErrorMarriageFaile dToComplete'	'loadErrorMarriageFaile dAuthentication'
	'loadErrorMarriageUnsp ecifiedError'	'loadErrorPurgeSuiteNo Error'	'loadErrorPurgeSuitePur gePackagesError'
	'loadErrorPurgeSuiteCle arLeKeyError'	'loadErrorPurgeSuiteUn specifiedError'	
<pre># PlayBackLoadedState examples InterfaceName.Update('PlayBackLoadedState') Value = InterfaceName.ReadStatus('PlayBackLoadedState') InterfaceName.SubscribeStatus('PlayBackLoadedState', None, FeedbackHandler)</pre>			
Command PlayBackLoopMode	Value 'Enabled'	Value 'Disabled'	
<pre># PlayBackLoopMode examples InterfaceName.Update('PlayBackLoopMode') Value = InterfaceName.ReadStatus('PlayBackLoopMode') InterfaceName.SubscribeStatus('PlayBackLoopMode', None, FeedbackHandler)</pre>			
Command PlayBackRealDConfigFile	Qualifier Value 'String'		
<pre># PlayBackRealDConfigFile examples InterfaceName.Update('PlayBackRealDConfigFile') Value = InterfaceName.ReadStatus('PlayBackRealDConfigFile') InterfaceName.SubscribeStatus('PlayBackRealDConfigFile', None, FeedbackHandler)</pre>			
Command PlayBackState	Value 'Stop'	Value 'Play'	Value 'Pause'
<pre># PlayBackState examples InterfaceName.Update('PlayBackState') Value = InterfaceName.ReadStatus('PlayBackState') InterfaceName.SubscribeStatus('PlayBackState', None, FeedbackHandler)</pre>			
Command PlayBackTimeInSeconds	Value Integer in steps of 1 sec		
<pre># PlayBackTimeInSeconds examples InterfaceName.Update('PlayBackTimeInSeconds') Value = InterfaceName.ReadStatus('PlayBackTimeInSeconds') InterfaceName.SubscribeStatus('PlayBackTimeInSeconds', None, FeedbackHandler)</pre>			
Command PlayBackVideoBufferPercentage	Value Integer in %		
<pre># PlayBackVideoBufferPercentage examples InterfaceName.Update('PlayBackVideoBufferPercentage') Value = InterfaceName.ReadStatus('PlayBackVideoBufferPercentage') InterfaceName.SubscribeStatus('PlayBackVideoBufferPercentage', None, FeedbackHandler)</pre>			

Global Scripter Module Communication Sheet

Revision: 10/31/2018

Command	Value	Value
PrimaryDrive	'Available'	'Unavailable'
# PrimaryDrive examples InterfaceName.Update('PrimaryDrive') Value = InterfaceName.ReadStatus('PrimaryDrive') InterfaceName.SubscribeStatus('PrimaryDrive', None, FeedbackHandler)		
Command	Value	Value
RealD3DEQ	'Enabled'	'Disabled'
# RealD3DEQ examples InterfaceName.Update('RealD3DEQ') Value = InterfaceName.ReadStatus('RealD3DEQ') InterfaceName.SubscribeStatus('RealD3DEQ', None, FeedbackHandler)		
Command	Qualifier Value	
SelectedIMBType	'String'	
# SelectedIMBType examples InterfaceName.Update('SelectedIMBType') Value = InterfaceName.ReadStatus('SelectedIMBType') InterfaceName.SubscribeStatus('SelectedIMBType', None, FeedbackHandler)		
Command	Qualifier Value	
ServiceDoorTamper	'String'	
# ServiceDoorTamper examples InterfaceName.Update('ServiceDoorTamper') Value = InterfaceName.ReadStatus('ServiceDoorTamper') InterfaceName.SubscribeStatus('ServiceDoorTamper', None, FeedbackHandler)		
Command	Qualifier Value	
SMAAlgorithmIntegrity	'String'	
# SMAAlgorithmIntegrity examples InterfaceName.Update('SMAAlgorithmIntegrity') Value = InterfaceName.ReadStatus('SMAAlgorithmIntegrity') InterfaceName.SubscribeStatus('SMAAlgorithmIntegrity', None, FeedbackHandler)		
Command	Qualifier Value	
SMBatteryEvent	'String'	
# SMBatteryEvent examples InterfaceName.Update('SMBatteryEvent') Value = InterfaceName.ReadStatus('SMBatteryEvent') InterfaceName.SubscribeStatus('SMBatteryEvent', None, FeedbackHandler)		
Command	Qualifier Value	
SMBatteryLow	'String'	
# SMBatteryLow examples InterfaceName.Update('SMBatteryLow') Value = InterfaceName.ReadStatus('SMBatteryLow') InterfaceName.SubscribeStatus('SMBatteryLow', None, FeedbackHandler)		
Command	Value	Value
SMConnection	'Secure'	'Unsecure'
# SMConnection examples InterfaceName.Update('SMConnection')		

Global Scripter Module Communication Sheet

Revision: 10/31/2018

<pre>Value = InterfaceName.ReadStatus('SMConnection') InterfaceName.SubscribeStatus('SMConnection', None, FeedbackHandler)</pre>		
Command	Value	Value
SMConnectionStatus	'Connected'	'Disconnected'
<pre># SMConnectionStatus examples InterfaceName.Update('SMConnectionStatus') Value = InterfaceName.ReadStatus('SMConnectionStatus') InterfaceName.SubscribeStatus('SMConnectionStatus', None, FeedbackHandler)</pre>		
Command	Value	Value
SMCryptoState	'Ok'	'Failed'
<pre># SMCryptoState examples InterfaceName.Update('SMCryptoState') Value = InterfaceName.ReadStatus('SMCryptoState') InterfaceName.SubscribeStatus('SMCryptoState', None, FeedbackHandler)</pre>		
Command	Qualifier Value	
SMImageIntegrity	'String'	
<pre># SMImageIntegrity examples InterfaceName.Update('SMImageIntegrity') Value = InterfaceName.ReadStatus('SMImageIntegrity') InterfaceName.SubscribeStatus('SMImageIntegrity', None, FeedbackHandler)</pre>		
Command	Qualifier Value	
SMLogSpaceWarning	'String'	
<pre># SMLogSpaceWarning examples InterfaceName.Update('SMLogSpaceWarning') Value = InterfaceName.ReadStatus('SMLogSpaceWarning') InterfaceName.SubscribeStatus('SMLogSpaceWarning', None, FeedbackHandler)</pre>		
Command	Qualifier Value	
SMMarriage	'String'	
<pre># SMMarriage examples InterfaceName.Update('SMMarriage') Value = InterfaceName.ReadStatus('SMMarriage') InterfaceName.SubscribeStatus('SMMarriage', None, FeedbackHandler)</pre>		
Command	Qualifier Value	
SMSecurityLogStatus	'String'	
<pre># SMSecurityLogStatus examples InterfaceName.Update('SMSecurityLogStatus') Value = InterfaceName.ReadStatus('SMSecurityLogStatus') InterfaceName.SubscribeStatus('SMSecurityLogStatus', None, FeedbackHandler)</pre>		
Command	Qualifier Value	
SMTamper	'String'	
<pre># SMTamper examples InterfaceName.Update('SMTamper') Value = InterfaceName.ReadStatus('SMTamper') InterfaceName.SubscribeStatus('SMTamper', None, FeedbackHandler)</pre>		
Command	Qualifier Value	

Global Scripter Module Communication Sheet

Revision: 10/31/2018

SMZeroization	'String'	
# SMZeroization examples InterfaceName.Update('SMZeroization') Value = InterfaceName.ReadStatus('SMZeroization') InterfaceName.SubscribeStatus('SMZeroization', None, FeedbackHandler)		
Command	Qualifier Value	
StorageActivePath	'String'	
# StorageActivePath examples InterfaceName.Update('StorageActivePath') Value = InterfaceName.ReadStatus('StorageActivePath') InterfaceName.SubscribeStatus('StorageActivePath', None, FeedbackHandler)		
Command	Value	Value
SystemDouser	'Open'	'Close'
# SystemDouser examples InterfaceName.Update('SystemDouser') Value = InterfaceName.ReadStatus('SystemDouser') InterfaceName.SubscribeStatus('SystemDouser', None, FeedbackHandler)		
Command	Value	Value
SystemLightSource	'On'	'Off'
# SystemLightSource examples InterfaceName.Update('SystemLightSource') Value = InterfaceName.ReadStatus('SystemLightSource') InterfaceName.SubscribeStatus('SystemLightSource', None, FeedbackHandler)		
Command	Qualifier Value	
TemperatureSensorLocation	'String'	
Qualifier Key	Qualifier Value	
'Sensor ID'	'1' – '10'	
# TemperatureSensorLocation examples InterfaceName.Update('TemperatureSensorLocation', {'Sensor ID': '1'}) Value = InterfaceName.ReadStatus('TemperatureSensorLocation', {'Sensor ID': '1'}) InterfaceName.SubscribeStatus('TemperatureSensorLocation', None, FeedbackHandler)		
Command	Qualifier Value	
TemperatureSensorValue	'String'	
Qualifier Key	Qualifier Value	
'Sensor ID'	'1' – '10'	
# TemperatureSensorValue examples InterfaceName.Update('TemperatureSensorValue', {'Sensor ID': '1'}) Value = InterfaceName.ReadStatus('TemperatureSensorValue', {'Sensor ID': '1'}) InterfaceName.SubscribeStatus('TemperatureSensorValue', None, FeedbackHandler)		
Command	Value	
TotalMemorySpace	Value	
# TotalMemorySpace examples InterfaceName.Update('TotalMemorySpace') Value = InterfaceName.ReadStatus('TotalMemorySpace') InterfaceName.SubscribeStatus('TotalMemorySpace', None, FeedbackHandler)		

Global Scripter Module Communication Sheet

Command	Value
TotalPrimaryDiskSpace	Integer in MB
# TotalPrimaryDiskSpace examples InterfaceName.Update('TotalPrimaryDiskSpace') Value = InterfaceName.ReadStatus('TotalPrimaryDiskSpace') InterfaceName.SubscribeStatus('TotalPrimaryDiskSpace', None, FeedbackHandler)	
Command	Value
TotalRootDiskSpace	Integer in MB
# TotalRootDiskSpace examples InterfaceName.Update('TotalRootDiskSpace') Value = InterfaceName.ReadStatus('TotalRootDiskSpace') InterfaceName.SubscribeStatus('TotalRootDiskSpace', None, FeedbackHandler)	
Command	Value
UsedRootDiskSpace	Integer in MB
# UsedRootDiskSpace examples InterfaceName.Update('UsedRootDiskSpace') Value = InterfaceName.ReadStatus('UsedRootDiskSpace') InterfaceName.SubscribeStatus('UsedRootDiskSpace', None, FeedbackHandler)	

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	161
Logon Credentials Supported:	No
Multi-Connection Capabilities:	No
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication. This module is based on SNMP Protocol.

Notes for the Device