

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Projector
Manufacturer: Christie
Firmware Version: N/A
Model(s): Vivid LX33, Vivid LX41, Vivid LW25

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.00.0000-b022	2.0.0

Version History

Module Version	Date	Notes
1_0_0_0	10/16/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Classes and Examples

SerialClass
<code>InterfaceName = ModuleName.SerialClass(ProcessorName, 'COM1', Model='Vivid LX33')</code>
SerialOverEthernetClass
<code>InterfaceName = ModuleName.SerialOverEthernetClass('192.168.254.254', 2001, Model='Vivid LX33')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AspectRatio	Value 'Normal'	Value 'Wide'	
# AspectRatio example InterfaceName.Set('AspectRatio', 'Normal')			
Command AudioMute	Value 'On'	Value 'Off'	
# AudioMute example InterfaceName.Set('AudioMute', 'On')			
Command AutoImage	Value None		
# AutoImage example InterfaceName.Set('AutoImage', None)			
Command Focus	Value 'Far'	Value 'Near'	
# Focus example InterfaceName.Set('Focus', 'Far')			
Command Freeze	Value 'On'	Value 'Off'	
# Freeze example InterfaceName.Set('Freeze', 'On')			
Command Input	Value 'Input 1 Digital' 'Input 2 YPBPR' 'Input 3 S-Video'	Value 'Input 1 Analog' 'Input 2 Analog' 'Input 3 YPBPR'	Value 'Input 2 Video' 'Input 3 Video'
# Input example InterfaceName.Set('Input', 'Input 1 Digital')			
Command LampMode	Value 'Eco'	Value 'Normal'	
# LampMode example InterfaceName.Set('LampMode', 'Eco')			
Command MenuNavigation	Value 'On' 'Left' 'Off'	Value 'Up' 'Right'	Value 'Down' 'Enter'

Global Scripter Module Communication Sheet

# MenuNavigation example InterfaceName.Set('MenuNavigation', 'On')		
Command Power	Value 'On'	Value 'Off'
# Power example InterfaceName.Set('Power', 'On')		
Command VideoMute	Value 'On'	Value 'Off'
# VideoMute example InterfaceName.Set('VideoMute', 'On')		
Command Volume	Value 0 to 63 in steps of 1	
# Volume example InterfaceName.Set('Volume', 63)		
Command Zoom	Value 'In'	Value 'Out'
# Zoom example InterfaceName.Set('Zoom', 'In')		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus do not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
AspectRatio	'Normal'	'Wide'	
# AspectRatio examples InterfaceName.Update('AspectRatio') Value = InterfaceName.ReadStatus('AspectRatio') InterfaceName.SubscribeStatus('AspectRatio', None, FeedbackHandler)			
Command	Value	Value	
AudioMute	'On'	'Off'	
# AudioMute examples InterfaceName.Update('AudioMute') Value = InterfaceName.ReadStatus('AudioMute') InterfaceName.SubscribeStatus('AudioMute', None, FeedbackHandler)			
Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	Value
DeviceStatus ¹	'Temp Warning & Recovered'	'Normal'	'Cooling Down (Abnormal Temp)'
	'Power Save (Cooling Down)'	'Power Failure'	'Power Save'
	'Countdown in Process'	'Cooling Down in Process'	'No Key Input'
	'Temp Warning (Power On)'		
# DeviceStatus examples InterfaceName.Update('DeviceStatus') Value = InterfaceName.ReadStatus('DeviceStatus') InterfaceName.SubscribeStatus('DeviceStatus', None, FeedbackHandler)			

Global Scripter Module Communication Sheet

Command Freeze	Value 'On'	Value 'Off'	
<pre># Freeze examples InterfaceName.Update('Freeze') Value = InterfaceName.ReadStatus('Freeze') InterfaceName.SubscribeStatus('Freeze', None, FeedbackHandler)</pre>			
Command Input	Value 'Input 1 Digital'	Value 'Input 1 Analog'	Value 'Input 2 Video'
	'Input 2 YPBPR'	'Input 2 Analog'	'Input 3 Video'
	'Input 3 S-Video'	'Input 3 YPBPR'	
<pre># Input examples InterfaceName.Update('Input') Value = InterfaceName.ReadStatus('Input') InterfaceName.SubscribeStatus('Input', None, FeedbackHandler)</pre>			
Command LampMode	Value 'Eco'	Value 'Normal'	
<pre># LampMode examples InterfaceName.Update('LampMode') Value = InterfaceName.ReadStatus('LampMode') InterfaceName.SubscribeStatus('LampMode', None, FeedbackHandler)</pre>			
Command LampUsage	Value Hours		
<pre># LampUsage examples InterfaceName.Update('LampUsage') Value = InterfaceName.ReadStatus('LampUsage') InterfaceName.SubscribeStatus('LampUsage', None, FeedbackHandler)</pre>			
Command OperationHours	Value Hours		
<pre># OperationHours examples InterfaceName.Update('OperationHours') Value = InterfaceName.ReadStatus('OperationHours') InterfaceName.SubscribeStatus('OperationHours', None, FeedbackHandler)</pre>			
Command Power ¹	Value 'On'	Value 'Off'	Value 'Cooling Down'
	'Warming Up'		
<pre># Power examples InterfaceName.Update('Power') Value = InterfaceName.ReadStatus('Power') InterfaceName.SubscribeStatus('Power', None, FeedbackHandler)</pre>			
Command VideoMute	Value 'On'	Value 'Off'	
<pre># VideoMute examples InterfaceName.Update('VideoMute') Value = InterfaceName.ReadStatus('VideoMute') InterfaceName.SubscribeStatus('VideoMute', None, FeedbackHandler)</pre>			

Command	Value
Volume	0 to 63 in steps of 1
<pre># Volume examples InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)</pre>	

¹ Calling Update method with any of these commands will provide status for the other commands with this superscript.

Cable and Adapter Requirements

Captive Screw to Female DB9 RS-232 Serial Cable

Notes for the Device

Serial communication

Port Type: RS-232

Baud Rate: 19200

Data Bits: 8

Parity: None

Stop Bits: One

Flow Control: None

Pin Assignments Diagram

Appendix A. Set Commands

Aspect Ratio Normal	CF SCREEN NORMAL\x0D
Aspect Ratio Wide	CF SCREEN WIDE\x0D
Audio Mute Off	C0C\x0D
Audio Mute On	C0B\x0D
Auto Image None	C89\x0D
Focus Far	C4B\x0D
Focus Near	C4A\x0D
Freeze Off	C44\x0D
Freeze On	C43\x0D
Input Input 1 Analog	CF INPUT1 ANALOG\x0D
Input Input 1 Digital	CF INPUT1 DIGITAL\x0D
Input Input 2 Analog	CF INPUT2 ANALOG\x0D
Input Input 2 Video	CF INPUT2 VIDEO\x0D
Input Input 2 YPBPR	CF INPUT2 YPBPR\x0D
Input Input 3 S-Video	CF INPUT3 S-VIDEO\x0D
Input Input 3 Video	CF INPUT3 VIDEO\x0D
Input Input 3 YPBPR	CF INPUT3 YPBPR\x0D
Lamp Mode Eco	CF LAMPMODE ECO\x0D
Lamp Mode Normal	CF LAMPMODE FUL\x0D
Menu Navigation Down	C3D\x0D
Menu Navigation Enter	C3F\x0D
Menu Navigation Left	C3B\x0D
Menu Navigation Off	C1D\x0D
Menu Navigation On	C1C\x0D
Menu Navigation Right	C3A\x0D
Menu Navigation Up	C3C\x0D
Power Off	C01\x0D
Power On	C00\x0D
Video Mute Off	C0E\x0D
Video Mute On	C0D\x0D
Volume 0	CF VOLUME 000\x0D
Volume 63	CF VOLUME 063\x0D
Zoom In	C47\x0D
Zoom Out	C46\x0D

Appendix B. Update Commands

Aspect Ratio	CR SCREEN\x0D
Audio Mute	CR MUTE\x0D
Device Status	CR0\x0D
Freeze	CR FREEZE\x0D
Input	CR INPUT\x0D
Lamp Mode	CR LAMPMODE\x0D
Lamp Usage	CR3\x0D
Operation Hours	CR PROJH\x0D
Power	CR0\x0D
Video Mute	CR VMUTE\x0D
Volume	CR VOLUME\x0D