

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Conference
Manufacturer: Cisco
Firmware Version: CE9.1
Model(s): Spark Room Kit CE9.1.X, Spark Room Kit Plus CE9.1.X

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.08.0001-b006	1.4.2

Version History

Module Version	Date	Notes
1_1_1_0	4/6/2018	Added SSH Support. Removed HTTP support. Added missing camera commands for Spark Room Kit Plus.
1_0_1_0	11/1/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- CallHistoryOccurrenceType variable must be set accordingly. Default value is 'Time'. Call History Occurrence Type ranges from 'Time' and 'Frequency'.
Example: `InterfaceName.CallHistoryOccurrenceType = 'Time'`
- NumberofPhonebookSearch variable must be set accordingly. Default value is 5.
NumberofPhonebookSearch ranges from 1 to 10.
Example: `InterfaceName.NumberofPhonebookSearch = 5`
- NumberofCallHistory variable must be set accordingly. Default value is 5. NumberofCallHistory ranges from 1 to 20.
Example: `InterfaceName.NumberofCallHistory = 5`
- NumberofPhonebookFolderSearch variable must be set accordingly. Default value is 5
NumberofPhonebookFolderSearch ranges from 1 to 10.
Example: `InterfaceName.NumberofPhonebookFolderSearch = 5`
- NumberofPeripheral variable must be set accordingly. Default value is 5 NumberofPeripheral ranges from 1 to 10.
Example: `InterfaceName.NumberofPeripheral = 5`
- NumberofContactsPerSearch variable must be set accordingly. Default value is 50
NumberofContactsPerSearch ranges from 20 to 250.
Example: `InterfaceName.NumberofContactsPerSearch = 50`
- SpeakerTrack: The SpeakerTrack Control command will work only after the SpeakerTrack Mode: Auto command is sent. This command applies only when using a Cisco TelePresence SpeakerTrack 60 camera.

Supported Classes and Examples

SSHClass

#Password required

```
InterfaceName=ModuleName.SSHClass('192.168.254.254', 22, Credentials=('Username','Password'),  
Model='Spark Room Kit CE9.1.X')
```

#No Password required

```
InterfaceName=ModuleName.SSHClass('192.168.254.254', 22, Credentials=('Username',''), Model='Spark  
Room Kit CE9.1.X')
```

Phonebook commands:

- **PhonebookUpdate**
This is used to trigger the Phonebook search.
- **PhonebookSearchResult**
This is where the search results will be saved to when phonebook is searched. The number of results are set by a driver parameter Number of Phonebook Search, this is initialized to 5 results by default. Simply call SetText with the returned result to display the search result on a button or label object.
- **PhonebookNavigation**
This command is used for navigating through the search results. The navigation commands scroll through the results when there are more results than NumberofPhonebookSearch variable.
- **PhonebookSearchSet**
When the number selected in this command is triggered, it will dial the number with the xCommand Dial Number command.
- **PhonebookFolderIDUpdate**
This is used to trigger the Folder search within the Phonebook.
- **PhonebookFolderIDSearchResult**
This is where the search results are saved when PhonebookFolderIDUpdate is called. The number of results displayed is set to 5 by default. Simply call SetText with the returned results to display the results on a button or label object.
- **PhonebookFolderIDSearchSet**
When the Folder Name is selected using this command, it will store the Folder Name in a class variable named FolderIDNumber. This variable can be used in the 'FolderID' qualifier in the PhonebookUpdate command.

Example: `InterfaceName.Set('PhonebookUpdate','Refresh', {'Contact':'','FolderID':
InterfaceName.FolderIDNumber, 'PhonebookType':'Local'})`

Call History commands:

- **CallHistoryRefresh**
This is used to trigger the search for recent Call History based on the CallHistoryOccuranceType class variable.
- **CallHistory**
This is where the search results are saved when CallHistoryRefresh is called. The number of results displayed is set to 5 by default. Simply call SetText to display the results on a button or label object.
- **CallHistoryNavigation**
This command is used for navigating through the CallHistory results.
- **CallHistorySelect**
When the CallHistorySelect is triggered, it will dial the number selected.

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AudioOutput	Value 'On'	Value 'Off'	
Qualifier Key 'Output'	Qualifier Value 'Internal Speaker'	Qualifier Value 'Line'	
# AudioOutput example InterfaceName.Set('AudioOutput', 'On', {'Output': 'Internal Speaker'})			
Command AutoAnswer	Value 'On'	Value 'Off'	
# AutoAnswer example InterfaceName.Set('AutoAnswer', 'On')			
Command CallHistoryNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# CallHistoryNavigation example InterfaceName.Set('CallHistoryNavigation', 'Up')			
Command CallHistoryRefresh	Value None		
# CallHistoryRefresh example InterfaceName.Set('CallHistoryRefresh', None)			
Command CallHistorySelect	Value '1' – '20'		
# CallHistorySelect example InterfaceName.Set('CallHistorySelect', '1')			
Command CallSetupMode	Value 'Gatekeeper'	Value 'Direct'	
# CallSetupMode example InterfaceName.Set('CallSetupMode', 'Gatekeeper')			
Command CameraFocus	Value 'Near'	Value 'Far'	Value 'Stop'
# CameraFocus example InterfaceName.Set('CameraFocus', 'Near')			
Command CameraFocusPlus	Value 'Near'	Value 'Far'	Value 'Stop'
Qualifier Key	Qualifier Value		

Global Scripter Module Communication Sheet

'Camera'	'1' – '7'		
# CameraFocusPlus example InterfaceName.Set('CameraFocusPlus', 'Near', {'Camera': '1'})			
Command CameraPan	Value 'Left'	Value 'Right'	Value 'Stop'
Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraPan example InterfaceName.Set('CameraPan', 'Left', {'Speed': 15})			
Command CameraPanPlus	Value 'Left'	Value 'Right'	Value 'Stop'
Qualifier Key 'Camera'	Qualifier Value '1' – '7'		
Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraPan example InterfaceName.Set('CameraPanPlus', 'Left', {'Camera': '1', 'Speed': 15})			
Command CameraPresetRecall	Value '1' – '35'		
# CameraPresetRecall example InterfaceName.Set('CameraPresetRecall', '1')			
Command CameraPresetSave	Value '1' – '35'		
# CameraPresetSave example InterfaceName.Set('CameraPresetSave', '1')			
Command CameraPresetSavePlus	Value '1' – '35'		
Qualifier Key 'Camera'	Qualifier Value '1' – '7'		
# CameraPresetSavePlus example InterfaceName.Set('CameraPresetSavePlus', '1', {'Camera': '1'})			
Command CameraTiltPlus	Value 'Up'	Value 'Down'	Value 'Stop'
Qualifier Key 'Camera'	Qualifier Value '1' – '7'		
Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraTiltPlus example InterfaceName.Set('CameraTiltPlus', 'Up', {'Camera': '1', 'Speed': 15})			
Command CameraTilt	Value 'Up'	Value 'Down'	Value 'Stop'

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraTilt example InterfaceName.Set('CameraTilt', 'Up', {'Speed': 15})			
Command CameraZoomPlus	Value 'In'	Value 'Out'	Value 'Stop'
Qualifier Key 'Camera'	Qualifier Value '1' – '7'		
Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraZoomPlus example InterfaceName.Set('CameraZoomPlus', 'In', {'Camera': '1', 'Speed': 15})			
Command CameraZoom	Value 'In'	Value 'Out'	Value 'Stop'
Qualifier Key 'Speed'	Qualifier Value 1 to 15 in steps of 1		
# CameraZoom example InterfaceName.Set('CameraZoom', 'In', {'Speed': 15})			
Command ConnectedDeviceNavigation	Value 'Up'	Value 'Down'	Value 'Page Up'
	'Page Down'		
# ConnectedDeviceNavigation example InterfaceName.Set('ConnectedDeviceNavigation', 'Up')			
Command ConnectedDeviceUpdate	Value None		
# ConnectedDeviceUpdate example InterfaceName.Set('ConnectedDeviceUpdate', None)			
Command DisplayMode	Value 'Dual'	Value 'Single'	Value 'Dual Presentation Only'
	'Auto'		
# DisplayMode example InterfaceName.Set('DisplayMode', 'Dual')			
Command DNSDomainNameCommand	Value 'String'		
# DNSDomainNameCommand example InterfaceName.Set('DNSDomainNameCommand', 'String')			
Command DNSServerAddressCommand	Value 'String'		
# DNSServerAddressCommand example InterfaceName.Set('DNSServerAddressCommand', 'String')			

Command DoNotDisturb	Value 'Active'	Value 'Inactive'	
# DoNotDisturb example InterfaceName.Set('DoNotDisturb', 'Active')			
Command DTMF	Value '0' '3' '6' '9'	Value '1' '4' '7' '*'	Value '2' '5' '8' '#'
# DTMF example InterfaceName.Set('DTMF', '0')			
Command FarEndCameraPanTilt	Value 'Up' 'Right'	Value 'Down' 'Stop'	Value 'Left'
# FarEndCameraPanTilt example InterfaceName.Set('FarEndCameraPanTilt', 'Up')			
Command FarEndCameraPresetRecall	Value '1' – '15'		
# FarEndCameraPresetRecall example InterfaceName.Set('FarEndCameraPresetRecall', '1')			
Command FarEndCameraSource	Value '0' – '15'		
# FarEndCameraSource example InterfaceName.Set('FarEndCameraSource', '0')			
Command FarEndCameraZoom	Value 'In'	Value 'Out'	Value 'Stop'
# FarEndCameraZoom example InterfaceName.Set('FarEndCameraZoom', 'In')			
Command FarEndControl	Value 'On'	Value 'Off'	
# FarEndControl example InterfaceName.Set('FarEndControl', 'On')			
Command H323GatekeeperAddressCommand	Value 'String'		
# H323GatekeeperAddressCommand example InterfaceName.Set('H323GatekeeperAddressCommand', 'String')			
Command H323AliasE164Command	Value 'String'		
# H323AliasE164Command example InterfaceName.Set('H323AliasE164Command', 'String')			
Command	Value		

H323AliasIDCommand	'String'		
# H323AliasIDCommand example InterfaceName.Set('H323AliasIDCommand', 'String')			
Command H323ProfileAuthenticationLoginNameCommand	Value 'String'		
# H323ProfileAuthenticationLoginNameCommand example InterfaceName.Set('H323ProfileAuthenticationLoginNameCommand', 'String')			
Command H323ProfileAuthenticationPasswordCommand	Value 'String'		
# H323ProfileAuthenticationPasswordCommand example InterfaceName.Set('H323ProfileAuthenticationPasswordCommand', 'String')			
Command Hook	Value 'Dial' 'Join 2' 'Join 5' 'Hold 3' 'Resume 1' 'Resume 4' 'Disconnect 2' 'Disconnect 5'	Value 'Accept' 'Join 3' 'Hold 1' 'Hold 4' 'Resume 2' 'Resume 5' 'Disconnect 3' 'Reject'	Value 'Join 1' 'Join 4' 'Hold 2' 'Hold 5' 'Resume 3' 'Disconnect 1' 'Disconnect 4'
Qualifier Key 'Number'	Qualifier Value 'String'		
Qualifier Key 'Protocol'	Qualifier Value 'Auto' 'H320'	Qualifier Value 'SIP' 'Spark'	Qualifier Value 'H323'
# Hook example InterfaceName.Set('Hook', 'Accept', {'Protocol': 'Auto'}) InterfaceName.Set('Hook', 'Dial', {'Number': '123', 'Protocol': 'Auto'})			
Command Input	Value '1' – '5'		
# Input example InterfaceName.Set('Input', '1')			
Command InputMicLevel	Value 0 to 24 in steps of 1		
Qualifier Key 'Input'	Qualifier Value 'Microphone 1'	Qualifier Value 'Microphone 2'	
# InputMicLevel example InterfaceName.Set('InputMicLevel', 24, {'Input': 'Microphone 1'})			

Global Scripter Module
Communication Sheet

Revision: 4/6/2018

Command InputMute	Value 'On'	Value 'Off'	
Qualifier Key 'Input'	Qualifier Value 'Internal Microphone'	Qualifier Value 'Microphone 1'	Qualifier Value 'Microphone 2'
# InputMute example InterfaceName.Set('InputMute', 'On', {'Input': 'Internal Microphone'})			
Command IPv4AddressCommand	Value 'String'		
# IPv4AddressCommand example InterfaceName.Set('IPv4AddressCommand', 'String')			
Command IPv4GatewayCommand	Value 'String'		
# IPv4GatewayCommand example InterfaceName.Set('IPv4GatewayCommand', 'String')			
Command IPv4SubnetMaskCommand	Value 'String'		
# IPv4SubnetMaskCommand example InterfaceName.Set('IPv4SubnetMaskCommand', 'String')			
Command IREmulation	Value '0' '3' '6' '9' 'Down' 'F3' 'Grab' 'Left' 'Ok' 'Right' 'Aux' 'PC' 'Up' 'Zoom In' '+' '1' '4' '7' 'C' 'F1' 'F4' 'Home' 'Mute' 'PhoneBook' 'Selfview' 'Camera' 'VCR' 'Volume Down' 'Zoom Out' '_'	Value '1' '4' '7' 'C' 'F1' 'F4' 'Home' 'Mute' 'PhoneBook' 'Selfview' 'Camera' 'VCR' 'Volume Down' 'Zoom Out' '_'	Value '2' '5' '8' 'Call' 'F2' 'F5' 'Layout' 'Mute Mic' 'Presentation' 'Square' 'Doc Cam' '*' 'Volume Up' 'Disconnect'
Qualifier Key 'Key'	Qualifier Value 'Click'	Qualifier Value 'Press'	Qualifier Value 'Release'
# IREmulation example InterfaceName.Set('IREmulation', '0', {'Key': 'Click'})			
Command	Value	Value	Value

Global Scripter Module Communication Sheet

Revision: 4/6/2018

LayoutSet	'Auto'	'Custom'	'Equal'
	'Overlay'	'Prominent'	'Single'
Qualifier Key 'Target'	Qualifier Value 'Local'	Qualifier Value 'Remote'	
# LayoutSet example InterfaceName.Set('LayoutSet', 'Auto', {'Target': 'Local'})			
Command MicrophonesMute	Value 'On'	Value 'Off'	
# MicrophonesMute example InterfaceName.Set('MicrophonesMute', 'On')			
Command PhonebookFolderIDNavigation	Value 'Up'	Value 'Down'	Value 'Page Up'
	'Page Down'		
# PhonebookFolderIDNavigation example InterfaceName.Set('PhonebookFolderIDNavigation', 'Up')			
Command PhonebookFolderIDSearchSet	Value 1 – 10		
# PhonebookFolderIDSearchSet example InterfaceName.Set('PhonebookFolderIDSearchSet', 10)			
Command PhonebookFolderIDUpdate	Value None		
Qualifier Key 'Phonebook Type'	Qualifier Value 'Corporate'	Qualifier Value 'Local'	
# PhonebookFolderIDUpdate example InterfaceName.Set('PhonebookFolderIDUpdate', None, {'Phonebook Type': 'Corporate'})			
Command PhonebookNavigation	Value 'Up'	Value 'Down'	Value 'Page Up'
	'Page Down'		
Qualifier Key 'Contact'	Qualifier Value 'String'		
Qualifier Key 'FolderID'	Qualifier Value 'String'		
Qualifier Key 'Phonebook Type'	Qualifier Value 'Corporate'	Qualifier Value 'Local'	
# PhonebookNavigation example InterfaceName.Set('PhonebookNavigation', 'Up', {'Phonebook Type': 'Local'}) InterfaceName.Set('PhonebookNavigation', 'Up', {'Contact': 'John Doe', 'FolderID': '123', 'Phonebook Type': 'Local'})			
Command	Value		

PhonebookSearchSet	1 – 10		
# PhonebookSearchSet example InterfaceName.Set('PhonebookSearchSet', 10)			
Command PhonebookUpdate	Value 'Refresh'	Value 'Next Search'	Value 'Previous Search'
Qualifier Key 'Contact'	Qualifier Value 'String'		
Qualifier Key 'FolderID'	Qualifier Value 'String'		
Qualifier Key 'Phonebook Type'	Qualifier Value 'Corporate'	Qualifier Value 'Local'	
# PhonebookUpdate example InterfaceName.Set('PhonebookUpdate', 'Refresh', {'Contact': '', 'FolderID': '', 'Phonebook Type': 'Local'}) InterfaceName.Set('PhonebookUpdate', 'Refresh', {'Contact': 'John Doe', 'FolderID': '123', 'Phonebook Type': 'Local'})			
Command Presentation ¹	Value 'Start'	Value 'Stop'	
# Presentation example InterfaceName.Set('Presentation', 'Start')			
Command PresentationSendingMode ¹	Value 'Local and Remote'	Value 'Local Only'	
# PresentationSendingMode example InterfaceName.Set('PresentationSendingMode', 'Local and Remote')			
Command PresetRecall	Value '1' – '15'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command PresetSave	Value '1' – '15'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command Reboot	Value None		
# Reboot example InterfaceName.Set('Reboot', None)			
Command SelfView	Value 'On'	Value 'Off'	
# SelfView example InterfaceName.Set('SelfView', 'On')			
Command	Value 'On'	Value 'Off'	Value 'Current'

SelfViewDefaultFullscreenMode			
# SelfViewDefaultFullscreenMode example InterfaceName.Set('SelfViewDefaultFullscreenMode', 'On')			
Command SelfViewPosition	Value 'Upper Left' 'Center Left' 'Lower Right'	Value 'Upper Center' 'Center Right'	Value 'Upper Right' 'Lower Left'
# SelfViewPosition example InterfaceName.Set('SelfViewPosition', 'Upper Left')			
Command SleepTimer	Value 1 – 480		
# SleepTimer example InterfaceName.Set('SleepTimer', 480)			
Command SpeakerTrackControl	Value 'On'	Value 'Off'	
# SpeakerTrackControl example InterfaceName.Set('SpeakerTrackControl', 'On')			
Command SpeakerTrackMode	Value 'Auto'	Value 'Off'	
# SpeakerTrackMode example InterfaceName.Set('SpeakerTrackMode', 'Auto')			
Command Standby	Value 'Activate'	Value 'Deactivate'	
# Standby example InterfaceName.Set('Standby', 'Activate')			
Command Volume	Value 0 to 100 in steps of 1		
# Volume example InterfaceName.Set('Volume', 100)			

¹ Requires to be in an active call to work

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, and Volume do not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command AudioOutput	Value 'On'	Value 'Off'
Qualifier Key 'Output'	Qualifier Value 'Internal Speaker'	Qualifier Value 'Line'
# AudioOutput examples InterfaceName.Update('AudioOutput', {'Output': 'Internal Speaker'}) Value = InterfaceName.ReadStatus('AudioOutput', {'Output': 'Internal Speaker'}) InterfaceName.SubscribeStatus('AudioOutput', None, FeedbackHandler)		
Command AutoAnswer	Value 'On'	Value 'Off'
# AutoAnswer examples InterfaceName.Update('AutoAnswer') Value = InterfaceName.ReadStatus('AutoAnswer') InterfaceName.SubscribeStatus('AutoAnswer', None, FeedbackHandler)		
Command CallHistory	Value 'String'	
Qualifier Key 'Button'	Qualifier Value '1' – '20'	
Qualifier Key 'Detail Type'	Qualifier Value 'Display Name' 'Occurrence Count'	Qualifier Value 'Callback Number' 'Occurrence Type'
# CallHistory examples InterfaceName.Update('CallHistory', {'Button': '1', 'Detail Type': 'Display Name'}) Value = InterfaceName.ReadStatus('CallHistory', {'Button': '1', 'Detail Type': 'Display Name'}) InterfaceName.SubscribeStatus('CallHistory', None, FeedbackHandler)		
Command CallSetupMode	Value 'Gatekeeper'	Value 'Direct'
# CallSetupMode examples		

Global Scripter Module Communication Sheet

Revision: 4/6/2018

<pre>InterfaceName.Update('CallSetupMode') Value = InterfaceName.ReadStatus('CallSetupMode') InterfaceName.SubscribeStatus('CallSetupMode', None, FeedbackHandler)</pre>			
Command CallStatus	Value 'Dialing' 'Ringing' 'On Hold' 'Remote Preserved'	Value 'Connecting' 'Idle' 'Early Media'	Value 'Connected' 'Disconnecting' 'Preserved'
Qualifier Key 'Call'	Qualifier Value '1' – '5'		
<pre># CallStatus examples Value = InterfaceName.ReadStatus('CallStatus', {'Call': '1'}) InterfaceName.SubscribeStatus('CallStatus', None, FeedbackHandler)</pre>			
Command CallStatusType	Value 'Video' 'Forward All Call'	Value 'Audio' 'Unknown'	Value 'Audio Can Escalate'
Qualifier Key 'Call'	Qualifier Value '1' – '5'		
<pre># CallStatusType examples Value = InterfaceName.ReadStatus('CallStatusType', {'Call': '1'}) InterfaceName.SubscribeStatus('CallStatusType', None, FeedbackHandler)</pre>			
Command ConnectedDeviceMAC	Value 'String'		
Qualifier Key 'Button'	Qualifier Value 1 to 10 in steps of 1		
<pre># ConnectedDeviceMAC examples InterfaceName.Update('ConnectedDeviceMAC', {'Button': 10}) Value = InterfaceName.ReadStatus('ConnectedDeviceMAC', {'Button': 10}) InterfaceName.SubscribeStatus('ConnectedDeviceMAC', None, FeedbackHandler)</pre>			
Command ConnectedDeviceName	Value 'String'		
Qualifier Key 'Button'	Qualifier Value 1 to 10 in steps of 1		
<pre># ConnectedDeviceName examples InterfaceName.Update('ConnectedDeviceName', {'Button': 10}) Value = InterfaceName.ReadStatus('ConnectedDeviceName', {'Button': 10}) InterfaceName.SubscribeStatus('ConnectedDeviceName', None, FeedbackHandler)</pre>			
Command ConnectedDeviceType	Value 'String'		
Qualifier Key 'Button'	Qualifier Value 1 to 10 in steps of 1		
<pre># ConnectedDeviceType examples InterfaceName.Update('ConnectedDeviceType', {'Button': 10})</pre>			

Global Scripter Module Communication Sheet

<pre>Value = InterfaceName.ReadStatus('ConnectedDeviceType', {'Button': 10}) InterfaceName.SubscribeStatus('ConnectedDeviceType', None, FeedbackHandler)</pre>			
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'	
<pre># ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)</pre>			
Command DisplayMode	Value 'Dual'	Value 'Single'	Value 'Dual Presentation Only'
	'Triple Presentation Only'	'Triple'	'Quadruple'
<pre># DisplayMode examples Value = InterfaceName.ReadStatus('DisplayMode') InterfaceName.SubscribeStatus('DisplayMode', None, FeedbackHandler)</pre>			
Command DisplayName	Value 'String'		
Qualifier Key 'Call'	Qualifier Value '1' – '5'		
<pre># DisplayName examples InterfaceName.Update('DisplayName', {'Call': '1'}) Value = InterfaceName.ReadStatus('DisplayName', {'Call': '1'}) InterfaceName.SubscribeStatus('DisplayName', None, FeedbackHandler)</pre>			
Command DNSDomainName	Value 'String'		
<pre># DNSDomainName examples InterfaceName.Update('DNSDomainName') Value = InterfaceName.ReadStatus('DNSDomainName') InterfaceName.SubscribeStatus('DNSDomainName', None, FeedbackHandler)</pre>			
Command DNSServerAddress	Value 'String'		
Qualifier Key 'Server'	Qualifier Value '1' – '5'		
<pre># DNSServerAddress examples InterfaceName.Update('DNSServerAddress', {'Server': '1'}) Value = InterfaceName.ReadStatus('DNSServerAddress', {'Server': '1'}) InterfaceName.SubscribeStatus('DNSServerAddress', None, FeedbackHandler)</pre>			
Command DoNotDisturb	Value 'Active'	Value 'Inactive'	
<pre># DoNotDisturb examples Value = InterfaceName.ReadStatus('DoNotDisturb') InterfaceName.SubscribeStatus('DoNotDisturb', None, FeedbackHandler)</pre>			
Command FarEndControl	Value 'On'	Value 'Off'	
<pre># FarEndControl examples InterfaceName.Update('FarEndControl')</pre>			

Value = InterfaceName.ReadStatus('FarEndControl') InterfaceName.SubscribeStatus('FarEndControl', None, FeedbackHandler)			
Command FirmwareVersion	Value 'String'		
# FirmwareVersion examples InterfaceName.Update('FirmwareVersion') Value = InterfaceName.ReadStatus('FirmwareVersion') InterfaceName.SubscribeStatus('FirmwareVersion', None, FeedbackHandler)			
Command GatewayAddress	Value 'String'		
# GatewayAddress examples InterfaceName.Update('GatewayAddress') Value = InterfaceName.ReadStatus('GatewayAddress') InterfaceName.SubscribeStatus('GatewayAddress', None, FeedbackHandler)			
Command H323GatekeeperAddress	Value 'String'		
# H323GatekeeperAddress examples InterfaceName.Update('H323GatekeeperAddress') Value = InterfaceName.ReadStatus('H323GatekeeperAddress') InterfaceName.SubscribeStatus('H323GatekeeperAddress', None, FeedbackHandler)			
Command H323GatekeeperStatus	Value 'Required' 'Authenticating' 'Registered'	Value 'Discovering' 'Authenticated' 'Inactive'	Value 'Discovered' 'Registering' 'Rejected'
# H323GatekeeperStatus examples Value = InterfaceName.ReadStatus('H323GatekeeperStatus') InterfaceName.SubscribeStatus('H323GatekeeperStatus', None, FeedbackHandler)			
Command Input	Value '1' – '5'		
# Input examples Value = InterfaceName.ReadStatus('Input') InterfaceName.SubscribeStatus('Input', None, FeedbackHandler)			
Command InputMicLevel	Value 0 to 24 in steps of 1		
Qualifier Key 'Input'	Qualifier Value 'Microphone 1'	Qualifier Value 'Microphone 2'	
# InputMicLevel examples InterfaceName.Update('InputMicLevel', {'Input': 'Microphone 1'}) Value = InterfaceName.ReadStatus('InputMicLevel', {'Input': 'Microphone 1'}) InterfaceName.SubscribeStatus('InputMicLevel', None, FeedbackHandler)			
Command InputMute	Value 'On'	Value 'Off'	
Qualifier Key 'Input'	Qualifier Value 'Internal Microphone'	Qualifier Value 'Microphone 1'	Qualifier Value 'Microphone 2'

<pre># InputMute examples InterfaceName.Update('InputMute', {'Input': 'Internal Microphone'}) Value = InterfaceName.ReadStatus('InputMute', {'Input': 'Internal Microphone'}) InterfaceName.SubscribeStatus('InputMute', None, FeedbackHandler)</pre>			
Command InputSignal	Value 'True'	Value 'False'	Value 'Unknown'
Qualifier Key 'Input'	Qualifier Value '1' – '2'		
<pre># InputSignal examples Value = InterfaceName.ReadStatus('InputSignal', {'Input': '1'}) InterfaceName.SubscribeStatus('InputSignal', None, FeedbackHandler)</pre>			
Command IPAddress	Value 'String'		
<pre># IPAddress examples InterfaceName.Update('IPAddress') Value = InterfaceName.ReadStatus('IPAddress') InterfaceName.SubscribeStatus('IPAddress', None, FeedbackHandler)</pre>			
Command MACAddress	Value 'String'		
<pre># MACAddress examples InterfaceName.Update('MACAddress') Value = InterfaceName.ReadStatus('MACAddress') InterfaceName.SubscribeStatus('MACAddress', None, FeedbackHandler)</pre>			
Command MicrophonesMute	Value 'On'	Value 'Off'	
<pre># MicrophonesMute examples Value = InterfaceName.ReadStatus('MicrophonesMute') InterfaceName.SubscribeStatus('MicrophonesMute', None, FeedbackHandler)</pre>			
Command NetworkAssignment	Value 'Static'	Value 'DHCP'	
<pre># NetworkAssignment examples InterfaceName.Update('NetworkAssignment') Value = InterfaceName.ReadStatus('NetworkAssignment') InterfaceName.SubscribeStatus('NetworkAssignment', None, FeedbackHandler)</pre>			
Command PhonebookFolderIDSearch Result	Value 'String'		
Qualifier Key 'Button'	Qualifier Value 1 to 10 in steps of 1		
<pre># PhonebookFolderIDSearchResult examples InterfaceName.Update('PhonebookFolderIDSearchResult', {'Button': 10}) Value = InterfaceName.ReadStatus('PhonebookFolderIDSearchResult', {'Button': 10}) InterfaceName.SubscribeStatus('PhonebookFolderIDSearchResult', None, FeedbackHandler)</pre>			
Command PhonebookSearchResult	Value 'String'		

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Qualifier Key 'Button'	Qualifier Value 1 to 10 in steps of 1		
# PhonebookSearchResult examples InterfaceName.Update('PhonebookSearchResult', {'Button': 10}) Value = InterfaceName.ReadStatus('PhonebookSearchResult', {'Button': 10}) InterfaceName.SubscribeStatus('PhonebookSearchResult', None, FeedbackHandler)			
Command Presentation ¹	Value 'Start'	Value 'Stop'	
# Presentation examples Value = InterfaceName.ReadStatus('Presentation') InterfaceName.SubscribeStatus('Presentation', None, FeedbackHandler)			
Command PresentationMode ¹	Value 'On'	Value 'Off'	
# PresentationMode examples Value = InterfaceName.ReadStatus('PresentationMode') InterfaceName.SubscribeStatus('PresentationMode', None, FeedbackHandler)			
Command PresentationSendingModeStatus ¹	Value 'Local and Remote'	Value 'Local Only'	Value 'Off'
# PresentationSendingModeStatus examples Value = InterfaceName.ReadStatus('PresentationSendingModeStatus') InterfaceName.SubscribeStatus('PresentationSendingModeStatus', None, FeedbackHandler)			
Command RemoteNumber	Value 'String'		
Qualifier Key 'Call'	Qualifier Value '1' – '5'		
# RemoteNumber examples InterfaceName.Update('RemoteNumber', {'Call': '1'}) Value = InterfaceName.ReadStatus('RemoteNumber', {'Call': '1'}) InterfaceName.SubscribeStatus('RemoteNumber', None, FeedbackHandler)			
Command SelfView	Value 'On'	Value 'Off'	
# SelfView examples Value = InterfaceName.ReadStatus('SelfView') InterfaceName.SubscribeStatus('SelfView', None, FeedbackHandler)			
Command SelfViewDefaultFullscreenMode	Value 'On'	Value 'Off'	Value 'Current'
# SelfViewDefaultFullscreenMode examples InterfaceName.Update('SelfViewDefaultFullscreenMode') Value = InterfaceName.ReadStatus('SelfViewDefaultFullscreenMode') InterfaceName.SubscribeStatus('SelfViewDefaultFullscreenMode', None, FeedbackHandler)			
Command SelfViewPosition	Value 'Upper Left'	Value 'Upper Center'	Value 'Upper Right'

Global Scripter Module Communication Sheet

Revision: 4/6/2018

	'Center Left'	'Center Right'	'Lower Left'
	'Lower Right'		
# SelfViewPosition examples Value = InterfaceName.ReadStatus('SelfViewPosition') InterfaceName.SubscribeStatus('SelfViewPosition', None, FeedbackHandler)			
Command SIPRegistrationStatus	Value 'Deregistering' 'Registered'	Value 'Failed' 'Registering'	Value 'Inactive'
# SIPRegistrationStatus examples Value = InterfaceName.ReadStatus('SIPRegistrationStatus') InterfaceName.SubscribeStatus('SIPRegistrationStatus', None, FeedbackHandler)			
Command SpeakerTrackControl	Value 'On'	Value 'Off'	
# SpeakerTrackControl examples Value = InterfaceName.ReadStatus('SpeakerTrackControl') InterfaceName.SubscribeStatus('SpeakerTrackControl', None, FeedbackHandler)			
Command SpeakerTrackMode	Value 'Auto'	Value 'Off'	
# SpeakerTrackMode examples InterfaceName.Update('SpeakerTrackMode') Value = InterfaceName.ReadStatus('SpeakerTrackMode') InterfaceName.SubscribeStatus('SpeakerTrackMode', None, FeedbackHandler)			
Command Standby	Value 'Activate' 'Halfwake'	Value 'Deactivate'	Value 'Entering Standby'
# Standby examples Value = InterfaceName.ReadStatus('Standby') InterfaceName.SubscribeStatus('Standby', None, FeedbackHandler)			
Command SubnetMask	Value 'String'		
# SubnetMask examples InterfaceName.Update('SubnetMask') Value = InterfaceName.ReadStatus('SubnetMask') InterfaceName.SubscribeStatus('SubnetMask', None, FeedbackHandler)			
Command Volume	Value 0 to 100 in steps of 1		
# Volume examples Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)			

¹ Requires to be in an active call to work

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	SSH
Default Port:	22
Logon Credentials Supported:	Yes
Default Username:	admin
Default Password:	Cisco
Multi-Connection	Yes
Capabilities:	
Port Changeability:	No

Ethernet Module Configuration Description

Notes for the Device

SSH mode must be set to 'On' by an admin to have open communication with the driver.

Appendix A. Set Commands

Audio Output Off Output Internal Speaker	xConfiguration Audio Output InternalSpeaker Mode:Off\x0D
Audio Output On Output Internal Speaker	xConfiguration Audio Output InternalSpeaker Mode:On\x0D
Audio Output Off Output Line	xConfiguration Audio Output Line 1 Mode:Off\x0D
Audio Output On Output Line	xConfiguration Audio Output Line 1 Mode:On\x0D
Auto Answer Off	xConfiguration Conference AutoAnswer Mode: Off\x0D
Auto Answer On	xConfiguration Conference AutoAnswer Mode: On\x0D
Call Setup Mode Direct	xConfiguration H323 CallSetup Mode: Direct\x0D
Call Setup Mode Gatekeeper	xConfiguration H323 CallSetup Mode: Gatekeeper\x0D
Camera Focus Far	xCommand Camera Ramp CameraId:1 Focus:Far\x0D
Camera Focus Near	xCommand Camera Ramp CameraId:1 Focus:Near\x0D
Camera Focus Stop	xCommand Camera Ramp CameraId:1 Focus:Stop\x0D
Camera Focus Far Camera 1	xCommand Camera Ramp CameraId:1 Focus:Far\x0D
Camera Focus Near Camera 1	xCommand Camera Ramp CameraId:1 Focus:Near\x0D
Camera Focus Stop Camera 1	xCommand Camera Ramp CameraId:1 Focus:Stop\x0D
Camera Focus Far Camera 7	xCommand Camera Ramp CameraId:7 Focus:Far\x0D
Camera Focus Near Camera 7	xCommand Camera Ramp CameraId:7 Focus:Near\x0D
Camera Focus Stop Camera 7	xCommand Camera Ramp CameraId:7 Focus:Stop\x0D
Camera Pan Left Speed 1	xCommand Camera Ramp CameraId:1 Pan:Left PanSpeed:1\x0D
Camera Pan Right Speed 1	xCommand Camera Ramp CameraId:1 Pan:Right PanSpeed:1\x0D
Camera Pan Stop Speed 1	xCommand Camera Ramp CameraId:1 Pan: Stop\x0D
Camera Pan Left Speed 15	xCommand Camera Ramp CameraId:1 Pan:Left PanSpeed:15\x0D
Camera Pan Right Speed 15	xCommand Camera Ramp CameraId:1 Pan:Right PanSpeed:15\x0D
Camera Pan Stop Speed 15	xCommand Camera Ramp CameraId:1 Pan: Stop\x0D
Camera Pan Left Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Pan:Left PanSpeed:1\x0D
Camera Pan Right Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Pan:Right PanSpeed:1\x0D
Camera Pan Stop Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Pan: Stop\x0D
Camera Pan Left Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Pan:Left PanSpeed:15\x0D
Camera Pan Right Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Pan:Right PanSpeed:15\x0D
Camera Pan Stop Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Pan: Stop\x0D
Camera Pan Left Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Pan:Left PanSpeed:1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Camera Pan Right Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Pan:Right PanSpeed:1\x0D
Camera Pan Stop Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Pan: Stop\x0D
Camera Pan Left Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Pan:Left PanSpeed:15\x0D
Camera Pan Right Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Pan:Right PanSpeed:15\x0D
Camera Pan Stop Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Pan: Stop\x0D
Camera Preset Recall 1	xCommand Camera Preset Activate PresetId: 1\x0D
Camera Preset Recall 35	xCommand Camera Preset Activate PresetId: 35\x0D
Camera Preset Save 1	xCommand Camera Preset Store PresetId:1 CameraId:1\x0D
Camera Preset Save 35	xCommand Camera Preset Store PresetId:35 CameraId:1\x0D
Camera Preset Save 1 Camera 1	xCommand Camera Preset Store PresetId:1 CameraId:1\x0D
Camera Preset Save 35 Camera 1	xCommand Camera Preset Store PresetId:35 CameraId:1\x0D
Camera Preset Save 1 Camera 7	xCommand Camera Preset Store PresetId:1 CameraId:7\x0D
Camera Preset Save 35 Camera 7	xCommand Camera Preset Store PresetId:35 CameraId:7\x0D
Camera Tilt Down Speed 1	xCommand Camera Ramp CameraId:1 Tilt:Down TiltSpeed:1\x0D
Camera Tilt Stop Speed 1	xCommand Camera Ramp CameraId:1 Tilt: Stop\x0D
Camera Tilt Up Speed 1	xCommand Camera Ramp CameraId:1 Tilt:Up TiltSpeed:1\x0D
Camera Tilt Down Speed 15	xCommand Camera Ramp CameraId:1 Tilt:Down TiltSpeed:15\x0D
Camera Tilt Stop Speed 15	xCommand Camera Ramp CameraId:1 Tilt: Stop\x0D
Camera Tilt Up Speed 15	xCommand Camera Ramp CameraId:1 Tilt:Up TiltSpeed:15\x0D
Camera Tilt Down Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Tilt:Down TiltSpeed:1\x0D
Camera Tilt Stop Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Tilt: Stop\x0D
Camera Tilt Up Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Tilt:Up TiltSpeed:1\x0D
Camera Tilt Down Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Tilt:Down TiltSpeed:15\x0D
Camera Tilt Stop Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Tilt: Stop\x0D
Camera Tilt Up Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Tilt:Up TiltSpeed:15\x0D
Camera Tilt Down Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Tilt:Down TiltSpeed:1\x0D
Camera Tilt Stop Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Tilt: Stop\x0D
Camera Tilt Up Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Tilt:Up TiltSpeed:1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Camera Tilt Down Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Tilt:Down TiltSpeed:15\x0D
Camera Tilt Stop Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Tilt: Stop\x0D
Camera Tilt Up Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Tilt:Up TiltSpeed:15\x0D
Camera Zoom In Speed 1	xCommand Camera Ramp CameraId:1 Zoom:In ZoomSpeed:1\x0D
Camera Zoom Out Speed 1	xCommand Camera Ramp CameraId:1 Zoom:Out ZoomSpeed:1\x0D
Camera Zoom Stop Speed 1	xCommand Camera Ramp CameraId:1 Zoom: Stop\x0D
Camera Zoom In Speed 15	xCommand Camera Ramp CameraId:1 Zoom:In ZoomSpeed:15\x0D
Camera Zoom Out Speed 15	xCommand Camera Ramp CameraId:1 Zoom:Out ZoomSpeed:15\x0D
Camera Zoom Stop Speed 15	xCommand Camera Ramp CameraId:1 Zoom: Stop\x0D
Camera Zoom In Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Zoom:In ZoomSpeed:1\x0D
Camera Zoom Out Camera 1 Speed 1	xCommand Camera Ramp CameraId:1 Zoom:Out ZoomSpeed:1\x0D
Camera Zoom Stop Camera 1 Speed 1	xCommand Camera Ramp CameraId:{0} Zoom: Stop\x0D
Camera Zoom In Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Zoom:In ZoomSpeed:15\x0D
Camera Zoom Out Camera 1 Speed 15	xCommand Camera Ramp CameraId:1 Zoom:Out ZoomSpeed:15\x0D
Camera Zoom Stop Camera 1 Speed 15	xCommand Camera Ramp CameraId:{0} Zoom: Stop\x0D
Camera Zoom In Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Zoom:In ZoomSpeed:1\x0D
Camera Zoom Out Camera 7 Speed 1	xCommand Camera Ramp CameraId:7 Zoom:Out ZoomSpeed:1\x0D
Camera Zoom Stop Camera 7 Speed 1	xCommand Camera Ramp CameraId:{0} Zoom: Stop\x0D
Camera Zoom In Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Zoom:In ZoomSpeed:15\x0D
Camera Zoom Out Camera 7 Speed 15	xCommand Camera Ramp CameraId:7 Zoom:Out ZoomSpeed:15\x0D
Camera Zoom Stop Camera 7 Speed 15	xCommand Camera Ramp CameraId:{0} Zoom: Stop\x0D
Connected Device Update None	xStatus Peripherals ConnectedDevice\x0D
DNS Domain Name Command None	xConfiguration Network 1 DNS Domain Name: string\x0D
DNS Server Address Command None	xConfiguration Network 1 DNS Server 1 Address: string\x0D
DTMF 0	xCommand Call DTMFSend DTMFString:0\x0D
DTMF 9	xCommand Call DTMFSend DTMFString:9\x0D
DTMF #	xCommand Call DTMFSend DTMFString:#\x0D
DTMF *	xCommand Call DTMFSend DTMFString:*\x0D
Display Mode Auto	xConfiguration Video Monitors: Auto\x0D
Display Mode Dual	xConfiguration Video Monitors: Dual\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Display Mode Dual Presentation Only	xConfiguration Video Monitors: DualPresentationOnly\x0D
Display Mode Single	xConfiguration Video Monitors: Single\x0D
Do Not Disturb Active	xCommand Conference DoNotDisturb Activate\x0D
Do Not Disturb Inactive	xCommand Conference DoNotDisturb Deactivate\x0D
Far End Camera Pan/Tilt Down	xCommand Call FarEndControl Camera Move Value:Down\x0D
Far End Camera Pan/Tilt Left	xCommand Call FarEndControl Camera Move Value:Left\x0D
Far End Camera Pan/Tilt Right	xCommand Call FarEndControl Camera Move Value:Right\x0D
Far End Camera Pan/Tilt Stop	xCommand Call FarEndControl Camera Stop\x0D
Far End Camera Pan/Tilt Up	xCommand Call FarEndControl Camera Move Value:Up\x0D
Far End Camera Preset Recall 1	xCommand Call FarEndControl RoomPreset Activate:1\x0D
Far End Camera Preset Recall 15	xCommand Call FarEndControl RoomPreset Activate:15\x0D
Far End Camera Source 0	xCommand Call FarEndControl Source Select SourceId:0\x0D
Far End Camera Source 15	xCommand Call FarEndControl Source Select SourceId:15\x0D
Far End Camera Zoom Stop	xCommand Call FarEndControl Camera Stop\x0D
Far End Control Off	xConfiguration Conference FarEndControl Mode: Off\x0D
Far End Control On	xConfiguration Conference FarEndControl Mode: On\x0D
H323 Gatekeeper Address Command None	xConfiguration H323 Gatekeeper Address: string\x0D
H323Alias E164 Command None	xConfiguration H323 H323Alias E164: string\x0D
H323Alias ID Command None	xConfiguration H323 H323Alias ID: string\x0D
H323Profile Authentication LoginName Command None	xConfiguration H323 Authentication LoginName: string\x0D
H323Profile Authentication Password Command None	xConfiguration H323 Authentication Password: string\x0D
Hook Accept Protocol Auto	xCommand Call Accept\x0D
Hook Dial Protocol Auto	xCommand Dial Number:"string"\x0D
Hook Disconnect 1 Protocol Auto	xCommand Call Disconnect CallId: 1\x0D
Hook Disconnect 2 Protocol Auto	xCommand Call Disconnect CallId: 2\x0D
Hook Disconnect 3 Protocol Auto	xCommand Call Disconnect CallId: 3\x0D
Hook Disconnect 4 Protocol Auto	xCommand Call Disconnect CallId: 4\x0D
Hook Disconnect 5 Protocol Auto	xCommand Call Disconnect CallId: 5\x0D
Hook Hold 1 Protocol Auto	xCommand Call Hold CallId: 1\x0D
Hook Hold 2 Protocol Auto	xCommand Call Hold CallId: 2\x0D
Hook Hold 3 Protocol Auto	xCommand Call Hold CallId: 3\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Hook Hold 4 Protocol Auto	xCommand Call Hold CallId: 4\x0D
Hook Hold 5 Protocol Auto	xCommand Call Hold CallId: 5\x0D
Hook Join 1 Protocol Auto	xCommand Call Join CallId: 1\x0D
Hook Join 2 Protocol Auto	xCommand Call Join CallId: 2\x0D
Hook Join 3 Protocol Auto	xCommand Call Join CallId: 3\x0D
Hook Join 4 Protocol Auto	xCommand Call Join CallId: 4\x0D
Hook Join 5 Protocol Auto	xCommand Call Join CallId: 5\x0D
Hook Reject Protocol Auto	xCommand Call Reject\x0D
Hook Resume 1 Protocol Auto	xCommand Call Resume CallId: 1\x0D
Hook Resume 2 Protocol Auto	xCommand Call Resume CallId: 2\x0D
Hook Resume 3 Protocol Auto	xCommand Call Resume CallId: 3\x0D
Hook Resume 4 Protocol Auto	xCommand Call Resume CallId: 4\x0D
Hook Resume 5 Protocol Auto	xCommand Call Resume CallId: 5\x0D
Hook Accept Protocol H320	xCommand Call Accept\x0D
Hook Dial Protocol H320	xCommand Dial Number:"string" Protocol:H320\x0D
Hook Disconnect 1 Protocol H320	xCommand Call Disconnect CallId: 1\x0D
Hook Disconnect 2 Protocol H320	xCommand Call Disconnect CallId: 2\x0D
Hook Disconnect 3 Protocol H320	xCommand Call Disconnect CallId: 3\x0D
Hook Disconnect 4 Protocol H320	xCommand Call Disconnect CallId: 4\x0D
Hook Disconnect 5 Protocol H320	xCommand Call Disconnect CallId: 5\x0D
Hook Hold 1 Protocol H320	xCommand Call Hold CallId: 1\x0D
Hook Hold 2 Protocol H320	xCommand Call Hold CallId: 2\x0D
Hook Hold 3 Protocol H320	xCommand Call Hold CallId: 3\x0D
Hook Hold 4 Protocol H320	xCommand Call Hold CallId: 4\x0D
Hook Hold 5 Protocol H320	xCommand Call Hold CallId: 5\x0D
Hook Join 1 Protocol H320	xCommand Call Join CallId: 1\x0D
Hook Join 2 Protocol H320	xCommand Call Join CallId: 2\x0D
Hook Join 3 Protocol H320	xCommand Call Join CallId: 3\x0D
Hook Join 4 Protocol H320	xCommand Call Join CallId: 4\x0D
Hook Join 5 Protocol H320	xCommand Call Join CallId: 5\x0D
Hook Reject Protocol H320	xCommand Call Reject\x0D
Hook Resume 1 Protocol H320	xCommand Call Resume CallId: 1\x0D
Hook Resume 2 Protocol H320	xCommand Call Resume CallId: 2\x0D
Hook Resume 3 Protocol H320	xCommand Call Resume CallId: 3\x0D
Hook Resume 4 Protocol H320	xCommand Call Resume CallId: 4\x0D
Hook Resume 5 Protocol H320	xCommand Call Resume CallId: 5\x0D
Hook Accept Protocol H323	xCommand Call Accept\x0D
Hook Dial Protocol H323	xCommand Dial Number:"string" Protocol:H323\x0D
Hook Disconnect 1 Protocol H323	xCommand Call Disconnect CallId: 1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Hook Disconnect 2 Protocol H323	xCommand Call Disconnect CallId: 2\x0D
Hook Disconnect 3 Protocol H323	xCommand Call Disconnect CallId: 3\x0D
Hook Disconnect 4 Protocol H323	xCommand Call Disconnect CallId: 4\x0D
Hook Disconnect 5 Protocol H323	xCommand Call Disconnect CallId: 5\x0D
Hook Hold 1 Protocol H323	xCommand Call Hold CallId: 1\x0D
Hook Hold 2 Protocol H323	xCommand Call Hold CallId: 2\x0D
Hook Hold 3 Protocol H323	xCommand Call Hold CallId: 3\x0D
Hook Hold 4 Protocol H323	xCommand Call Hold CallId: 4\x0D
Hook Hold 5 Protocol H323	xCommand Call Hold CallId: 5\x0D
Hook Join 1 Protocol H323	xCommand Call Join CallId: 1\x0D
Hook Join 2 Protocol H323	xCommand Call Join CallId: 2\x0D
Hook Join 3 Protocol H323	xCommand Call Join CallId: 3\x0D
Hook Join 4 Protocol H323	xCommand Call Join CallId: 4\x0D
Hook Join 5 Protocol H323	xCommand Call Join CallId: 5\x0D
Hook Reject Protocol H323	xCommand Call Reject\x0D
Hook Resume 1 Protocol H323	xCommand Call Resume CallId: 1\x0D
Hook Resume 2 Protocol H323	xCommand Call Resume CallId: 2\x0D
Hook Resume 3 Protocol H323	xCommand Call Resume CallId: 3\x0D
Hook Resume 4 Protocol H323	xCommand Call Resume CallId: 4\x0D
Hook Resume 5 Protocol H323	xCommand Call Resume CallId: 5\x0D
Hook Accept Protocol SIP	xCommand Call Accept\x0D
Hook Dial Protocol SIP	xCommand Dial Number:"string" Protocol:Sip\x0D
Hook Disconnect 1 Protocol SIP	xCommand Call Disconnect CallId: 1\x0D
Hook Disconnect 2 Protocol SIP	xCommand Call Disconnect CallId: 2\x0D
Hook Disconnect 3 Protocol SIP	xCommand Call Disconnect CallId: 3\x0D
Hook Disconnect 4 Protocol SIP	xCommand Call Disconnect CallId: 4\x0D
Hook Disconnect 5 Protocol SIP	xCommand Call Disconnect CallId: 5\x0D
Hook Hold 1 Protocol SIP	xCommand Call Hold CallId: 1\x0D
Hook Hold 2 Protocol SIP	xCommand Call Hold CallId: 2\x0D
Hook Hold 3 Protocol SIP	xCommand Call Hold CallId: 3\x0D
Hook Hold 4 Protocol SIP	xCommand Call Hold CallId: 4\x0D
Hook Hold 5 Protocol SIP	xCommand Call Hold CallId: 5\x0D
Hook Join 1 Protocol SIP	xCommand Call Join CallId: 1\x0D
Hook Join 2 Protocol SIP	xCommand Call Join CallId: 2\x0D
Hook Join 3 Protocol SIP	xCommand Call Join CallId: 3\x0D
Hook Join 4 Protocol SIP	xCommand Call Join CallId: 4\x0D
Hook Join 5 Protocol SIP	xCommand Call Join CallId: 5\x0D
Hook Reject Protocol SIP	xCommand Call Reject\x0D
Hook Resume 1 Protocol SIP	xCommand Call Resume CallId: 1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Hook Resume 2 Protocol SIP	xCommand Call Resume CallId: 2\x0D
Hook Resume 3 Protocol SIP	xCommand Call Resume CallId: 3\x0D
Hook Resume 4 Protocol SIP	xCommand Call Resume CallId: 4\x0D
Hook Resume 5 Protocol SIP	xCommand Call Resume CallId: 5\x0D
Hook Accept Protocol Spark	xCommand Call Accept\x0D
Hook Dial Protocol Spark	xCommand Dial Number:"string" Protocol:Spark\x0D
Hook Disconnect 1 Protocol Spark	xCommand Call Disconnect CallId: 1\x0D
Hook Disconnect 2 Protocol Spark	xCommand Call Disconnect CallId: 2\x0D
Hook Disconnect 3 Protocol Spark	xCommand Call Disconnect CallId: 3\x0D
Hook Disconnect 4 Protocol Spark	xCommand Call Disconnect CallId: 4\x0D
Hook Disconnect 5 Protocol Spark	xCommand Call Disconnect CallId: 5\x0D
Hook Hold 1 Protocol Spark	xCommand Call Hold CallId: 1\x0D
Hook Hold 2 Protocol Spark	xCommand Call Hold CallId: 2\x0D
Hook Hold 3 Protocol Spark	xCommand Call Hold CallId: 3\x0D
Hook Hold 4 Protocol Spark	xCommand Call Hold CallId: 4\x0D
Hook Hold 5 Protocol Spark	xCommand Call Hold CallId: 5\x0D
Hook Join 1 Protocol Spark	xCommand Call Join CallId: 1\x0D
Hook Join 2 Protocol Spark	xCommand Call Join CallId: 2\x0D
Hook Join 3 Protocol Spark	xCommand Call Join CallId: 3\x0D
Hook Join 4 Protocol Spark	xCommand Call Join CallId: 4\x0D
Hook Join 5 Protocol Spark	xCommand Call Join CallId: 5\x0D
Hook Reject Protocol Spark	xCommand Call Reject\x0D
Hook Resume 1 Protocol Spark	xCommand Call Resume CallId: 1\x0D
Hook Resume 2 Protocol Spark	xCommand Call Resume CallId: 2\x0D
Hook Resume 3 Protocol Spark	xCommand Call Resume CallId: 3\x0D
Hook Resume 4 Protocol Spark	xCommand Call Resume CallId: 4\x0D
Hook Resume 5 Protocol Spark	xCommand Call Resume CallId: 5\x0D
IPv4 Address Command None	xConfiguration Network 1 IPv4 Address: string\x0D
IPv4 Gateway Command None	xConfiguration Network 1 IPv4 Gateway: string\x0D
IPv4 Subnet Mask Command None	xConfiguration Network 1 IPv4 SubnetMask: string\x0D
Input 1	xCommand Video Input SetMainVideoSource ConnectorId: 1\x0D
Input 5	xCommand Video Input SetMainVideoSource ConnectorId: 5\x0D
Input Mic Level 0 Input Microphone 2	xConfiguration Audio Input Microphone 2 Level:0\x0D
Input Mic Level 24 Input Microphone 2	xConfiguration Audio Input Microphone 2 Level:24\x0D
Input Mic Level 0 Input Microphone 3	xConfiguration Audio Input Microphone 3 Level:0\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Input Mic Level 24 Input Microphone 3	xConfiguration Audio Input Microphone 3 Level:24\x0D
Input Mute Off Input Internal Microphone	xConfiguration Audio Input Microphone 1 Mode:Off\x0D
Input Mute On Input Internal Microphone	xConfiguration Audio Input Microphone 1 Mode:On\x0D
Input Mute Off Input Microphone 2	xConfiguration Audio Input Microphone 2 Mode:Off\x0D
Input Mute On Input Microphone 2	xConfiguration Audio Input Microphone 2 Mode:On\x0D
Input Mute Off Input Microphone 3	xConfiguration Audio Input Microphone 3 Mode:Off\x0D
Input Mute On Input Microphone 3	xConfiguration Audio Input Microphone 3 Mode:On\x0D
Layout Set Auto Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:auto\x0D
Layout Set Custom Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:custom\x0D
Layout Set Equal Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:equal\x0D
Layout Set Overlay Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:overlay\x0D
Layout Set Prominent Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:prominent\x0D
Layout Set Single Target Local	xCommand Video Layout LayoutFamily Set Target: local LayoutFamily:single\x0D
Layout Set Auto Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:auto\x0D
Layout Set Custom Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:custom\x0D
Layout Set Equal Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:equal\x0D
Layout Set Overlay Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:overlay\x0D
Layout Set Prominent Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:prominent\x0D
Layout Set Single Target Remote	xCommand Video Layout LayoutFamily Set Target: remote LayoutFamily:single\x0D
Microphones Mute Off	xCommand Audio Microphones Unmute\x0D
Microphones Mute On	xCommand Audio Microphones Mute\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 1 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalOnly ConnectorId:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 1 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 1 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalOnly ConnectorId:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 1 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Start Sending Mode Local Only Video Input Source Connector Id 1 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalOnly ConnectorId:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 1 Instance New	xCommand Presentation Stop Instance:New ConnectorId:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Start SendingMode:LocalOnly ConnectorId:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Stop ConnectorId:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 1 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalRemote ConnectorId:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 1 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 1 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalRemote ConnectorId:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 1 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 1 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalRemote ConnectorId:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 1 Instance New	xCommand Presentation Stop Instance:New ConnectorId:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Start SendingMode:LocalRemote ConnectorId:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Stop ConnectorId:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 1 Instance 1	xCommand Presentation Start Instance:1 ConnectorId:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 1 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 1 Instance 6	xCommand Presentation Start Instance:6 ConnectorId:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 1 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 1 Instance New	xCommand Presentation Start Instance:New ConnectorId:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 1 Instance New	xCommand Presentation Stop Instance:New ConnectorId:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Start ConnectorId:1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 1 Instance Not Specified	xCommand Presentation Stop ConnectorId:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 2 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalOnly ConnectorId:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 2 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 2 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalOnly ConnectorId:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 2 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 2 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalOnly ConnectorId:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 2 Instance New	xCommand Presentation Stop Instance:New ConnectorId:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Start SendingMode:LocalOnly ConnectorId:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Stop ConnectorId:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 2 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalRemote ConnectorId:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 2 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 2 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalRemote ConnectorId:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 2 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 2 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalRemote ConnectorId:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 2 Instance New	xCommand Presentation Stop Instance:New ConnectorId:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Start SendingMode:LocalRemote ConnectorId:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Stop ConnectorId:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 2 Instance 1	xCommand Presentation Start Instance:1 ConnectorId:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 2 Instance 1	xCommand Presentation Stop Instance:1 ConnectorId:2\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Start Sending Mode Not Specified Video Input Source Connector Id 2 Instance 6	xCommand Presentation Start Instance:6 ConnectorId:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 2 Instance 6	xCommand Presentation Stop Instance:6 ConnectorId:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 2 Instance New	xCommand Presentation Start Instance:New ConnectorId:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 2 Instance New	xCommand Presentation Stop Instance:New ConnectorId:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Start ConnectorId:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Connector Id 2 Instance Not Specified	xCommand Presentation Stop ConnectorId:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Not Specified Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalOnly\x0D
Presentation Stop Sending Mode Local Only Video Input Source Not Specified Instance 1	xCommand Presentation Stop Instance:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Not Specified Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalOnly\x0D
Presentation Stop Sending Mode Local Only Video Input Source Not Specified Instance 6	xCommand Presentation Stop Instance:6\x0D
Presentation Start Sending Mode Local Only Video Input Source Not Specified Instance New	xCommand Presentation Start Instance:New SendingMode:LocalOnly\x0D
Presentation Stop Sending Mode Local Only Video Input Source Not Specified Instance New	xCommand Presentation Stop Instance:New\x0D
Presentation Start Sending Mode Local Only Video Input Source Not Specified Instance Not Specified	xCommand Presentation Start SendingMode:LocalOnly\x0D
Presentation Stop Sending Mode Local Only Video Input Source Not Specified Instance Not Specified	xCommand Presentation Stop\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Not Specified Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalRemote\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Not Specified Instance 1	xCommand Presentation Stop Instance:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Not Specified Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalRemote\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Not Specified Instance 6	xCommand Presentation Stop Instance:6\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Not Specified Instance New	xCommand Presentation Start Instance:New SendingMode:LocalRemote\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Not Specified Instance New	xCommand Presentation Stop Instance:New\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Start Sending Mode Local and Remote Video Input Source Not Specified Instance Not Specified	xCommand Presentation Start SendingMode:LocalRemote\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Not Specified Instance Not Specified	xCommand Presentation Stop\x0D
Presentation Start Sending Mode Not Specified Video Input Source Not Specified Instance 1	xCommand Presentation Start Instance:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Not Specified Instance 1	xCommand Presentation Stop Instance:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Not Specified Instance 6	xCommand Presentation Start Instance:6\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Not Specified Instance 6	xCommand Presentation Stop Instance:6\x0D
Presentation Start Sending Mode Not Specified Video Input Source Not Specified Instance New	xCommand Presentation Start Instance:New\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Not Specified Instance New	xCommand Presentation Stop Instance:New\x0D
Presentation Start Sending Mode Not Specified Video Input Source Not Specified Instance Not Specified	xCommand Presentation Start\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Not Specified Instance Not Specified	xCommand Presentation Stop\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalOnly PresentationSource:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalOnly PresentationSource:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 1 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalOnly PresentationSource:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 1 Instance New	xCommand Presentation Stop Instance:New PresentationSource:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Start SendingMode:LocalOnly PresentationSource:1\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Stop PresentationSource:1\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalRemote PresentationSource:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalRemote PresentationSource:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalRemote PresentationSource:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance New	xCommand Presentation Stop Instance:New PresentationSource:1\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Start SendingMode:LocalRemote PresentationSource:1\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Stop PresentationSource:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Start Instance:1 PresentationSource:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 1 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Start Instance:6 PresentationSource:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 1 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 1 Instance New	xCommand Presentation Start Instance:New PresentationSource:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 1 Instance New	xCommand Presentation Stop Instance:New PresentationSource:1\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Start PresentationSource:1\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 1 Instance Not Specified	xCommand Presentation Stop PresentationSource:1\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalOnly PresentationSource:2\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalOnly PresentationSource:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 2 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalOnly PresentationSource:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 2 Instance New	xCommand Presentation Stop Instance:New PresentationSource:2\x0D
Presentation Start Sending Mode Local Only Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Start SendingMode:LocalOnly PresentationSource:2\x0D
Presentation Stop Sending Mode Local Only Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Stop PresentationSource:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Start Instance:1 SendingMode:LocalRemote PresentationSource:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Start Instance:6 SendingMode:LocalRemote PresentationSource:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance New	xCommand Presentation Start Instance:New SendingMode:LocalRemote PresentationSource:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance New	xCommand Presentation Stop Instance:New PresentationSource:2\x0D
Presentation Start Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Start SendingMode:LocalRemote PresentationSource:2\x0D
Presentation Stop Sending Mode Local and Remote Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Stop PresentationSource:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Start Instance:1 PresentationSource:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 2 Instance 1	xCommand Presentation Stop Instance:1 PresentationSource:2\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Start Instance:6 PresentationSource:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 2 Instance 6	xCommand Presentation Stop Instance:6 PresentationSource:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 2 Instance New	xCommand Presentation Start Instance:New PresentationSource:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 2 Instance New	xCommand Presentation Stop Instance:New PresentationSource:2\x0D
Presentation Start Sending Mode Not Specified Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Start PresentationSource:2\x0D
Presentation Stop Sending Mode Not Specified Video Input Source Presentation Source 2 Instance Not Specified	xCommand Presentation Stop PresentationSource:2\x0D
Presentation ExternalSource Select Command None	xCommand UserInterface Presentation ExternalSource Select SourceIdentifier: "string"\x0D
Preset Recall 1	xCommand RoomPreset Activate PresetId:1\x0D
Preset Recall 15	xCommand RoomPreset Activate PresetId:15\x0D
Preset Save 1	xCommand RoomPreset Store PresetId:1 Type:All\x0D
Preset Save 15	xCommand RoomPreset Store PresetId:15 Type:All\x0D
Reboot None	xCommand SystemUnit Boot Action:Restart\x0D
Self View Off	xCommand Video Selfview Set Mode:Off\x0D
Self View On	xCommand Video Selfview Set Mode:On\x0D
Self View Default Fullscreen Mode Current	xConfiguration Video Selfview Default FullscreenMode:Current\x0D
Self View Default Fullscreen Mode Off	xConfiguration Video Selfview Default FullscreenMode:Off\x0D
Self View Default Fullscreen Mode On	xConfiguration Video Selfview Default FullscreenMode:On\x0D
Self View Position Center Left	xCommand Video Selfview Set PIPPosition:CenterLeft\x0D
Self View Position Center Right	xCommand Video Selfview Set PIPPosition:CenterRight\x0D
Self View Position Lower Left	xCommand Video Selfview Set PIPPosition:LowerLeft\x0D
Self View Position Lower Right	xCommand Video Selfview Set PIPPosition:LowerRight\x0D
Self View Position Upper Center	xCommand Video Selfview Set PIPPosition:UpperCenter\x0D
Self View Position Upper Left	xCommand Video Selfview Set PIPPosition:UpperLeft\x0D
Self View Position Upper Right	xCommand Video Selfview Set PIPPosition:UpperRight\x0D

Global Scripter Module Communication Sheet

Revision: 4/6/2018

Sleep Timer 1	xCommand Standby ResetTimer Delay:1\x0D
Sleep Timer 480	xCommand Standby ResetTimer Delay:480\x0D
SpeakerTrack Control Off	xCommand Cameras SpeakerTrack Deactivate\x0D
SpeakerTrack Control On	xCommand Cameras SpeakerTrack Activate\x0D
SpeakerTrack Mode Auto	xConfiguration Cameras SpeakerTrack Mode: Auto\x0D
SpeakerTrack Mode Off	xConfiguration Cameras SpeakerTrack Mode: Off\x0D
Standby Activate	xCommand Standby Activate\x0D
Standby Deactivate	xCommand Standby Deactivate\x0D
Volume 0	xCommand Audio Volume Set Level:0\x0D
Volume 100	xCommand Audio Volume Set Level:100\x0D