

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scripter Modules, refer to the "[Guide to Using Scripter Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: Computer Support Systems
Firmware Version: N/A
Model(s): Intelligent Power - ZIP5008

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scripter Version
3.01.0000-b010	2.1.0

Version History

Module Version	Date	Notes
1_1_1_0	2/13/2019	Added status for SwitchPowerOutlet. Added EnergyStatus, FrequencyStatus, LoadStatus, PowerFactorStatus, PowerStatus, VoltageStatus
1_0_0_0	4/20/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'admin', 'password',  
Model='Intelligent Power - ZIP5008')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command SwitchPowerOutlet	Value 'On'	Value 'Off'
Qualifier Key 'Outlet'	Qualifier Value '1' – '8'	Qualifier Value 'All'
# SwitchPowerOutlet example InterfaceName.Set('SwitchPowerOutlet', 'On', {'Outlet': 'All'})		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, EnergyStatus, FrequencyStatus, LoadStatus, PowerFactorStatus, PowerStatus, SwitchPowerOutlet, and VoltageStatus do not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command DeviceStatus	Value 'On' 'Undefined'	Value 'Off' 'Rebooting'
# DeviceStatus examples InterfaceName.Update('DeviceStatus') Value = InterfaceName.ReadStatus('DeviceStatus') InterfaceName.SubscribeStatus('DeviceStatus', None, FeedbackHandler)		
Command EnergyStatus	Value Float value	
# EnergyStatus examples Value = InterfaceName.ReadStatus('EnergyStatus') InterfaceName.SubscribeStatus('EnergyStatus', None, FeedbackHandler)		
Command FrequencyStatus	Value Float value	
# FrequencyStatus examples Value = InterfaceName.ReadStatus('FrequencyStatus') InterfaceName.SubscribeStatus('FrequencyStatus', None, FeedbackHandler)		
Command LoadStatus	Value Float value	
# LoadStatus examples Value = InterfaceName.ReadStatus('LoadStatus') InterfaceName.SubscribeStatus('LoadStatus', None, FeedbackHandler)		

Command	Value	
PowerFactorStatus	Float value	
# PowerFactorStatus examples Value = InterfaceName.ReadStatus('PowerFactorStatus') InterfaceName.SubscribeStatus('PowerFactorStatus', None, FeedbackHandler)		
Command	Value	
PowerStatus	Float value	
# PowerStatus examples Value = InterfaceName.ReadStatus('PowerStatus') InterfaceName.SubscribeStatus('PowerStatus', None, FeedbackHandler)		
Command	Value	Value
SwitchPowerOutlet	'On'	'Off'
Qualifier Key	Qualifier Value	Qualifier Value
'Outlet'	'1' – '8'	'All'
# SwitchPowerOutlet examples Value = InterfaceName.ReadStatus('SwitchPowerOutlet', {'Outlet': 'All'}) InterfaceName.SubscribeStatus('SwitchPowerOutlet', None, FeedbackHandler)		
Command	Value	
VoltageStatus	Float value	
# VoltageStatus examples Value = InterfaceName.ReadStatus('VoltageStatus') InterfaceName.SubscribeStatus('VoltageStatus', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Multi-Connection	Undetermined
Capabilities:	
Port Changeability:	No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device