PingPong – operator cheat sheet

N1MM Logger+ multi-op · S55OO

1 · What the lamp shows

Lamp	Means	You
—	Nobody on your band and mode is transmitting.	Operate normally.
CQ	A station on your band and mode is transmitting – its color, its message, its name (top left) and frequency (top right).	Inband: don't transmit over it.
GO	RUN has just finished (3 s) – the slot is free for the inband stations.	Now is the moment. First inband to transmit gets the slot.
WAIT · INB1 · 32 s	Another inband holds the slot. Your F1–F11, Enter, Insert are blocked.	Wait for RUN to transmit; frees itself after the release time.
BLOCKED · F1	You pressed a blocked key – nothing was sent.	Wait, then press again.
F12 · RUN1 · 25 s	F12 call: the border blinks in the caller's color – "hold off, please". Your F-keys may be blocked meanwhile.	Stop transmitting. Left click on the lamp stops the blinking.
RUN1 · QRL? ⚡	Urgent call (Shift+F2/F4) from a station on your band and mode – flashes fast (color ↔ white) as long as its message is sent. `PRIORITY` in the corner (Ctrl+F2/F4): your transmission was stopped, keys held.	Stop and listen – at once.
INB2 · INB	Lamp test from the master PC: purple ↔ white for 3 s, `TEST` in the corner.	Nothing – it shows your own name.

2 · Your keys

F12 in S&P	The S&P stations on your band blink in your color and hold off (call time, default 30 s). F12 again = end the call.
F12 in Run	**All** stations on your band hold off for a few seconds (default 5 s).
Shift+F2 / F4	N1MM sends F2/F4 as usual, and every lamp on your band and mode flashes your name and the message while it is sent.
Ctrl+F2 / F4	**Priority:** stations on your band and mode that transmit are stopped (Esc) and held; then your F2/F4 goes out – same flashing.
Run / S&P	Your role follows N1MM: Run = **RUN**, S&P = **INB** – nothing to set.
Mouse	Left click on lamp = stop blinking · right click = Options · Shift+F = compact lamp.

"F12 busy · RUN2" = a call is already running on your band; wait until it ends.

3 · Taking turns (ping-pong)

RUN transmits → **GO** → **first INB takes slot** → **other INBs WAIT** → **RUN transmits**

- The slot also frees itself after the **release time** (set on the master, default 40 s; 0 = only RUN frees it).
- The master can switch the lock **off** – then everybody may transmit, no priority.
- `no RUN on 7 MHz – lock off`: there is no RUN on your band, so nobody is locked.
- Only transmissions **N1MM starts** count. Paddle, microphone PTT or footswitch are not seen and not blocked.

Phone lamp

Options ▾ → **Phone lamp QR code…** → scan it with the phone. The phone shows the same lamp (needs the firewall rule).

4 · Messages under the lamp – what to do

Message	Do
`no data from this PC's N1MM on UDP 12062`	N1MM: Config → Configure Ports… → **Broadcast Data** → **Radio** ticked, line `127.0.0.1:12060 127.0.0.1:12062` → OK.
`⚠ UDP 12062 also used by …` (red)	Another program takes N1MM's data on this PC – tell the captain.
`no PingPong heard – firewall?`	Options ▾ → **Allow PingPong in Windows Firewall…** (asks for administrator rights).
`⚠ TWO MASTERS` · different versions	Tell the captain (Overview: **Update all lamps…**).
`🔒 … has a password – click here`	Click the line and type the network password (ask the captain) – it is checked at once.
Lamp gone / closed	Start `n1mm_lamps.exe` again – only one lamp per PC. The Overview raises an alarm when an operating lamp is silent for 30 s.

It prevents mistakes – it is not a hardware interlock. N1MM's own interlock still applies.