

(KODAK Photo Printer 6800/6850)
Error Code List

First edition : January 15, 2010
Latest edition : August 15, 2015
Revision : Rev.3

History of Revisions

Date of revision	Revision	Descriptions
Jan. 27 '10	Rev.1	Official Release
Nov. 17 '11	Rev.2	Changed User Error codes.
Aug. 15 '15	Rev.3	Page 3 • Added error codes as follows; "Control Error 23" "Control Error 24" "Control Error 25"

Table of Contents

1. Scope.....	1
2. Error code lists	2
2.1. Basic format	2
2.2. Error code lists.....	3
2.2.1. Control Errors.....	3
2.2.2. Mechanical Errors.....	4
2.2.3. Sensor Errors	5
2.2.4. Thermistor Temperature Sensor Errors.....	6
2.2.5. Paper Jam Errors	7
2.2.6. User Errors	9

1. Scope

This manual describes the error codes of the following Photo Printer (hereinafter Printer).

Kodak Photo Printer 6800/6850

2. Error code lists

2.1. Basic format

Basic format of error code list and meaning of each item are as follows

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
Control Error 01	02H	80000000H	01H(1)	4001	EEPROM Writing Time Out.	Yes

➤ Display to OCP

Means the string that is displayed to Operator Control Panel, during occurrence of the error.

➤ Error code(Printer)

Means the error code in format "hex value(decimal value)" that the printer responds to the host PC, during occurrence of the error.

CHCUSB-DLL responds this code to the application through the call of Tag Identifier (kPINFTAG_SVCINFO) in function"chcusb_getPrinterInfo" by the application.

➤ SDK status code

Means the code in format "decimal value" when CHCUSB-DLL responds to application by function "chcusb_status", during occurrence of the error.

➤ Error log registration

Means whether printer records the error log (Yes)/(No), when the error occurs.

2.2. Error code lists

2.2.1. Control Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	Detail			
Control Error 01	02H	80000000H	01H(1)	4001	EEPROM Writing Time Out.	Yes
Control Error 02	02H	80000000H	02H(2)	4002	EEPROM verify error.	Yes
Control Error 03	02H	80000000H	03H(3)	4003	EEPROM checksum Error.	Yes
Control Error 04	02H	80000000H	04H(4)	4004	ROM for DSP is not mounted.	Yes
Control Error 05	02H	80000000H	05H(5)	4005	DSP Program was not downloaded.	Yes
Control Error 06	02H	80000000H	06H(6)	4006	During downloading Main program, checksum error occurred.	Yes
Control Error 07	02H	80000000H	07H(7)	4007	During downloading Main program, failure to write flash.	Yes
Control Error 08	02H	80000000H	08H(8)	4008	During downloading DSP program, checksum error occurred.	Yes
Control Error 09	02H	80000000H	09H(9)	4009	During downloading DSP program, failure to write flash.	Yes
Control Error 10	02H	80000000H	0AH(10)	4010	ASIC Error.	Yes
Control Error 11	02H	80000000H	0BH(11)	4011	DRAM Controller Error.	Yes
Control Error 12	02H	80000000H	0CH(12)	4012	User Tone Curve Table checksum Error.	Yes
Control Error 13	02H	80000000H	0DH(13)	4013	User Tone Curve Table Write Error.	Yes
Control Error 14	02H	80000000H	0EH(14)	4014	Current Tone Curve Table checksum Error.	Yes
Control Error 15	02H	80000000H	0FH(15)	4015	Current Tone Curve Table Write Error.	Yes
Control Error 16	02H	80000000H	10H(16)	4016	User Tone Curve Table checksum Error.	Yes
Control Error 17	02H	80000000H	11H(17)	4017	User Tone Curve Table Read Error.	Yes
Control Error 18	02H	80000000H	12H(18)	4018	Current Tone Curve Table checksum Error.	Yes
Control Error 19	02H	80000000H	13H(19)	4019	Current Tone Curve Table Read Error.	Yes
Control Error 20	02H	80000000H	14H(20)	4020	User Tone Curve Reset Error.	Yes
Control Error 21	02H	80000000H	15H(21)	4021	Main Program was not downloaded.	Yes
Control Error 23	02H	80000000H	17H(23)	4023	During downloading TABLE program, checksum error occurred.	Yes
Control Error 24	02H	80000000H	18H(24)	4024	During downloading Main program, it failed to write flash.	Yes
Control Error 25	02H	80000000H	19H(25)	4025	TABLE Program was not downloaded.	Yes
Control Error 41	02H	80000000H	29H(41)	4041	Main-DSP Communication Error.	Yes
Serial No. Error	02H	80000000H	2AH(42)	4042	Incorrect Serial No. is set.	Yes

2.2.2. Mechanical Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
MechaError01	02H	40000000H	01H(1)	4101	Head up error.	Yes
MechaError02	02H	40000000H	02H(2)	4102	Head down error.	Yes
MechaError03	02H	40000000H	03H(3)	4103	Main pinch roller up error.	Yes
MechaError04	02H	40000000H	04H(4)	4104	Main pinch roller down Error.	Yes
MechaError05	02H	40000000H	05H(5)	4105	Sub pinch roller up error.	Yes
MechaError06	02H	40000000H	06H(6)	4106	Sub pinch roller down error.	Yes
MechaError07	02H	40000000H	07H(7)	4107	Feed pinch roller up error.	Yes
MechaError08	02H	40000000H	08H(8)	4108	Feed pinch roller down error.	Yes
MechaError09	02H	40000000H	09H(9)	4109	Eject pinch roller up error.	Yes
MechaError10	02H	40000000H	0AH(10)	4110	Eject pinch roller down error.	Yes
MechaError11	02H	40000000H	0BH(11)	4111	Cut error L->R (left to right movement).	Yes
MechaError12	02H	40000000H	0CH(12)	4112	Cut error R->L (right to left movement).	Yes

2.2.3. Sensor Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
SensorError01	02H	00002000H	01H(1)	4201	Head up/down position sensor error.	Yes
SensorError02	02H	00002000H	02H(2)	4202	Pinch roller up/down position sensor error.	Yes
SensorError03	02H	00002000H	03H(3)	4203	Feed pinch roller up/down position sensor error.	Yes
SensorError04	02H	00002000H	04H(4)	4204	Eject pinch roller up/down position sensor error.	Yes
SensorError05	02H	00002000H	05H(5)	4205	Cutter position sensor error. (Left or Right Side)	Yes
SensorError06	02H	00002000H	06H(6)	4206	Cutter position sensor error. (Left Side)	Yes
SensorError07	02H	00002000H	07H(7)	4207	Cutter position sensor error. (Right Side)	Yes
SensorError09	02H	00002000H	09H(9)	4209	Head down position sensor error.	Yes
SensorError10	02H	00002000H	0AH(10)	4210	Head up position sensor error.	Yes
SensorError11	02H	00002000H	0BH(11)	4211	Main pinch roller down position sensor error.	Yes
SensorError12	02H	00002000H	0CH(12)	4212	Main pinch roller up position Sensor error.	Yes
SensorError13	02H	00002000H	0DH(13)	4213	Feed pinch roller down position sensor error.	Yes
SensorError14	02H	00002000H	0EH(14)	4214	Feed pinch roller up position Sensor error.	Yes
SensorError15	02H	00002000H	0FH(15)	4215	Eject pinch roller down position sensor error.	Yes
SensorError16	02H	00002000H	10H(16)	4216	Eject pinch roller up position Sensor error.	Yes
SensorError17	02H	00002000H	11H(17)	4217	Cutter position sensor left.	Yes
SensorError18	02H	00002000H	12H(18)	4218	Cutter position sensor right.	Yes
SensorError19	02H	00002000H	13H(19)	4219	Cutter position sensor center.	Yes
SensorError20	02H	00002000H	14H(20)	4220	Upper cover sensor error.	Yes
SensorError21	02H	00002000H	15H(21)	4221	Feed paper cover sensor error.	Yes
SensorError22	02H	00002000H	16H(22)	4222	Jam sensor error.	Yes
SensorError23	02H	00002000H	17H(23)	4223	Take up side ribbon encoder sensor error.	Yes
SensorError24	02H	00002000H	18H(24)	4224	Supply side ribbon encoder sensor error.	Yes

2.2.4. Thermistor Temperature Sensor Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
TempSensError01	02H	00002000H	01H(1)	4301	Temperature sensor of the thermal print head is faulty. (High)	No
TempSensError02	02H	00002000H	02H(2)	4302	Temperature sensor of the thermal print head is faulty. (Low)	No
TempSensError03	02H	00002000H	03H(3)	4303	Ambient temperature sensor is faulty. (High)	Yes
TempSensError04	02H	00002000H	04H(4)	4304	Ambient temperature sensor is faulty. (Low)	Yes
TempSensError05	02H	00002000H	05H(5)	4305	Pre-heat error.	Yes

2.2.5. Paper Jam Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
Paper Jam 01	02H	00000100H	01H(1)	3001	Receiver Entrance ->Handling to Receiver Empty Sensor, Receiver Empty Sensor is not turning ON.	Yes
Paper Jam 02	02H	00000100H	02H(2)	3002	Receiver Empty Sensor ->Handling to Receiver Edge Sensor, Receiver Edge Sensor is not turning ON.	Yes
Paper Jam 03	02H	00000100H	03H(3)	3003	Receiver Edge Sensor ->Handling to Print Position Sensor, Slow up/down feed error 1 occurred.	Yes
Paper Jam 04	02H	00000100H	04H(4)	3004	Receiver Edge Sensor ->Handling to Print Position Sensor, Slow up/down feed error 2 occurred.	Yes
Paper Jam 05	02H	00000100H	05H(5)	3005	Receiver Edge Sensor ->Handling to Print Position Sensor, Print Position Sensor is not turning ON.	Yes
Paper Jam 11	02H	00000100H	0BH(11)	3011	Home Position ->Handling to Print Position Sensor, Print Position Sensor is not turning Off.	Yes
Paper Jam 12	02H	00000100H	0CH(12)	3012	Print Position Sensor->Handling to Edge Sensor, Edge sensor is not turning Off.	Yes
Paper Jam 13	02H	00000100H	0DH(13)	3013	Receiver Edge Sensor->Handling to Print Position Sensor, Slow up/down feed error 1 occurred.	Yes
Paper Jam 14	02H	00000100H	0EH(14)	3014	Receiver Edge Sensor->Handling to Print Position Sensor, Slow up/down feed error 2 occurred.	Yes
Paper Jam 15	02H	00000100H	0FH(15)	3015	Receiver Edge Sensor->Handling to Print Position Sensor, Print Position Sensor does not turn on.	Yes
Paper Jam 16	02H	00000100H	10H(16)	3016	Receiver Type Check-> Handling to Home Position, Slow up/down feed error 1 occurred.	Yes
Paper Jam 17	02H	00000100H	11H(17)	3017	Receiver Type Check-> Handling to Home Position, Slow up/down feed error 2 occurred.	Yes
Paper Jam 18	02H	00000100H	12H(18)	3018	Receiver Type Check-> Handling to Home Position, Print Position Sensor is not turning Off.	Yes
Paper Jam 21	02H	00000100H	15H(21)	3021	Handling to Print Position Sensor, Print Position Sensor is not turning Off.	Yes
Paper Jam 22	02H	00000100H	16H(22)	3022	Handling to Edge Sensor, Edge Sensor is not turning Off.	Yes
Paper Jam 23	02H	00000100H	17H(23)	3023	Handling to Receiver Empty Sensor, Handling Empty Sensor is not turning Off.	Yes
Paper Jam 31	02H	00000100H	1FH(31)	3031	Handling to Print Position Sensor, Print Position Sensor is not turning Off until end of remaining paper passes.	Yes
Paper Jam 41	02H	00000100H	29H(41)	3041	Home Position ->Handling to Print Position Sensor, Print Position Sensor is not turning On.	Yes
Paper Jam 51	02H	00000100H	33H(51)	3051	Skew correction Process -> Handling to Home Position, Slow up/down feed error 1 occurred.	Yes
Paper Jam 52	02H	00000100H	34H(52)	3052	Skew correction Process -> Handling to Home Position. Slow up/down feed error 2 occurred.	Yes
Paper Jam 53	02H	00000100H	35H(53)	3053	Skew correction Process -> Handling to Home position, Print Position Sensor is not turning OFF.	Yes
Paper Jam 61	02H	00000100H	3DH(61)	3061	After 1 color print, Edge Sensor is turning Off.	Yes
Paper Jam 62	02H	00000100H	3EH(62)	3062	After YMC print, after paper rewind, Print Position Sensor is turning Off.	Yes
Paper Jam 64	02H	00000100H	40H(64)	3064	Cut->Print start position, Slow up/down feed error occurred.	Yes

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
Paper Jam 65	02H	00000100H	41H(65)	3065	Cut->At the time of finishing feeding to print start position, Print Position Sensor is turning Off. (except for5x3.5)	Yes
Paper Jam 66	02H	00000100H	42H(66)	3066	Cut->At the time of finishing feeding to print start position, Print Position Sensor is turning Off. (for5x3.5)	Yes
Paper Jam 67	02H	00000100H	43H(67)	3067	Skew correction Process -> Handling to Print Start Position, Slow up/down feed error 1 occurred.	Yes
Paper Jam 68	02H	00000100H	44H(68)	3068	Skew correction Process -> Handling to Print Start Position, Slow up/down feed error 2 occurred.	Yes
Paper Jam 69	02H	00000100H	45H(69)	3069	Skew correction Process -> Print Position Sensor is not turning Off.	Yes
Paper Jam 71	02H	00000100H	47H(71)	3071	Home Position->Handling to Print Position Sensor, Print Position sensor is not turning ON.	Yes
Paper Jam 81	02H	00000100H	51H(81)	3081	Paper Edge Sensor detect OFF while printer is Ready.	Yes
Paper Jam 83	02H	00000100H	53H(83)	3083	Paper Empty Sensor detect OFF while printer is Ready.	Yes
Paper Jam 84	02H	00000100H	54H(84)	3084	Paper size Sensor detect OFF while printer is Ready. (Using 6 inch paper).	Yes
Paper Jam 91	02H	00000100H	5BH(91)	3091	Paper Edge Sensor sense ON, while printer is ready.	Yes
Paper Jam 92	02H	00000100H	5CH(92)	3092	Print Position Sensor sense ON, while printer is ready.	Yes
Paper Jam 93	02H	00000100H	5DH(93)	3093	Paper Empty Sensor sense ON, while printer is ready.	Yes
Paper Jam 94	02H	00000100H	5EH(94)	3094	Paper size Sensor sense ON, while printer is ready.	Yes

2.2.6. User Errors

Display to OCP	Host Notice Status			SDK status code	Description	Error log registration
	Condition1	Condition2	detail			
Incorrect Ribbon	02H	00000010H	01H(0)	2403	The ribbon does not correspond.	No
Ribbon Empty	02H	00000010H	00H(0)	2405	Detecting the end of a paper. No ribbon is set.	No
Incorrect Paper	02H	00000040H	03H(0)	2404	The paper does not correspond.	No
Paper Empty	02H	00000040H	00H(0)	2408	Paper is not set.	No
Take Out Paper	02H	00000040H	02H(0)	2413	After paper end detection, complete to eject remaining paper. Message of "Please pull out the paper".	No
Ready Loading	02H	00000040H	01H(0)	2412	The state in which loading of a paper is possible.	No
Cover Open	02H	00001000H	00H(0)	2401	Upper Cover open.	No
PaperCover Open	02H	00001000H	01H(1)	2402	Paper cover open.	No
Paper Posi.Error	02H	00000100H	5FH(95)	3095	The position of paper is too far in.	No