DI_Support versions

| | E7.2(P5) | E8.5(SP2P2) | E9.0 | E9.0(SP3P5) |
|------------|----------------------------|-------------------------|-------------------------|-------------------------|
| PFM | IT 13 | IT 13 | IT 13 | IT 13 |
| SAT | R14 | R16 | R19. | R19. |
| CatiaV4 | 4.1.9 ~ 4.2.4 | 4.1.9 ~ 4.2.4 | 4.1.9 ~ 4.2.4 | 4.1.9 ~ 4.2.4 |
| CatiaV5 | 読込み:R2~R16, 書出し: R6~R16 | R6~R18 | R2 ~ R19 | R2 ~ R20 |
| UG | Ver11~18 NX1~NX4 | Ver11~18 NX1~NX5 | Ver11~18 NX1~NX6 | Ver11~18 NX1~NX7 |
| Pro/E | Pro/E 16 ∼ Wildfire2 | Pro/E 16 ~ Wildfire3 | Pro/E 16 ∼ Wildfire4 | Pro/E 16 ~ Wildfire5 |
| SolidWorks | Ver 98 ~ 2006 | Ver 98 ~ 2008 | Ver 98 ~ 2009 | Ver 98 ~ 2010 |
| Parasolid | 17, 書出し: Ver10.0~16 | Ver10.0 ~ 19.0.172 | Ver10.0 ~20.0 | Ver10.0 ~20.0 |