

Holoscan Sensor Bridge Bring-up Guide

NVIDIA AGX Thor + Agilex 5 Modular Development Kit

This guide summarizes the customer bring-up flow used for the Altera/NVIDIA Holoscan Sensor Bridge demo on NVIDIA AGX Thor with Agilex 5 Modular Development Kits. It covers the working 10GbE and 25GbE paths, the issues encountered, and the fixes applied.

1. Reference Documents

- Jetson AGX Thor ISO installation:
<https://docs.nvidia.com/jetson/agx-thor-devkit/user-guide/latest/quick_start.html#>>
 - Holoscan Sensor Bridge host setup, AGX Thor tab:
<<https://docs.nvidia.com/holoscan/sensor-bridge/2.5.0/setup.html#sd-tab-item-3>>>
 - Altera HSB 25GbE reference design:
<https://github.com/altera-fpga/holoscan-sensor-bridge/tree/altera-release-2.6.0/fpga/altera/AGX_5E_065A_Modular_DevKit_HSB_MIPI_25GbE>
 - Altera HSB 10GbE reference design:
<https://github.com/altera-fpga/holoscan-sensor-bridge/tree/altera-release-2.6.0/fpga/altera/AGX_5E_065B_Modular_DevKit_HSB_MIPI_10GbE>
-

2. System Used

Host

- NVIDIA Jetson AGX Thor Developer Kit
- JetPack 7.2 / L4T R39.2

Verify:

```
cat /etc/nv_tegra_release
```

Expected:

```
# R39 (release), REVISION: 2.0
```

FPGA Images

10GbE / Group B:

```
AGX_5E_065B_Modular_DevKit_HSB_MIPI_10GbE.sof
```

25GbE / Group A:

```
AGX_5E_065A_Modular_DevKit_HSB_MIPI_25GbE.sof
```

3. AGX Thor Base Installation

Follow the Jetson AGX Thor ISO quick start guide.

High-level flow:

1. Download the Jetson AGX Thor ISO image.
2. Create the bootable USB installer.
3. Boot AGX Thor from the USB installer.
4. Install the BSP to NVMe.
5. Remove the USB installer.
6. Boot from NVMe and complete Ubuntu OEM setup.
7. Verify JetPack/L4T version.

Reference:

https://docs.nvidia.com/jetson/agx-thor-devkit/user-guide/latest/quick_start.html#

4. Host Setup for Holoscan Sensor Bridge

Use the AGX Thor tab in the Holoscan Sensor Bridge host setup guide.

Reference:

<https://docs.nvidia.com/holoscan/sensor-bridge/2.5.0/setup.html#sd-tab-item-3>

Clone the Altera release branch:

```
git clone -b altera-release-2.6.0 https://github.com/altera-fpga/holoscan-sensor-bridge.git
cd holoscan-sensor-bridge
git lfs pull
```

Build the demo container:

```
sh docker/build.sh --igpu
```

Start the demo container:

```
xhost +
sh docker/demo.sh
```

Inside the container, use:

```
hololink-enumerate
```

The tool is installed under /usr/local/bin, so ./tools/enumerate/hololink-enumerate may not exist in the container.

5. Common Network Configuration

The FPGA/HSB default IP is:

```
192.168.0.2
```

Configure Thor:

```
EN0=mgbe0_0
```

```
sudo nmcli connection delete hololink-$EN0 2>/dev/null || true
sudo nmcli con add con-name hololink-$EN0 ifname $EN0 type ethernet ip4 192.168.0.101/24
sudo nmcli connection modify hololink-$EN0 +ipv4.routes 192.168.0.2/32
sudo nmcli connection up hololink-$EN0
```

Test:

```
ping 192.168.0.2
```

Check link status:

```
for i in 0 1 2 3; do
    echo "---- mgbe${i}_0 ----"
    sudo ethtool mgbe${i}_0 | grep -E "Speed|Link detected"
done
```

6. 10GbE Demo Flow

Program the 10GbE FPGA image:

```
AGX_5E_065B_Modular_DevKit_HSB_MIP1_10GbE.sof
```

Expected Thor link:

```
mgbe0_0
Speed: 10000Mb/s
Link detected: yes
```

Successful HSB enumeration example:

```
mac_id=CA:FE:C0:FF:EE:10
hsb_ip_version=0x2603
ip_address=192.168.0.2
fpga_uuid=7b1fa8c7-31aa-44b6-abcc-eac134461fdc
interface=mgbe0_0
```

Run camera test:

```
python3 examples/linux_agx5_player.py --cam 0 --lines 1080 --frame-rate 30
```

Headless validation:

```
python3 examples/linux_agx5_player.py --cam 0 --lines 1080 --frame-rate 30 --headless --frame-limit 100
```

Stereo:

```
python3 examples/linux_agx5_player_stereo.py
```

7. 25GbE Demo Flow

Important

AGX Thor does not support runtime switching between 10GbE x4 and 25GbE x4 through nmcli or normal Linux network settings. The Thor boot image / QSPI boot slot must be switched.

Capsule files used:

Tegra_Thor_BL_7.2_10G.Cap
Tegra_Thor_BL_7.2_25G.Cap

Current slot mapping from this bring-up:

slot 0 = 25G
slot 1 = 10G

Switch to 25G:

```
sudo nvbootctrl set-active-boot-slot 0  
sudo reboot
```

Switch to 10G:

```
sudo nvbootctrl set-active-boot-slot 1  
sudo reboot
```

Check active slot and speed:

```
sudo nvbootctrl get-current-slot  
cat /sys/devices/platform/bus@0/*/net/mgbe*/speed
```

Expected for 25G:

```
0  
25000  
25000  
25000  
25000
```

Program the 25GbE FPGA image:

AGX_5E_065A_Modular_DevKit_HSB_MIPI_25GbE.sof

Expected Thor link:

```
mgbe0_0  
Speed: 25000Mb/s  
Link detected: yes
```

Run:

```
hololink-enumerate  
python3 examples/linux_agx5_player.py --cam 0 --lines 1080 --frame-rate 30
```

For two physical cameras:

```
python3 examples/agx5_multiviewer.py --cam 2 --lines 2160 --frame-rate 30 --receiver-type coe
```

If CoE is unstable, test with Linux receiver:

```
python3 examples/agx5_multiviewer.py --cam 2 --lines 1080 --frame-rate 30 --receiver-type linux
```

8. MAX10 MIPI Power Fix

Symptom

Holoscan applications reached the FPGA/HSB, but camera configuration failed with I2C transaction errors:

```
hololink._hololink.TransactionError: i2c_transaction i2c_address=0x37  
hololink._hololink.TransactionError: i2c_transaction i2c_address=0x1a
```

Root Cause

Early production MDK boards, both Group A and Group B, shipped with a bug in the MAX10 image. The buggy MAX10 image does not apply power to the MIPI connectors. Without MIPI connector power, camera I2C communication is impossible.

Customer release production boards are expected to ship with a fixed MAX10 image and should be plug-and-play. Currently available early boards may need MAX10 reflashing.

Fix Applied

1. Switch MAX10 onto the JTAG chain by setting SW4 on the carrier board to ON. This is the single switch nearest the HDMI connector.
2. Use Quartus Programmer GUI to reflash MAX10 with:

```
max10_top_rtl_v1p1p6_fw_v2p0p1.pof
```

3. Power off the board.
4. Set SW4 back to OFF so the FPGA appears on the JTAG chain again.

After this MAX10 update, camera I2C configuration succeeded.

Additional Note

Initial production MDK batches may have a carrier micro USB hub that is susceptible to ESD. If the carrier micro USB is not detected, for example Windows fails to read descriptors, use the standard JTAG connector and a Byte Blaster.

9. AI Demo Examples

YOLOv8 Body Pose

Inside container:

```
apt-get update && apt-get install -y ffmpeg  
pip3 install ultralytics onnx  
  
cd examples  
yolo export model=yolov8n-pose.pt format=onnx  
trtexec --onnx=yolov8n-pose.onnx --saveEngine=yolov8n-pose.engine.fp32  
cd -
```

Run:

```
python3 examples/linux_body_pose_estimation_agx5.py --cam 0 --lines 1080 --frame-rate 30
```

TAO PeopleNet

Download model:

```
curl -L 'https://api.ngc.nvidia.com/v2/models/org/nvidia/team/tao/peoplenet/pruned_quantized_decrypted_v2.3.3/files?redirect=true&path=resnet34_peoplenet_int8.onnx' -o examples/resnet34_peoplenet_int8.onnx
```

Run:

```
python3 examples/linux_tao_peoplenet_agx5.py --cam 0 --lines 1080 --frame-rate 30
```

First run builds a TensorRT engine and can take several minutes.

If the PeopleNet AGX5 example crashes in InferenceOp, disable metadata in `examples/linux_tao_peoplenet_agx5.py`:

```
self.is_metadata_enabled = False
```

10. Display and Runtime Notes

If Holoviz/GLFW fails:

```
Failed to initialize glfw
Authorization required, but no authorization protocol specified
XDG_RUNTIME_DIR is invalid or not set
```

Run on Thor host before starting Docker:

```
xhost +local:root
xhost +local:docker
xhost +
```

Inside Docker:

```
export XDG_RUNTIME_DIR=/tmp/runtime-root
mkdir -p $XDG_RUNTIME_DIR
chmod 700 $XDG_RUNTIME_DIR
```

For receiver buffer warnings:

```
echo 10420224 | sudo tee /proc/sys/net/core/rmem_max
```

Inside the container as root, omit sudo:

```
echo 10420224 > /proc/sys/net/core/rmem_max
```

Use Ctrl+C to stop demos. Avoid Ctrl+Z, which suspends jobs and can leave resources open.

11. Known Issues and Lessons Learned

- Thor defaults to 10GbE mode.
- 25GbE FPGA images need Thor booted in 25GbE mode.
- 10G/25G mode switching requires boot slot / capsule handling, not nmcli.
- Early MDK boards may need MAX10 reflashing to power MIPI connectors.

- Camera I2C errors can be caused by missing MIPI connector power, not only cable orientation.
- hololink-enumerate confirms the FPGA/HSB network path.
- GUI failures are often X11 authorization issues.
- .sof FPGA programming is volatile; reprogram after FPGA board power cycle.
- For customer demos on AGX Thor, 10GbE and Linux socket mode are the most stable paths. 25GbE CoE is available but may show stability issues under some multi-stream scenarios.