Click Here



Are you at least 18 years old? Sorry, the content of this store can't be seen by younger audiences. Come back when you're older. FREE 3 DAY SHIPPING ON ALL DASH CAMS Below, you'll find all the latest firmware, PC, Mac and mobile applications, as well as the manuals for your Dash Cam. To start using your camera, first format the memory card in the camera's system settings to prevent it from updating the firmware every time it restarts. We recommend using ROVE Ultimate Micro SD Card for optimal performance. This is because dashcams put micro SD cards under higher stress than most electronic products due to their constant loop recording. We test our cards extensively before selecting them for inclusion in our products, ensuring good performance and minimal degradation over time. Using other micro SD cards can affect the dashcam's performance and force it to reboot randomly during recording. The basic requirements of micro SD cards for ROVE dashcams are Class 10 or U3, with the SD card formatted [Windows] or MS-DOS (FAT) [Mac OS]. Join our ROVE Dash Cam Community on FB and hang out directly with us. Limited Time Launch Offer... EMAIL US help@rovedashcam.com For faster response, text us TEXT US 1 (401) 484-ROVE(7683). Scan the QR Code to Email or Text Us. WATCH HOW TO VIDEOS Visit our website www.rovedashcam.com/pages/videos to learn and understand all the features of your ROVE R3 3-Channel Touch Screen Dash Cam. The Rove Dash Cam is a high-resolution device that supports recording in 1440P, 1080P, and 1080P resolutions for up to 24 hours with auto trigger parking mode. It requires a ROVE USB Type-C HWK (not included) and supports micro-SD cards of up to 512GB capacity (Class 10, U3 speed only). The user agreement assumes consent with the product's terms and conditions upon purchase, allowing for returns within a specified window if any term is not agreed upon. Important safety precautions include using only the supplied ROVE car charger or R3 hardwire kit and avoiding direct sunlight or high temperatures (above 140°F/60°C) to prevent damage. Before using an external memory card, inspect it for physical damage or cracks to avoid short-circuits and burns. The camera uses a Supercapacitor and should be kept plugged in during operation; it automatically records video when powered on and stops recording and turns off when power is disconnected. There is no reset button, but unplugging and replugging the power cable can resolve any issues. The user manual provides detailed specifications for the camera, including memory card requirements, G-sensor functionality, built-in loop recording, and voice guidance. It also includes a quick start guide and notes that a memory card (Class 10, U3 speed) is not included but recommended for optimal performance. To instal the fron/main camera you have a suction mount or magnetic sticky mount avilable. Page 17 USER MANUAL Put the suction mount on the windshield and while preshing it lock the mount in place. You can easly remove the suction mount by sliding it out from the latch or turning the knob to unlock position and lifthing the tab to break the suktion. Or, most peaple instal their ROVE R3 next to the rear veiw mirrow on the opposite side from the driver. When using sticky mount we recomend that you use electrostatic film. Page 19 USER MANUAL Clean the windshield area ussing the cleaning pad and let it air dry. Put the exposed static side of the elecstic film on the windshield and apply preshure. Slide a credit card to remove any air bubbles for a strong bond with the windshield. Page 20 Now make shure the 3M Mount is fully secured and locked in place. No gap should be ed in place. To remuve the magnetic mount hold the top and bottom of the front camera and lifth up the bottom. Page 21 Now peel off the RED side of the 3M film from the windshield over the electrostatic film. Then apply even preshure to the camera from both sides for about 30 seconds. This should create a proper bond between 3M Sticky-Mount &... Page 22 Ensure you are not running cable past any airbags as this can prevent them from deploing. Plug in the included ROVE's USB car charger into your car's cigarette lighter socket. Page 23 Install the rear camera at the rear window. Clean the rear windshield ussing included cleaning wipe and let it air dry. Put the static film on the rear windshield and use a credit card to remove all the air bubbles. Page 24 Check the complete wiring at a glance diagram below to ensure everything is connected properly. Plug in the rear camera's cable into the front camera's connecting port. Push gently until you hear a clicking sound to make sure it is connected securely. Page 25 Adjust the lens angle of the front, cabin, and rear cameras accordingly. Given article text here it receives power i.e., when the car engine is started. Auto Power OFF: The camera is also pre-configured to save that last video file safely before shutting off the dash cam, in case if the power gets disconnected due to accident and also during daily turning off your vehicle. It charges faster than a battery. The amount of charge a capacitor can hold depends upon its capacitance or the charge storage capacity. ROVE R3’s Supercapacitor will hold the charge for about 2 seconds. WHY SUPERCAPACITOR? ROVE R3 dash cam uses a supercapacitor, making it a unique, reliable dash cam on power consumption and safety. HOME SCREEN Exposure G-sensor IR LED Parking Mode Loop Recording Video Time lapse Video Memory Card GPS Signal WiFi Loop Recording Timer Record Audio Recording Status Cabin Camera View Rear Camera View Settings Playback Folder Emergency Lock Video WiFi on/off Button Back To Home Screen WiFi Status LED Recording Status LED In order to save time, money, and hassle in the long run, we recommend our ROVE Ultimate microSDXC Cards. See a few details below to understand why? Therefore, with that said, to save time, money, and hassle on going back and forth fighting with which card to get, we simply now recommend our ROVE Ultimate Micro SD Card. At ROVE, we have higher standards. Because in the long run, we all want the camera and memory card to just work without any issues because we need peace of mind, and we have better things to do in life than fight to find a simple memory card. Must use only Brand Name, Class 10, U3, or higher speed Micro-SD card. Max supports up to 512GB. We recommend ROVE Ultimate Class 10, U3 Speed Micro-SD card. You can purchase it from Amazon. Search for “ROVE Ultimate Micro SD Card”... To remove the Micro-SD card, gently push its edge inward until it clicks and pops out, and then simply pull it out of the slot. IMPORTANT: Plus or any other generic cheap memory cards. You have purchased a FORMATTING MEMORY CARD Press anywhere on the LCD screen of the camera to access the Menu Settings... 39 Time Zone Setting: Choose from three options to set the date and time. Manually select the desired date and time in System Settings > Date/Time or opt for automatic setting based on GMT/UTC value selection when GPS signal lock is received. Note that this camera does not rely on cloud services or IP connectivity. To connect your R3 dash cam with your smartphone via WiFi, follow these steps: Download and install the ROVE APP from the App Store or Google Play Store. Register for a free account using the app to secure your videos and data. Turn ON WiFi from the camera's settings by going to System settings > WiFi option or pressing the WiFi icon on screen menu. To connect to ROVE R3 WiFi, go to Settings > WiFi > ROVE R3 WiFi, enter the default password (12345678), and JOIN the network. Once connected, open the ROVE APP, and the camera will sync automatically. In addition to the initial connection process, you may need to wait 10-15 seconds for a notification pop-up before proceeding. The ROVE R3 has two camera modes: VIDEO MODE and PLAYBACK MODE. Video Mode allows recording of live videos and storing them on the installed Micro SD card. Playback Mode provides access to recorded videos through three folders (front, cabin, and events). To playback your recorded videos, you can access the Playback Mode directly on the camera or remove the memory card and insert it into your PC/Mac using a memory slot or ROVE USB Type-C Card reader. If your default video player does not open VLC player by double clicking, right-click on each video file and select OPEN WITH > VLC Media Player. Important: Make sure to follow these steps carefully before operating your ROVE R3 dash cam. First, download the necessary software from page 51. You will also find a "Protect" folder there. To set up your dash cam on a smartphone: 1. Turn on WiFi on your phone and connect to the ROVE R3's network using the default password: 12345678. 2. Download and install the correct ROVE app for your device. 3. Once connected, you can access various settings, including video resolution, WiFi mode, loop recording, and more. When setting up camera settings: 1. Go to video resolution (page 53) and choose your preferred setting, keeping in mind that higher resolutions improve quality but increase file size. 2. You can also select the combination of cameras you want to use. Understanding loop recording (page 54): * The dash cam will begin loop recording when only 2% of unused space remains on the memory card. * This feature does not affect previously locked videos in the event directory. IR LED settings: 1. There are 4 hidden IR LEDs around the cabin camera lens, which help illuminate images in low light conditions. 2. You can choose between "Always OFF," "Always ON" or set it to auto mode (default). Audio recording and parking mode: 1. Audio recording is turned off by default; you can enable it if needed. 2. ROVE's custom parking monitor allows for automation and enhanced user experience. Important: Hardwiring your dash cam to the car's fuse box is necessary for power supply. The ROVE Ultimate USB Type-C Hardwire Kit is not included, so you'll need to purchase it separately. Understanding collision detection (page 58): 1. When you turn off the engine and the HWK is installed properly, the dash cam will enter parking mode. 2. If an impact occurs while the car is turned off, the dash cam will record a Time-Lapse Video. What to do if someone hits your parked car: 1. The dash cam will alert you with an on-screen pop-up when you start the engine next time. 2. Tap the OK button to acknowledge the alert and review the last event video to see what happened. Remember, if no one hits your car, simply tap the OK button to dismiss the alert. What level should I set my "Parking Mode G-Sensor" depends on personal preference and various factors. There are 9 gravitational sensor levels to choose from, ranging from -2.0 to +2.2. Even small vibrations like tapping the LCD or closing the car door can activate the R3 dash cam. You can adjust exposure levels to suit your needs, and turn ON/OFF video stamps including date, time, GPS coordinates, driving speed, license plate, and ROVE logo. The Time-Lapse Video feature allows you to record at a lower frame rate, while Speed Unit lets you choose between KM/H and MPH. Live Speed & Compass shows real-time speed and compass information on the LCD. You can also format your memory card in the camera, set the time and date automatically based on UTC/GMT value, and customize the date format. Additionally, you can turn ON/OFF screen savers, including always-on, after 1-minute idle, or turning off only the LCD while continuing to record. Finally, you can adjust Touch Tone settings to turn ON/OFF camera button beeps and voice confirmation, as well as enable Voice Guidance for female voice feedback. 1. Place your camera on a stable surface and check that voice feedback is not required. You can turn it off if you prefer. 2. Choose your TV mode according to your country's TV setting. The default is NTSC. 3. Storage space shows information about the memory card inserted into the camera. 4. Firmware updates are provided for free on the ROVE Dash Cam APP, which can be downloaded from the app store. 5. GPS player software is available for download at www.rovedashcam.com for PC/MAC only. 6. The G-Sensor Data allows you to play back recorded videos and view exact GPS routes with the video on Google Maps. 7. Driving speed can be displayed using the GPS Player, which also shows taggings of devices. 8. Playback controls include reverse, play, fast forward, and volume control. 9. The camera’s movement is measured by the G-Sensor Indicator, which helps measure camera movement. 10. One year limited warranty is provided from the date of purchase to cover defects in materials and craftsmanship. 11. Please save your warranty/serial number card as evidence. 12. Replacement units are either new or refurbished based on availability, with the option to upgrade to a newer version if discontinued. 13. Limitations and disclaimers include liability for compensations, damages, losses, etc. 14. The images in this user manual are only illustrative purposes and not real examples captured by the ROVE dash cam. 15. If your camera is freezing or lagging, try restarting it, or check if the micro SD card is correctly inserted. Troubleshooting Guide for ROVE R3 Dash Cam: If none of the troubleshooting steps work, please email customer care for assistance with a manual firmware update. Camera Installation and Power Supply: Ensure that the camera is securely locked in place (Page 84). If you're using a non-ROVE USB Car Charger, your car's direct USB might not provide enough power, which can cause reboots (Page 85). Recording Issues: There are three possible reasons why recording may start and stop even with properly connected cables: 1. Using a low-quality memory card. 2. Rear camera connector not connected properly. Display and Touch Screen Issues: If icons are not visible or the touch screen is unresponsive after updating firmware, it's likely due to a failed update process (Page 86). Rear Camera Live View Issue: There could be three reasons why rear camera live feed is not showing on the main screen: 1. Rear camera cable connected to sticky mount power port. 2. Rear camera not securely connected. Wi-Fi Connection Issues: Apple devices may disconnect and reconnect to your car's Wi-Fi due to priority switching (Page 88). Reconnecting to ROVE App: Uninstall and reinstall the app, then sign in and reconnect to R3's WiFi connection (Page 89). G-Sensor Settings: Update firmware to fix minor bug with compass direction. Set Parking Mode G-sensor feature accordingly to avoid false positive alarms. Firmware Update Issue: If your camera has an old firmware version, update it remotely using the ROVE App to fix compass direction issue. Contacting Customer Support: Email customer care at help@rovedashcam.com or text support number (visit) for assistance. Most emails are replied within 4-6 hours, and all questions are answered within 24 hours. Industry Canada Compliance Statement: This device complies with Industry Canada's licence-exempt operation subject to the following conditions: This device does not intentionally emit interference, and it must tolerate any interference that could cause it to malfunction. If you have questions or concerns about your device, please visit our support page at Page 95 for a list of frequently asked questions. For more immediate assistance, you can contact our customer service team via text message. Our response time is just six hours. You can also reach us by calling (401) 484-ROVE (7683) or emailing help@rovedashcam.com. Our business hours are Monday through Friday from 9am to 5pm Pacific Standard Time.

Rove dash cam update. Rove r2-4k dash cam setup. Rove dash cam player. Rove dash cam software update. Rove dash cam app. Rove dash cam discount code. How to use rove r2-4k dash cam. Rove dash cam coupon code.